


RoofPak™ Singlezone Roof Mounted Heating and Cooling Units

Group: **Applied Systems**

Part Number: **IM 926**

Date: **October 2008**

RPS/RDT/RFS/RCS 015C - 105C
MicroTech III® Unit Controller



Contents

Introduction	3	Enthalpy Control	85
Unit Nameplate	3	Hot Gas Bypass	86
Compressor Nameplate	3	SpeedTrol™ (N/A Unit Sizes 015C to 030C)	87
Gas Burner Nameplate	3	External Time Clock	87
Hazard Identification Information	3	Smoke and Fire Protection	87
Unit Description	4	Smoke Detectors	88
Typical Component Locations	4	Emergency Shutdown	88
Condenser Fan Arrangement	6	Freeze Protection	88
Refrigeration Piping	7	Field Output Signals	89
Control Locations	9	Entering Fan Temperature Sensor	90
Control Panel	11	Duct High Pressure Limit	90
Controls, Settings, and Functions	20	Variable Frequency Drive Operation	90
Mechanical Installation	22	Convenience Receptacle/Section Lights	90
Unit Clearances	22	DesignFlow™ Outdoor Air Damper Option	91
Ventilation Clearance	23	Propeller Exhaust Fan Option	94
Overhead Clearance	23	Exhaust Fan On/Off Control	96
IBC Seismic Compliant Units	26	Ultraviolet Lights Option	96
Roof Curb Arrangement	26	Ultraviolet Light Operation	97
Post and Rail Arrangement	27	Check, Test, and Start Procedures	98
Post and Rail Mounting	30	Servicing Control Panel Components	98
Rigging and Handling	30	Before Start-Up	98
Reassembly of Split Units	33	Power Up	98
RPS/RDT Factory Split at Condensing Unit	35	Fan Start-Up	99
RFS/RCS Permanent Split Systems	41	Economizer Start-Up	99
Unit Piping	47	Compressor Startup	99
Steam Coil Piping	49	Scroll Compressor Rotational Direction	100
Steam Piping Recommendations	49	Heating System Start-up	102
Steam Trap Recommendations	50	Air Balancing	102
Damper Assemblies	51	Sheave Alignment	102
Cabinet Weather Protection	53	Drive Belt Adjustment	103
Installing Ductwork	53	Mounting and Adjusting Motor Sheaves	103
Installing Duct Static Pressure Sensor Taps	54	Final Control Settings	107
Installing Building Static Pressure Sensor Taps	55	Maintenance and Service	110
Electrical Installation	56	Servicing Control Panel Components	110
Field Power Wiring	56	Planned Maintenance	110
Field Control Wiring	59	Unit Storage	110
Preparing Unit for Operation	60	Gas Furnace	111
Spring Isolated Fans	60	Bearing Lubrication	111
Adjusting Spring Mounts	60	Setscrews	113
Relief Damper Tie-Down	61	Supply Fan Wheel-to-Funnel Alignment	114
Adjusting Scroll Dampers	61	Refrigerant Leaks	115
Adjusting Supply Fan Thrust Restraints	61	Refrigerant Charge	115
Sequences of Operation	62	Servicing Refrigerant Sensors or Switches	115
Power-up	62	Winterizing Water Coils	116
Fan Operation	62	Control Panel Components	116
Economizer Operation	63	Replacement Parts List	120
Mechanical Cooling Operation	63	Service and Warranty Procedure	121
Heating	64	Compressor Arrangements	121
MicroTech III Controller Operation	65	Replacing Portions of a Tandem or Trio Compressor	122
Using the Keypad/Display	65	Limited Product Warranty (North America)	123
Passwords	65	Exceptions	123
Navigation Mode	66	Assistance	123
Edit Mode	66	Sole Remedy	123
Wiring Diagrams	67	Rooftop Equipment Warranty Regist. Form	124
Unit Options	85	Quality Assurance Survey Report	127
Control Actuators	85		

This manual provides general information about the “C” vintage McQuay RoofPak applied rooftop unit, models RPS, RDT, RFS, and RCS. In addition to an overall description of the unit, it includes mechanical and electrical installation procedures, commissioning procedures, sequence of operation information, and maintenance instructions. For further information on the optional forced draft gas-fired furnace, refer to Bulletin No. IM 684 or IM 685.

The MicroTech® III applied rooftop unit controller is available on “C” vintage applied rooftop units. For a detailed description of the MicroTech III components, input/output configurations, field wiring options, requirements, and service procedures, see IM 919. For operation and information on using and programming the MicroTech III unit controller, refer to OM 920.

For a description of operation and information on using the keypad to view data and set parameters, refer to the appropriate program-specific operation manual (see Table 1).

Table 1: Program Specific Rooftop Unit Literature

	Rooftop unit control configuration	Operation manual bulletin number
VFDs	McQuay 208 - 460 V	OM 844-1
	McQuay 575 V	OM 895
	Non-McQuay	See vendor manuals


Unit Nameplate

The unit nameplate is located on the outside lower right corner of the main control box door. It includes the unit model number, serial number, unit part number, electrical characteristics, and refrigerant charge.

Compressor Nameplate

On units with a single compressor on each circuit, the compressor includes one compressor nameplate.

Figure 1: Nomenclature



On units that utilize the tandem compressor design, each compressor includes an individual nameplate along with a nameplate identifying the tandem compressors.

Gas Burner Nameplate

On units that include gas heat, the nameplate is located on the lower right corner of the main control box door. It includes the burner model number, minimum/maximum input, maximum temperature rise, and minimum cfm.

On units that utilize the tandem scroll compressor design, each compressor includes an individual nameplate along with a nameplate identifying the tandem compressors.

On units that utilize the tandem reciprocating design, each compressor includes an individual nameplate.

Hazard Identification Information

⚠ DANGER

Dangers indicate a hazardous situation which will result in death or serious injury if not avoided.

⚠ WARNING

Warnings indicate potentially hazardous situations, which can result in property damage, severe personal injury, or death if not avoided.


⚠ CAUTION

Cautions indicate potentially hazardous situations, which can result in personal injury or equipment damage if not avoided.

Introduction

Unit Description

Figure 2: RPS/RDT/RFS/RCS Unit



Typical Component Locations

Figure 2 shows an RPS/RDT/RFS/RCS unit. Figure 3 shows a typical RPS unit with the locations of the major components.

Figure 4 on page 5 shows a typical RDT unit with the locations of the major components.

These figures are for general information only. See the project's certified submittals for actual specific dimensions and locations.

Figure 3: Typical Component Locations—RPS Units





Figure 4: Component Locations—RDT Units



Introduction

Condenser Fan Arrangement

Table 2 shows the condenser fan numbering conventions and locations for each unit size.

Table 2: Condenser Fan Arrangement

Unit size	Refrigerant circuit	Arrangement	Unit size	Refrigerant circuit	Arrangement
015C 018C 020C	1 or 2		060C 070C	1 2	
025C 030C	1 or 2		075C 080C 090C	1 2	
036C 040C	1 2		105C	1 2	
045C 050C	1 2				

Refrigeration Piping

This section presents the unit refrigeration piping diagrams for the various available configurations.

Figure 5: Circuit Schematic





Figure 6: Condenser Piping, Scroll Compressors, 1 to 3 Compressors Per Circuit Provided (015C - 105C)



Introduction

Figure 7: Air Handler Piping (Flat DX)





Figure 8: Air Handler Piping (Staggered DX)




Control Locations

Figure 9 (RPS Units) and Figure 10 on page 10 (RDT Units) show the locations of the various control components mounted throughout the units. See “Control Panel” on page 11 for the locations of control components mounted in control panels. Additional information is included in Table 3 on page 20 and


the wiring diagram legend, which is included in “Wiring Diagrams” on page 67. Components mounted in the blow-through section are located in the same position within the draw-through section.

Figure 9: Control Locations—RPS Units



Introduction


Figure 10: Control Locations—RDT Units



Control Panel

The unit control panels and their locations are shown in the following figures. These figures show a typical unit configuration. Specific unit configurations may differ slightly from these figures depending on the particular unit options.

Figure 11: Control Panel Locations



Introduction

Figure 12: Typical Main Control Panel, 015C - 030C, 460 Volt





Figure 13: Typical Main Control Panel, 036C - 040C, 208 Volt



Introduction

Figure 14: Typical Main Control Panel, 045C - 075C, 460 Volt





Figure 15: Typical Main Control Panel, 080C - 105C, 460 Volt



Introduction

Figure 16: Typical Gas Heat Panel, 1000 MBH




Figure 17: Typical Prop Exhaust Panel, 3 Fans, 460 Volt




Figure 18: VFD Bypass Panel, 40 HP, 460 Volt)




Figure 19: RCS Control Panel with MicroTech III, 015C - 040C




Figure 20: RCS Control Panel with MicroTech III, RPS 045C - 075C





Figure 21: RCS Control Panel with MicroTech III, RPS 080C - 105C



Introduction

Figure 22: Electric Heat Panel, Sizes 015C - 040C




Figure 24: Electric Heat Panel, Sizes 080C - 105C




Figure 23: Electric Heat Panel, Sizes 045C - 075C





Figure 25: Harness Plug Connector Detail



Introduction

Controls, Settings, and Functions

Table 3 below lists all of the unit control devices and associated information.

Table 3: Controls, Settings, and Functions

Symbol	Description	Function	Reset	Location	Setting	Range	Differential	Part no.
CS1 & 2	Switch (toggle), refrigerant circuit	Shuts off compressor control circuits manually	N/A	Main control panel	N/A	N/A	N/A	01355000
DAT	Discharge air temperature sensor	Senses discharge air temperature	N/A	Discharge air section	N/A		N/A	060004705
DHL	Duct high limit switch	Prevents excessive VAV duct pressures; shuts off fan	Auto	Main control panel	3.5" w.c (871.8 Pa)	0.05–5.0" wc (12.5–1245.4 Pa)	.05" wc (12.5 Pa), fixed	065493801
EFT	Entering fan air temperature sensor	Senses entering fan air temperature	N/A	Inlet of supply fan	N/A		N/A	060004705
FP1, 2	Evaporator frost protection	Senses low refrigerant temperature	N/A	Return bends of evaporative coil	Opens at 30°F Closes at 45°F	N/A	N/A	072501901
FS1	Freezestat	Shuts off fans, opens heating valve, and closes outdoor damper if low air temperature at coil is detected	Auto	Heating section	38°F (3°C) or as required	35°F–45°F (2°C–7°C)	12°F (7°C), fixed	065830001
HP1, 2,	High pressure control	Stops compressor when refrigerant discharge pressure is too high	Manual (relay latched)	Compressor	See page 115.	N/A	100 psi (689 kPa)	047356120
LP1, 2	Low pressure control	Stops compressor when suction pressure is too low (used for pumpdown)	Auto	Compressor	See page 115.	N/A	25 psi (172 kPa)	047356111
MCB	Main control board	Processes input information	N/A	Main control box	N/A	N/A	N/A	060006101
MP1–6	Compressor motor protector	Senses motor winding temperature, shuts off compressor on high temperature. Notes: 1. Unit size 018C compressors include internal motor protector. 2. Unit sizes 020C–036C, circuit #1 compressors include internal motor protector (refer to unit wiring diagram).	Auto at 3400 ohms	Compressor junction box	9 K–18 K ohms	700 ohms cold	N/A	044691509
OAE	Enthalpy control (electro-mechanical)	Returns outside air dampers to minimum position when enthalpy is too high	Auto	Economizer section	"B" or as required	A–D	Temperature: 3.5°F (2°C) Humidity: 5% fixed	030706702
	Enthalpy control (electronic)	Returns outside air dampers to minimum position when outside air enthalpy is higher than return air enthalpy (use RAE)	Auto	Economizer section	Fully CW past "D" (when used with RAE)	A–D	N/A	049262201
OAT	Outside air temperature sensor	Senses outside air temperature	N/A		N/A		N/A	060004705
PC5	Dirty filter switch	Senses filter pressure drop	Auto	First filter section	As required	.05-5" wc (12.5–1245.4 Pa)	.05" wc (12.5 Pa)	065493801
PC6	Dirty filter switch	Senses filter pressure drop	Auto	Final filter section	As required	.05-5" wc (12.5–1245.4 Pa)	.05" wc (12.5 Pa)	065493801
PC7	Airflow proving switch	Senses supply fan pressure to prove airflow	Auto	Supply fan section	.10" wc (25 Pa)	.03-1.40" wc (7.5–348 Pa)	.03" wc (7.5 Pa), fixed	060015801
PS1, 2	Pumpdown switch	Used to manually pump down compressor	N/A	Condenser control box	N/A	N/A	N/A	01355000
RAE	Return air enthalpy sensor	Used to compare return air enthalpy to outside air enthalpy (used with OAE)	N/A	Economizer section	N/A	N/A	N/A	049262202
RAT	Return air temperature sensor	Senses return air temperature	N/A	Return air section	N/A		N/A	060004705

Table 3: Controls, Settings, and Functions (continued)

Symbol	Description	Function	Reset	Location	Setting	Range	Differential	Part no.
SD1	Smoke detector, supply air	Initiates unit shutdown if smoke is detected	Manual	Discharge air section	N/A	N/A	N/A	04925001
SD2	Smoke detector, return air	Initiates unit shutdown if smoke is detected	Manual	Return air section	N/A	N/A	N/A	04925001
SPS1	Static pressure sensor duct #1	Converts static pressure signals to voltage signals	N/A	Main control box	N/A	0–5" wc (0–1245.4 Pa) 1–6 V (dc) out	N/A	049545007
SPS2	Static pressure sensor duct #2	Converts static pressure signals to voltage signals and sends them to MicroTech III controller	N/A	Main control box	N/A	0–5" wc (0–1245.4 Pa) 1–6 V (dc) out	N/A	049545007
	Static pressure sensor: building (space) pressure	Converts static pressure signals to voltage signals.	N/A	Main control box	N/A	-025–0.25" wc (-62.3–62.3 Pa) 1–5 V (dc) out	N/A	049545006
SV1, 2	Solenoid valve (liquid line)	Closes liquid line while compressor is off	N/A	Condenser section	N/A	N/A	N/A	See parts catalog
S1	System switch	Shuts off entire control circuit (except crankcase heaters)	N/A	Main control box	N/A	N/A	N/A	001355000
S7	ON-OFF-AUTO switch	Used to manually switch unit	N/A	Main control box	N/A	N/A	N/A	

FanTrol

The FanTrol, provided on all units, is a method of head pressure control that automatically cycles the condenser fans in response to ambient air temperature. This feature maintains

head pressure and allows the unit to run at low ambient air temperatures.

RPS/RDT and RCS units have two independent refrigerant circuits with one to four condenser fans being controlled independently by the ambient air temperature of each circuit.

Table 4: R-22 FanTrol Setpoints in °F with MicroTech III Controls

RPS RCS RDT RPR	Degrees Farenheit							
	B05		B06		B07		B08	
	Setpoint	Differential	Setpoint	Differential	Setpoint	Differential	Setpoint	Differential
015 to 020C	0	5	60	5	—	—	—	—
025 to 030C	0	5	65	5	—	—	—	—
036	0	5	70	5	—	—	—	—
045 to 045C	0	5	65	5	—	—	—	—
050	0	5	60	5	—	—	—	—
060	0	5	25	5	70	5	—	—
070	0	5	40	5	70	5	—	—
075 to 090C	0	5	65	5	75	5	0	5
105	0	5	0	5	58	5	70	5

Table 5: R-407C FanTrol Setpoints in °F with MicroTech III Controls

RPS, RCS, RDT	Degrees Farenheit							
	B05		B06		B07		B08	
	Setpoint	Differential	Setpoint	Differential	Setpoint	Differential	Setpoint	Differential
015	0	5	60	5	—	—	—	—
018 to 020C	0	5	0	5	—	—	—	—
025 to 036C	0	5	65	5	—	—	—	—
040	0	5	60	6	—	—	—	—
045	0	5	55	5	—	—	—	—
050	0	5	50	5	—	—	—	—
060	0	5	15	5	70	5	—	—
070	0	5	30	5	70	5	—	—
075	0	5	65	5	75	5	0	5
080 to 090C	0	5	65	5	75	5	0	5
105	0	5	0	5	52	5	70	5

Mechanical Installation

Note: The installation of this equipment shall be in accordance with the regulations of authorities having jurisdiction and all applicable codes. It is the responsibility of the installer to determine and follow the applicable codes. Low head pressure may lead to poor, erratic refrigerant feed control at the thermostatic expansion valve. The units have automatic control of the condenser fans which should provide adequate head pressure control down to 50°F (10°C) provided the unit is not exposed to windy conditions. The system designer is responsible for assuring the condensing section is not exposed to excessive wind or air recirculation.

cartons have been received. **If the unit has become dirty during shipment (winter road chemicals are of particular concern), clean it when received.**

All units should be inspected carefully for damage when received. Report all shipping damage to the carrier and file a claim. In most cases, equipment ships F.O.B. factory and claims for freight damage should be filed by the consignee.

Before unloading the unit, check the unit nameplate to make sure the voltage complies with the power supply available.

CAUTION

Sharp edges on sheet metal and fasteners can cause personal injury. This equipment must be installed, operated, and serviced only by an experienced installation company and fully trained personnel.

Unit Clearances


Service Clearance

Allow an approximate service clearance as indicated in Figure 26. Also, McQuay recommends providing a roof walkway to the rooftop unit as well as along two sides of the unit that provide access to most controls and serviceable components.

Receiving Inspection

When the equipment is received, all items should be carefully checked against the bill of lading to be sure all crates and

Figure 26: Service Clearances



Ventilation Clearance

Below are minimum ventilation clearance recommendations. The system designer must consider each application and provide adequate ventilation. If this is not done, the unit will not perform properly.

Unit(s) surrounded by a screen or a fence:

- 1 The bottom of the screen or fence should be at least 1 ft. (305 mm) above the roof surface.
- 2 The distance between the unit and a screen or fence should be as described in Figure 26.
- 3 The distance between any two units within a screen or fence should be at least 120" (3048 mm).

Unit(s) surrounded by solid walls:

- 1 If there are walls on one or two adjacent sides of the unit, the walls may be any height. If there are walls on more than two adjacent sides of the unit, the walls should not be higher than the unit.
- 2 The distance between the unit and the wall should be at least 96" (2438 mm) on all sides of the unit.
- 3 The distance between any two units within the walls should be at least 120" (3048 mm).


Do not locate outside air intakes near exhaust vents or other sources of contaminated air.

If the unit is installed where windy conditions are common, install wind screens around the unit, maintaining the clearances specified (see Figure 27). This is particularly important to prevent blowing snow from entering the outside air intake and to maintain adequate head pressure control when mechanical cooling is required at low outdoor air temperatures.

Overhead Clearance

- 1 Unit(s) surrounded by screens or solid walls must have no overhead obstructions over any part of the unit.
- 2 The area above the condenser must be installed unobstructed to allow vertical air discharge.
- 3 The following restrictions must be observed for overhead obstructions above the air handler section (see Figure 27):
 - a There must be no overhead obstructions above the furnace flue, or within 9" (229 mm) of the flue box.
 - b Overhead obstructions must be no less than 96" (2438 mm) above the top of the unit.
 - c There must be no overhead obstructions in the areas above the outside air and exhaust dampers that are farther than 24" (610 mm) from the side of the unit.

Figure 27: Overhead Clearance



Mechanical Installation

Roof Curb Assembly and Installation

Locate the roof curb and unit on a portion of the roof that can support the weight of the unit. The unit must be supported to prevent bending or twisting of the machine.

If building construction allows sound and vibration into the occupied space, **locate the unit over a non-critical area. It is the responsibility of the system designer to make adequate provisions for noise and vibration in the occupied space.**

WARNING


Mold can cause personal injury. Some materials such as gypsum wall board can promote mold growth when damp. Such materials must be protected from moisture that can enter units during maintenance or normal operation.

Install the curb and unit level to allow the condensate drain to flow properly and allow service access doors to open and close without binding.

Integral supply and return air duct flanges are provided with the RPS/RFS roof curb, allowing connection of duct work to the curb before the unit is set. The gasketed top surface of the duct flanges seals against the unit when it is set on the curb. These flanges must not support the total weight of the duct work. See “Installing Ductwork” on page 53 for details on duct connections. It is critical that the condensate drain side of the unit be no higher than the opposite side.

Assembly of a typical RPS/RDT roof curb is shown in Figure 29 on page 25. Parts A through K are common to all units having bottom return openings. Depending on the unit length, Parts L and M may be included with the roof curb kit to create the correct overall curb length. Figure 28 shows the assembly of the RCS roof curb.

Figure 28: RCS Roof Curb Assembly



RCS unit size	“ZZ”	
	in.	mm
015C–030C	31.0	787
036C & 040C	94.0	2057
045C–060C	62.0	1575
070C–105C	100.0	2540

RCS Assembly instructions

- 1 Set curbing parts “A” (Figure 28) in place making sure that the orientation complies with the assembly instructions. Check alignment of all mating bolt holes.
- 2 Bolt curbing parts together using fasteners provided.
- 3 Curb must be level from side to side and over its length.
- 4 Weld curbing in place. Caulk all seams watertight and insulate between channels.
- 5 Flash curbing into roof as shown in Detail C.

RPS/RDT Assembly instructions

- 1 Set curbing parts A through K per dimensions shown over roof opening or on a level surface (see Figure 29 on page 25). Note location of return and supply air openings.
- 2 If applicable, set other curbing parts (D, L, M, etc.) in place making sure that the orientation complies with the assembly instructions (see Detail A). Check alignment of all mating bolt holes.

- 3 Bolt curbing parts together using fasteners provided. Tighten all bolts finger tight.
- 4 Square entire curbing assembly and securely tighten all bolts.
- 5 Position curb assembly over roof openings. Curb must be level from side to side and over its length. Check that top surface of the curb is flat with no bowing or sagging.
- 6 Weld curbing in place. Caulk all seams watertight. Remove backing from 0.25" (6 mm) thick × 1.50" (38 mm) wide gasketing and apply to surfaces shown by cross-hatching.
- 7 Flash curbing into roof as shown in Detail B.
- 8 Parts E and F are not required on units with no return shaft within the curb perimeter.
- 9 Parts G and H are not required on units with no supply shaft within the curb perimeter.
- 10 Be sure that electrical connections are coordinated (see Figure 35).

Figure 29: RPS/RFS Roof Curb Assembly




Table 6: Roof Curb Assembly Dimensions

Unit size	Fan	"X"		"Y"		"XX"		"YY"		Unit size	"Z"		"W"	
		in	mm	in	mm	in	mm	in	mm		in	mm	in	mm
015-040C	None	24.0	610	82.0	2083	6.8	173	1.5	38	015C-030C	45.9	1165	20.0	508
	(2) 15" FC	24.0	610	82.0	2083	6.8	173	1.5	38	036C and 040C	94.0	2388	20.0	508
	30" AF	30.0	762	76.0	1930	6.8	173	4.5	114	045C-075C	77.0	1956	28.0	712
	40" AF	36.0	914	78.0	1981	14.8	376	3.5	89	80C-90C	113	2870	38.0	965
045C-075C	All units	38.0	965	87.0	2210	8.8	222	3.5	89	105C	113	2870	46.0	1168
80C-135C	All units	62.0	1575	87.0	2210	8.8	222	3.5	89					

Note: These dimensions do not apply to units with energy recovery wheels.

Mechanical Installation

IBC Seismic Compliant Units

It is important to follow these installation instructions for all IBC Seismic compliant McQuay Rooftop units.

IBC Seismic compliant McQuay Rooftop units can be mounted to either a roof curb or a post and rail setup. If using a roof curb, it must be specifically designed for seismic restraint and be IBC seismic compliant (spring isolated or non-isolated type seismic roof curbs are available). Typical construction of a seismic rated roof curb is from structural steel framing and contains seismic hold down brackets for attachment of the rooftop unit (see Figure 30). Post and rail arrangements rated for seismic applications are also available (spring isolated or non-isolated).

IMPORTANT: An acceptable IBC seismic installation provides a direct positive attachment to both the building structure and the roof mounted equipment.

Refer to the roof curb manufacturer's submittal drawings for actual roof curb assembly, attachment details and rigging instructions for both roof curb and post and rail arrangements.

Roof Curb Arrangement

- 1 Set the rooftop unit on the roof curb (McQuay Rooftop units are designed to overhang from the roof curb).
- 2 Adjust the seismic hold down brackets so they come into contact with the unit base per Figures 31 and 32 on page 27.
 - a The seismic hold down brackets should be adjustable and accommodate the overhang of the rooftop unit.
 - b If the hold down bracket cannot reach the unit base, use a shim spacer. See Figure 32 on page 27.
- 3 Weld each seismic hold down bracket (and shim spacer, if required) to the unit base as shown in the acceptable weld zone detail in Figure 31 on page 27.

CAUTION

When welding unit to the curb, do not damage wiring (control panel side). Weld **ONLY** in the specified zone in the acceptable weld zone (see Figure 31 on page 27). Welding must comply with weld fillet size, etc. as indicated in Figure 31 on page 27.

Note: High temperature insulation is installed at the factory to allow for field welding along the lower front edge region of the unit base.

Figure 30: Typical Seismic Roof Curb (Spring Isolated)




Figure 31: Welding of Hold Down Brackets—Unit Base, Cross-Sectional View





Figure 32: Shim Spacers on Hold Down Brackets



Post and Rail Arrangement

- 1 Set the rooftop unit on the rails. The rails should run lengthwise and support the entire unit base.
- 2 Weld both sides of the unit directly to each rail as shown in Figures 33 and 34 on page 28. The total number of welds required is dependent on the length of the unit.
 - a Make the fillet welds 2 inches long, spaced 48 inches apart on centers.
 - b Place the end welds 6 to 12 inches from the unit edge.

CAUTION

When welding unit to the curb, do not damage wiring (control panel side). Weld **ONLY** in the specified zone in the acceptable weld zone (see Figure 33 on page 28). Welding must comply with weld fillet size, etc. as indicated in Figure 33 on page 28.

Note: High temperature insulation is installed at the factory to allow for field welding along the lower front edge region of the unit base.

Mechanical Installation

Figure 33: Welding of Unit to Rail—Unit Base, Cross-Sectional View






Figure 34: Weld Locations for Rail Arrangement



Mechanical Installation

Figure 35: Typical Power Wire Entrance, Curb View (RPS/RFS 015C - 040C Shown, Refer to Submittal Drawings)



Mechanical Installation

Post and Rail Mounting

When mounting by post and rail, run the structural support the full length of the unit. Locate the structural member at the base of the unit as shown in Figure 36, assuring the I-beam is well supported by the structural member.

CAUTION

The unit must be level side to side and over the entire length. Equipment damage can result if the unit is not level.

If resilient material is placed between the unit and the rail, insert a heavy steel plate between the unit and the resilient material to distribute the load. Seal cabinet penetrations (electrical, piping, etc.) properly to protect against moisture and weather.

Figure 36: Post and Rail Mounting




Table 7: "W" Dimension (Figure 36)

Unit	Dimension "W"	
	inches	mm
015C-040C	94	2388
045C-135C	99	2538

Rigging and Handling

Lifting brackets with 2" (51 mm) diameter holes are provided on the sides of the unit.

Use spreader bars, 96" to 100" (2438 to 2540 mm) wide, to prevent damage to the unit cabinet. Avoid twisting or uneven lifting of the unit. The cable length from the bracket to the hook should always be longer than the distance between the outer lifting points.

If the unit is stored at the construction site for an intermediate period, follow these additional precautions:

- 1 Support the unit well along the length of the base rail.
- 2 Level the unit (no twists or uneven ground surface).
- 3 Provide proper drainage around the unit to prevent flooding of the equipment.


- 4 Provide adequate protection from vandalism, mechanical contact, etc.
- 5 Securely close the doors.
- 6 If there are isolation dampers, make sure they are properly installed and fully closed to prevent the entry of animals and debris through the supply and return air openings.
- 7 Cover the supply and return air openings on units without isolation dampers.

Figure 37 shows an example of the rigging instruction label shipped with each unit.

WARNING

Use all lifting points. Improper lifting can cause severe personal injury and property damage.

Figure 37: Rigging and Handling Instruction Label



CAUTION

Lifting points may not be symmetrical to the center of gravity of the unit. Ballast or unequal cable lengths may be required.

Lifting Points

Refer to Figure 38 and Figure 39 and the following calculations to determine whether a four or six point lift is required.

X = distance from the entering air end of the unit (or shipping section) to the first lifting lug in the direction of air flow.

For all unit or shipping sections with outdoor air/return air options, X = 48"

For shippings sections without outdoor air/return air options, x = 0

Y = distance from condenser or leaving air end of unit to the last lifting lug.

Mechanical Installation

For all units or shipping sections with condensers, $Y = 36.5$ (sizes 50-60) or $Y = 30.0$ (sizes 70-105) or $Y = 38.0$ (sizes 110-115)

For all units or shipping sections without condensers, $Y = 0$.

Installation

Z = total base rail length of the units.

Note: Z excludes hoods and overhung parts extending past base rails of the unit.

$$A = Z - X - Y$$

If $A < 288"$, 4-point lift is sufficient

If $a > 288"$, 6-point lift is required

B = distance from first lifting lug to middle lifting lug on units with 6-point lift.

$$B = A / 2 \pm 48"$$

Note: Middle lifting lug may be installed on either side of the midpoint to avoid interference with condensate drains.

Figure 38: Unit Type RPS/RDT Lifting Points





Figure 39: Unit Type RFS or RPS/RDT Factory Split at Condenser



Mechanical Installation

Figure 40: Unit Type RCS




Figure 41: Unit Type RCS or Condenser Section from RPS/ RDT Factory Split at Condenser





Figure 42: RPS Factory Split at Supply Fan Section



Reassembly of Split Units

Although RoofPak units typically ship from the factory as complete units, they may be split at the factory in one of three possible configurations.

- 1 The RFS air handler section and RCS condenser section ship as two separate units, each with its own power supply and unit nameplate. This configuration is ordered when the condenser is intended to remain remote from the air handler because of space or structural constraints.

On all units except the RFS with end discharge, refrigerant piping is stubbed out the exterior of the cabinet for convenient field piping between the RCS and RFS units, and all necessary refrigeration components are provided. Detailed instructions are on pages 41 to 47.

- 2 The RPS/RDT unit factory split at the condenser ships as an air handler section and a condenser section that is recoupled together on the roof. This configuration is ordered if a packaged RPS unit is desired, but cannot go to the job site because of shipping length or weight limitations. A single nameplate is attached to the air handler section and power is fed to both sections through the main control box, as in a non-split RPS/RDT unit. Detailed instructions are on pages 35 to 41.

All interconnecting piping and refrigeration components are provided so that when the sections are coupled together, only field-provided couplings are required to connect the piping.

- 3 The RPS unit factory split at the fan ships as two pieces, split at the supply fan bulkhead, to recouple together on the roof. Like the RPS/RDT unit factory split at the condenser, this configuration is ordered if shipping length or weight limitation prevents a packaged RPS/RDT from being ordered. Splitting at the fan has the advantage of leaving all factory refrigerant piping intact so field evacuation and charging is not required. Detailed instructions are on pages 33 to 35.

A single nameplate is attached to the air handler section and power is fed to both sections through the main control box, as in a non-split RPS/RDT unit.


RPS/RDT Factory Split at Fan

Field reassembly of an RPS/RDT unit that shipped split at the fan takes place in three phases: (1) setting the sections, (2) mechanically recoupling the cabinet, and (3) reconnecting power and control wiring.

Phase I. Set sections (Figure 43)

- 1 Remove top cap and save for Phase II, Step 1.
- 2 Remove screws on fan panel, leaving retainer clips in place to secure bulkhead. Save screws for Phase II, Step 5.
- 3 Remove plywood and retaining angles from unit and discard.
- 4 Carefully lower both sections of unit (fan end and discharge end) into place, making sure the roof curb engages the recesses in the unit base.

Figure 43: Set Sections—Steps 1–4, RPS Factory Split at Supply Fan




Mechanical Installation

Phase II. Reassemble cabinet (Figure 44)

- 1 Reinstall top cap removed in Phase I, Step 1.
- 2 Caulk (watertight) ends of splice cap.
- 3 Caulk (watertight) vertical seam.
- 4 Install #10 screws (provided).
- 5 Install screws (.25–20 × .75) removed in Phase I, Step 2.
- 6 Install splice cover (provided).

Figure 44: Re-Assemble Cabinet



Phase III. Reconnect power and control wiring


The DX coil/condenser section contains power and control harnesses that have their excess length in the blank or heat section, which normally is immediately downstream of the fan. Once the sections are physically reconnected, the ends of the power harness are fed back through the unit base into the junction box, per the unit's electrical schematics.

CAUTION

Connect the power block correctly and maintain proper phasing. Improper installation can cause severe equipment damage.

- 1 Make electrical connections and reinstall inner raceway cover as shown in Figure 45.


Figure 45: Electrical Connections and Raceway Cover Installation



- 2 When power wire reconnection is complete, reinstall the inner raceway cover in the blank or heat section. Figure 45 shows a typical installation of the raceway cover.
- 3 Run the control harnesses by removing the external raceway covers on either side of the unit split.
- 4 Remove the excess harness length from the external raceway on the DX side of the split; then route along the raceway, through the bushed hole in the fan section and into the junction box where control wiring terminal blocks are provided for reconnection.
- 5 Make all electrical connections per the unit's electrical schematics.

- 6 Reinstall the external raceway covers after routing of the control wires is complete.
- 7 Draw through cooling coils only. Reconnect refrigerant piping. These refrigerant circuits for these units are shipped with a holding charge only. Figure 46 illustrates what the installer sees at the shipping split
 - a To bridge the gap and connect the piping, remove the refrigerant piping caps and add fittings and copper tubing, as required.
 - b Evacuate and charge the unit. See page 43 for further details.

Figure 46: Refrigerant Lines



RPS/RDT Factory Split at Condensing Unit

Field reassembly of an RPS/RDT unit that has shipped split at the condenser takes place in three phases: (1) setting the sections and mechanically recoupling the cabinet, (2) reconnecting refrigerant piping, and (3) reconnecting power and control wiring.

Phase I. Set sections and reassemble cabinet


- 1 Before setting sections together, remove top cap on air handler section and wire cover on condensing section. See Figure 47. Discard wire cover.
- 2 Remove piping cover and discard. Reinstall screws in holes to prevent water leakage.
- 3 Loosen piping brackets and clamps on both sections so refrigerant lines can be moved out of the way to prevent interference and damage as the sections are set together. See Figure 47.
- 4 Physically rig the air handler section into place.
- 5 After air handler is installed, remove lifting bracket and adjacent bolts on air handler unit (see Figure 47) and save for Step 7. Discard lifting bracket.

If unit is post-and-rail mounted on a structural beam that runs the full length of the unit, leave bolts and lifting brackets in place.

- 6 On condenser unit, remove bolts adjacent to lifting bracket and save for Step 12.

Mechanical Installation

Figure 47: RPS/RDT Split at Condensing Unit Reassembly, Steps 1–6




Note: RFS units with front discharge do NOT include refrigerant piping to the DX coil. Field piping is required.

7 Install condenser support on air handler unit as shown in Figure 48. Fill unused holes in unit base with bolts saved in Step 6.

If unit is post-and-rail mounted on a structural beam that runs the full length of the unit, bolts and lifting brackets were not removed. Omit this step.

Figure 48: Installing Condenser Support, Step 7



- 8 Lower the condenser unit until nearly level with main unit. See Figure 49.
- 9 Carefully shift condenser unit until it rests against the main unit. See Figure 49.



CAUTION


Do not damage piping components while setting condensing unit in place.



CAUTION

Support condenser unit by crane during Step 9 since condenser support rail is not designed to withstand the heavy lateral forces of a unit being slid over it.

Figure 49: Setting Condenser Unit in Place, Steps 8 and 9




Mechanical Installation

- 10 After condenser unit is set in place, install the top cap saved in Step 1. See Figure 50.
- 11 Caulk (watertight) ends of splice cap and vertical seam. See Figure 50.

- 12 Install 1/2" bolt removed in Step 5. See Figure 50.
- 13 Install splice cover (provided), see Figure 50.

Figure 50: Caulk and Install Parts, Steps 10–14



Phase II. Reconnect refrigerant piping

All refrigerant piping required to reconnect the two sections is provided so when the piping closures are cut off, piping from the air handler and condenser sections lines up.


- 1 Connect piping using field-supplied couplings.
- 2 As with RFS/RCS units, both sections of the RPS/RDT split-at-condenser unit ship from the factory with a holding charge. Before removing the piping closures, inspect the unit for line breakage or loosening of fittings.

- 3 Perform pressure testing as described in the “Leak Testing” section on page 42.

- 4 Perform evacuation, charging the system, and refrigerant charge requirements for the split-at-condenser unit per procedures on page 42.


Note: Use Tables 11 to 14 on pages 44 to 45 to determine refrigerant charge requirements for the RPS/RDT split-at-condenser. Because no field-installed refrigerant piping is required, the total charge per circuit is the sum of the base R-22 charge and the DX coil charge.

Figure 51: RFS/RCS 015 to 030 Refrigerant Piping Connections



Note: RFS units with front discharge do NOT include refrigerant piping to the DX coil. Field piping is required.

Figure 52: RFS/RCS 036 and 040 Refrigerant Piping Connections




Note: RFS units with front discharge do NOT include refrigerant piping to the DX coil. Field piping is required.

Table 8: Connection Sizes and Locations, Figures 51 and 52

Component circuit			Connection sizes				Connection locations							
			015C	020C	025C	030Cto 040C	RFS 015 to 030		RCS 015 to 030		RFS 036 and 040		RCS 036 and 040	
						X (in.)	Y (in.)	X (in.)	Y (in.)	X (in.)	Y (in.)	X (in.)	Y (in.)	
S1	Suction line	Ckt.1	1 1/8	1 1/8	1 5/8	1 5/8	9.00	5.70	67.60	6.25	8.25	5.70	59.50	19.30
S2	Suction line	Ckt.2	1 3/8	1 5/8	1 3/8	1 5/8	14.00	5.70	28.00	6.25	13.25	5.70	34.60	19.30
L1	Liquid line	Ckt.1	5/8	5/8	7/8	7/8	56.00	32.00	75.00	6.25	79.00	25.00	70.50	25.00
L2	Liquid line	Ckt.2	7/8	7/8	7/8	7/8	7.60	28.00	21.00	6.25	15.00	25.00	23.50	25.00
HG1	HGBP line	Ckt.1	7/8	7/8	7/8	7/8	52.00	10.00	60.80	6.25	67.00	6.70	64.60	6.60
HG2	HGBP line	Ckt.2	7/8	7/8	7/8	7/8	36.00	16.00	35.50	6.25	32.00	6.70	29.50	6.00

Mechanical Installation

Figure 53: RPS/RDT (Split)/RFS/RCS 045 to 105 Refrigerant Piping Connections



Note: RFS units with front discharge do NOT include refrigerant piping to the DX coil. Field piping is required.

Table 9: Connection Sizes and Locations, Figure 53

Component circuit			Connection sizes				Connection locations					
			045C	050C to 075C	080C to 90C	105C to 135C	RPS (split) and RFS 045 to 075C		RCS 045 to 075C		080 to 105C	
							X (in.)	Y (in.)	X (in.)	Y (in.)	X (in.)	Y (in.)
S1	Suction line	Ckt.1	1 5/8	2 1/8	2 1/8	2 5/8	11.7	5.2	21.	7.0	5.7	11.7
S2	Suction line	Ckt.2	1 5/8	2 1/8	2 1/8	2 5/8	7.5	5.2	16.5	7.0	5.7	7.5
L1	Liquid line	Ckt.1	7/8	7/8	1-1/8	1 1/8	81.5	29.1	81.5	29.1	29.1	81.4
L2	Liquid line	Ckt.2	7/8	7/8	1 1/8	1 1/8	10.3	29.1	10.3	29.1	29.1	10.4
HG1	HGBP line	Ckt.1	7/8	7/8	7/8	7/8	52.1	10.4	52.1	10.4	10.4	52.1
HG2	HGBP line	Ckt.2	7/8	7/8	7/8	7/8	40.9	4.7	40.9	4.7	4.7	40.9

Phase III. Reconnecting power and control wiring

The wire harnesses are coiled in the condenser section base rail (see Figure 54). The power wires into the lower base rail raceway and the control wires into the upper raceway.

- 1 Uncoil the harnesses and feed them through the base rail of the air handler section and make the proper connections. The power wires terminate to the load side of the contactors; the control wires plug into the plug patch panel.
- 2 The liquid line solenoid valve harness is split into two harnesses. Install one half in the plug patch panel in the main control box (see Figure 54).
- 3 The other half of the harness is located in conduit on the bulkhead of the air handler section (see Figure 54).
- 4 Terminate the conduit to the vertical raceway in the condenser section (see Figure 55).
- 5 Wire nut the ends of the two harnesses together.
- 6 The optional hot gas bypass solenoid valve harness is coiled in the upper raceway of the condenser base rail (see Figure 55). Route the plug end of the harness through the air handler raceway and into the main control cabinet and plug into the plug patch panel.

Figure 54: Connecting Power/Control Wiring (015C - 040C)





Figure 55: Remove Vertical Raceway



RFS/RCS Permanent Split Systems

Piping Recommendations

All field piping, wiring, and procedures must be performed in accordance with ASHRAE, EPA, and industry standards. Proper refrigerant piping can make the difference between a reliable system and an inefficient, problematic system.

The primary concerns related to piping are refrigerant pressure drop, a solid liquid feed to the expansion valves, continuous oil return and properly sized refrigerant specialties.

Insulate the suction line to reduce excessive superheat build-up. Insulate the liquid line, where located in areas above ambient temperature, to prevent loss of subcooling and consequent liquid flashing.

The recommended source for refrigerant piping techniques and sizing is the McQuay AG31-011 Refrigerant Piping Design Guide.

Although conflicting piping recommendations can be found in different sources, McQuay offers the following recommendations for these controversial issues.

The use of double risers for vertical gas risers is generally not required and should be used only as a last resort to maintain the minimum refrigerant flow to carry oil up the vertical risers. Slightly downsizing the vertical riser is a preferable option to providing double risers.

Slope the refrigerant lines 1" per 10 feet of horizontal run in the direction of refrigerant flow to assist oil return.

Pressure drops in the refrigerant lines should be maintained at or below the ASHRAE recommendations and line lengths should be made as short as possible. Exceeding these recommendations will decrease performance and could impact reliability.

Small traps should be provided at the base of each major vertical gas riser to assist in the collection of oil. If vertical risers exceed more than 25 feet, install a small trap at the midpoint and at a maximum of 20 foot intervals.

Use caution in sizing the liquid line in applications where the evaporator is above the outdoor section. The weight of the liquid refrigerant in the vertical column will decrease the pressure at the top of the riser (approximately 0.5 psi per foot of vertical rise) allowing some of the refrigerant to flash to a gas. Adequate refrigerant subcooling is needed at the outdoor section to prevent large volumes of refrigerant gas at the expansion valve.

Mechanical Installation

The piping systems should always extend above the highest component in the refrigeration system before dropping down to make the final refrigerant connections to components. This practice will hinder the draining of condensed refrigerant to the lower component when normal shutdown procedures do not occur (such as a power failure).

Note: Do not run refrigerant lines underground.

- 1 Use type K or L clean copper tubing. Thoroughly clean or braze all joints with high temperature solder. Make sure nitrogen is flowing through the tubes while brazing to minimize the formation of oxide contaminants.
- 2 Base piping sizes on temperature/pressure limitations as recommended in the following paragraphs. Under no circumstances should pipe size be based strictly upon coil or condensing unit piping connection size.
- 3 To determine the minimum tonnage required to carry oil up suction risers of various sizes, check the vertical suction risers using Table 10.

Table 10: Minimum Tonnage (R-22 or R-407C) to Carry Oil Up Suction Riser at 40°F Saturated Suction

Line size O.D.	Minimum tonnage
1 1/8"	1.5
1 3/8"	2.5
1 5/8"	3.8
2 1/8"	7.6
2 5/8"	13.10
3 1/8"	20.4
3 5/8"	29.7
4 1/8"	41.3

- 4 Size the liquid line for a pressure drop not to exceed the pressure equivalent of 2°F (1°C), 6 psi (41.4 kPa) saturated temperature. The RFS unit includes a factory installed filter-drier, solenoid valve, and sightglass in each liquid line, upstream of the thermostatic expansion valve.

Holding Charge

The RFS unit and RCS unit ship with a nitrogen holding charge. At the time the unit is received, a visual inspection of the unit piping should be made to be sure no breakage occurred or that the fittings did not loosen during shipping. A pressure test on the RCS units should indicate a positive pressure in the unit. If no pressure is evident, the unit must be leak tested and the leak repaired. Note and report this to the McQuay sales representative and freight carrier (if the loss is due to shipping damage).

WARNING

Before applying heat to remove brazed piping caps and plugs, *always* vent piping to atmosphere. Failure to do so can cause hazardous pressures, explosion, severe personal injuries, or death.

RCS—Vent to atmosphere by opening gauge ports at the compressors and liquid line shutoff valves. Make sure manual valves are not back seated to shut off the gauge ports.

RFS—Vent to atmosphere by cutting off the process tubes on the suction line caps.

The RFS unit does not have gauge ports for pressure measurement. If no positive pressure is detected when cutting off the process tubes and removing the tubing caps, the unit should be leak tested as described below, after the interconnecting piping has been brazed in place. This test will also confirm the integrity of the field braze joints.

Leak Testing

In the case of loss of the nitrogen holding charge, the unit should be checked for leaks prior to charging the complete system. If the full charge was lost, leak testing can be done by charging the refrigerant into the unit to build the pressure to approximately 10 psig and adding sufficient dry nitrogen to bring the pressure to a maximum of 125 psig. The unit should then be leak tested with halide or electronic leak detector. After making any necessary repair, the system should be evacuated as described in the following paragraphs.

WARNING

Do not use oxygen or air to build up pressure. Explosion hazard can cause severe personal injury or death.

Evacuation

After determining the unit is tight and there are no refrigerant leaks, evacuate the system. Use a vacuum pump with a pumping capacity of approximately 3 cu.ft./min. and the ability to reduce the vacuum in the unit to at least 1 mm (1000 microns).

- 1 Connect a mercury manometer or an electronic or other type of micron gauge to the unit at a point remote from the vacuum pump. For readings below 1 millimeter, use an electronic or other micron gauge.
- 2 Use the triple evacuation method, which is particularly helpful if the vacuum pump is unable to obtain the desired 1 mm of vacuum. The system is first evacuated to approximately 29" (740 mm) of mercury. Then add enough refrigerant vapor to the system to bring the pressure up to 0 pounds (0 microns).
- 3 Evacuate the system again to 29" (740 mm) of vacuum. Repeat his procedure three times. This method is most effective by holding system pressure at 0 pounds (0 microns) for a minimum of 1 hour between evacuations. The first pulldown removes about 90% of the noncondensables; the second removes about 90% of that remaining from the first pulldown. After the third

pulldown, only 1/10 of 1% of noncondensables remains. Table 16 on page 46 shows the relationship between pressure, microns, atmospheres, and the boiling point of water.

CAUTION

Before replacing refrigerant sensors or protective devices, see "Refrigerant Charge" on page 47 for an important warning to prevent an abrupt loss of the entire charge.

CAUTION

To prevent liquid return and damage to the compressor on systems with optional hot gas bypass, locate the bypass solenoid valve on the RCS, not on the RFS unit.

CAUTION

To service liquid line components, the manual shutoff valve is closed and refrigerant is pumped into the condenser. The pounds of refrigerant in the system may exceed the capacity of the condenser, depending on the amount of refrigerant in the liquid lines between the RFS and RCS units. Suitable means of containing the refrigerant is required.

Mechanical Installation

Table 11: Approximate R-22 Refrigerant Charge Per Circuit, 015C - 040C

Unit size	Base charge lbs per circuit (less DX coil)		EVAP.coil (lbs/CKT/coil row)	Additional charge for heat section additional length		Condenser pumpdown capacity* (lbs)
	Circuit #1	Circuit #2		Circuit #1	Circuit #2	
015 to 018	11	18	0.8/1.5	.5	1	47
020C	11	18	0.8/1.5	1	1	47
025C	23	22	1.7	1	1	72
030C	23	21	1.7	1	1	72
036C	32	32	1.7	1	1	106
040C	33	32	1.7	1	1	106

* Condenser pumpdown capacity is the total charge for both circuits and is based on volume between condenser entrance and liquid line solenoid at 90°F, 90% full

Table 12: Approximate R-22 Refrigerant Charge Per Circuit, 045C - 105C

Unit size	Base charge lbs per circuit (less DX coil)				DX coil charge lbs per circuit per coil row		Condenser pumpdown capacity** (lbs)
	RPS		RDT		DX=S*	DX=L*	
	Circuit #1	Circuit #2	Circuit #1	Circuit #2			
045C	34	33	34	28	2.5	—	108
050C	34	33	35	34	2.5	3.0	108
060C	35	34	35	34	2.5	3.0	108
070C	39	39	40	40	2.5	3.0	134
075C	39	39	40	40	2.5	3.0	134
080C	40	41	37	38	4.1	4.7	140
090C	46	47	44	47	4.1	4.7	160
105C	50	51	45	48	4.9	6.5	208

* DX coil configuration (S = Standard, L = Large) is identified by the eighth digit of the RPS/RDT or RFS model number, found on the unit nameplate. For example, DX = L for unit model number RFS06OCLY.

** Condenser pumpdown capacity is the total charge for both circuits and is based on volume between condenser entrance and liquid line solenoid at 90°F, 90% full.

Table 13: Approximate R-407C Refrigerant Charge Per Circuit, 015C - 040C

Unit size	Base charge lbs per circuit (less DX coil)		Evaporator coil (lbs/CKT/coil row)	Additional charge for heat section additional length		Condenser pumpdown capacity* (lbs)
	Circuit 1	Circuit 2		Circuit 1	Circuit 2	
015C to 018C	10	16	0.7/1.4	.5	1	45
020C	10	16	0.7/1.4	1	1	45
025C	21	20	1.6	1	1	68
030C	21	19	1.6	1	1	68
036C	29	29	1.6	1	1	101
040C	30	29	1.6	1	1	101

* Condenser pumpdown capacity is the total charge for both circuits and is based on volume between condenser entrance and liquid line solenoid at 90°F, 90% full

Table 14: Approximate R-407C Refrigerant Charge Per Circuit, 045C - 105C

Unit size	Base charge lbs per circuit (less DX coil)				DX coil charge lbs per circuit per coil row		Condenser pumpdown capacity** (lbs)
	RPS		RDT		DX=S*	DX=L*	
	Circuit #1	Circuit #2	Circuit #1	Circuit #2			
045C	31	30	31	26	2.3	—	103
050C	31	30	32	31	2.3	2.8	103
060C	32	31	32	31	2.3	2.8	103
070C	36	36	37	37	2.3	2.8	127
075C	36	36	37	37	2.3	2.8	127
080C	37	37	34	35	3.8	4.3	134
090C	42	43	41	43	3.8	4.3	152
105C	46	42	41	44	4.5	6.0	198

* DX coil configuration (S = Standard, L = Large) is identified by the eighth digit of the RPS/RDT or RFS model number, found on the unit nameplate. For example, DX = L for unit model number RFSO6OCLY.

** Condenser pumpdown capacity is the total charge for both circuits and is based on volume between condenser entrance and liquid line solenoid at 90°F, 90% full.

Table 15: Weight of Refrigerant in Copper Lines (Pounds Per 100 Feet of Type L Tubing)

O.D. line size	Vol. per 100 ft in cubic feet	Weight of refrigerant, lbs./100 feet							
		Liquid @100°F		Hot gas@120°F cond.		Suction gas (superheat to 85°F)			
		R-22	R-407C	R-22	R-407C	30°F		40°F	
						R-22	R-407C	R-22	R-407C
3/8"	0.054	3.84	3.64	0.20	0.46	0.052	0.047	0.077	0.071
1/2"	0.100	7.12	6.74	0.37	0.85	0.096	0.088	0.143	0.132
5/8"	0.162	11.53	10.92	0.61	1.38	0.156	0.142	0.232	0.214
7/8"	0.336	23.92	22.65	1.26	2.87	0.324	0.294	0.480	0.444
1 1/8"	0.573	40.80	38.62	2.14	4.89	0.552	0.501	0.819	0.756
1 3/8"	0.872	62.09	58.77	3.26	7.44	0.840	0.763	1.247	1.151
1 5/8"	1.237	88.07	83.37	4.63	10.55	1.191	1.082	1.769	1.633
2 1/8"	2.147	152.87	144.71	8.03	18.31	2.068	1.879	3.070	2.834
2 5/8"	3.312	235.81	223.23	12.38	28.25	3.189	2.898	4.736	4.372
3 1/8"	4.728	336.63	318.67	17.68	40.33	4.553	4.137	6.761	6.241
3 5/8"	6.398	455.54	431.23	23.92	54.57	6.161	5.598	9.149	8.445
4 1/8"	8.313	591.89	560.30	31.08	70.91	8.005	7.274	11.888	10.973

Mechanical Installation

Table 16: Pressure-Vacuum Equivalents

Absolute pressure above zero		Vacuum below 1 atmosphere		Approximate fraction of 1 atmosphere	H ₂ O boiling point at each pressure (°F)
Microns	PSIA	Mercury (mm)	Mercury (in)		
0	0	760.00	29.921	—	—
50	0.001	759.95	29.920	1/15,200	-50
100	0.002	759.90	29.920	1/7,600	-40
150	0.003	759.85	29.920	1/5,100	-33
200	0.004	759.80	29.910	1/3,800	-28
300	0.006	759.70	29.910	1/2,500	-21
500	0.009	759.50	29.900	1/1,520	-12
1,000	0.019	759.00	29.880	1/760	1
2000	0.039	758.00	29.840	1/380	15
4,000	0.078	756.00	29.760	1/189	29
6000	0.117	754.00	29.690	1/127	39
8,000	0.156	752.00	29.600	1/95	46
10,000	0.193	750.00	29.530	1/76	52
15,000	0.290	745.00	29.330	1/50	63
20,000	0.387	740.00	29.130	1/38	72
30,000	0.580	730.00	28.740	1/25	84
50,000	0.967	710.00	27.950	1/15	101
100,000	1.930	660.00	25.980	2/15	125
200,000	3.870	560.00	22.050	1/4	152
500,000	9.670	260.00	10.240	2/3	192
760,000	14.697	0	0	1 atmosphere	212

Charging the System

RCS units are leak tested at the factory and shipped with a nitrogen holding charge. If the holding charge has been lost due to shipping damage, charge the system with enough refrigerant to raise the unit pressure to 30 psig after first repairing the leaks and evacuating the system.

- 1 After all refrigerant piping is complete and the system is evacuated, it can be charged as described in the paragraphs following. Connect the refrigerant drum to the gauge port on the liquid shutoff valve and purge the charging line between the refrigerant cylinder and the valve. Then open the valve to the mid position.
- 2 If the system is under a vacuum, stand the refrigerant drum with the connection up, open the drum, and break the vacuum with refrigerant gas.
- 3 With a system gas pressure higher than the equivalent of a freezing temperature, invert the charging cylinder and elevate the drum above the condenser. With the drum in this position and the valves open, liquid refrigerant flows into the condenser. Approximately 75% of the total requirement estimated for the unit can be charged in this manner.

- 4 Refrigerant charging with Zeotropes—R-407C is a zeotropic mixture (see “Refrigerant Leaks” on page 115). During initial charging or “topping” off a system, it is important to remove the refrigerant from the charging cylinder in the liquid phase. Many of the cylinders for the newer refrigerants use a dip tube so that in the upright position liquid is drawn from the cylinder. DO NOT vapor charge out of a cylinder unless the entire cylinder is to be charged into the system. Refer to charging instructions provided by the refrigerant manufacturer.
- 5 After 75% of the required charge enters the condenser, reconnect the refrigerant drum and charging line to the suction side of the system. Again, purge the connecting line, stand the drum with the connection side up, and place the service valve in the open position.

Note: Stamp the total operating charge per circuit on the unit nameplate for future reference.

CAUTION

Adding refrigerant to the suction always risks liquid-related damage to the compressor.

Take special care to add refrigerant slowly enough to the suction to prevent damage. Adjust the charging tank hand valve so liquid leaves the tank but vapor enters the compressor.

This is especially true with R-407C because the charge must be drawn from the liquid portion of the tank.

⚠ CAUTION

Units purchased for R-22 operation must be charged only with R-22. Units purchased for R-407C operation must be charged only with R-407C.
Field mixing or changing of refrigerants can compromise performance and damage equipment.

Table 17: Acceptable Refrigerant Oils

Polyolester [POE] oils
Note: Do not use mineral oils
Copeland ULtra 22 CC
Mobil EAL™ Arctic 22 CC
ICI EMKARATE RL™ 32CL

Refrigerant Charge

Each unit is designed for use with R-22 or R-407C. The total charge per circuit is the sum of the following four values:

- Condenser section charge, see Table 11 on page 44.
- Evaporator coil charge, see Table 11 on page 44.
- Charge for length of unit piping to the evaporator coil, see Table 11 on page 44.
- Charge for length of interconnecting piping between the RCS and RFS units, installed by field, see Table 15 on page 45.

The exact charge for a one piece RPS/RDT is on the unit nameplate.

Note: The total operating charge per circuit should not exceed the pumpdown capacity per circuit shown in Tables 11 to 15 on pages 44 to 45.

Subcooling

When field charging the unit, use the following to properly charge the unit:

- All compressors on each circuit operating at full capacity.
- Allowable subcooling ranges are between 13°F to 20°F.
- Be sure to measure pressure and temperature at the same location when finding/calculating subcooling. Compare the actual temperature and pressures to the saturated liquid temperature. R-407C example: A pressure of 250 psi is measured at the condenser outlet. From the R-407C chart, 250 psig is approximately 108°F saturated liquid temperature. If the actual refrigerant temperature is 98°F, the liquid is subcooled 10°F.
- Ambient temperature must be between 60°F and 105°F.
- Hot Gas Bypass NOT operating (only if unit is supplied with option).
- SpeedTrol motors operating at 100% (only if unit is supplied with option).

If any one of the above items is not followed, subcooling readings will not be accurate and the potential exists for over or undercharging of the refrigerant circuit.

Refrigeration Service Valves

The unit is shipped with all refrigeration service valves closed. RDT, RPS and RCS units have the following:

Sizes 15 to 105—One discharge valve is provided per refrigerant circuit, located between the compressors and condenser.

Sizes 115 to 135—One service valve is provided on the discharge and suction of each compressor.

All Units—One liquid valve is provided per refrigeration circuit, located at end of condensing section opposite condenser control box.

RFS units do not ship with service valves installed. Before attempting to start the compressors, all refrigeration service valves should be fully opened and backseated.

Unit Piping

Condensate Drain Connection

- The unit is provided with a 1.5" male NPT condensate drain connection. Refer to certified drawings for the exact location. For proper drainage, level the unit and drain pan side to side and install a P-trap
- RPS units may have positive or negative pressure sections. Use traps in both cases with extra care given to negative pressure sections. In Figure 56, dimension "A" should be a minimum of 8" (203 mm). As a conservative measure to prevent the cabinet static pressure from blowing or drawing the water out of the trap and causing air leakage, dimension A should be two times the maximum static pressure encountered in the coil section in inches wc.
- Draining condensate directly onto the roof may be acceptable; refer to local codes. Provide a small drip pad of stone, mortar, wood, or metal to protect the roof against possible damage.
- If condensate is piped into the building drainage system, pitch the drain line away from the unit a minimum of 1/8" per foot. The drain line must penetrate the roof external to the unit. Refer to local codes for additional requirements. Sealed drain lines require venting to provide proper condensate flow.
- Where the cooling coils have intermediate condensate pans on the face of the evaporator coil, copper tubes near both ends of the coil provide drainage to the main drain pan. Check that the copper tubes are in place and open before the unit is put into operation.


Mechanical Installation

- On units with staggered cooling coils, the upper drain pan drains into the lower coil drain pan through a copper tube near the center of the drain pan. Check that this tube is open before putting the unit into operation and as a part of routine maintenance.
- Because drain pans in any air conditioning unit have some moisture in them, algae, etc. will grow. Periodically clean to prevent this buildup from plugging the drain and causing the drain pan to overflow. Clean drain pans to prevent the spread of disease. Cleaning should be performed by qualified personnel.

⚠ WARNING

Drain pans must be cleaned periodically.
Material in uncleaned drain pans can cause disease.
Cleaning should be performed by qualified personnel.

Figure 56: Condensate Drain Connection



Gas Piping

See the "Installation" section of the gas-fired furnace installation manual, Bulletin No. IM 684 or 685.

Hot Water Coil Piping

Hot water coils are provided without valves for field piping or piped with three-way valves and actuator motors.

Note: All coils have vents and drains factory installed.

Hot water coils are not normally recommended for use with entering air temperatures below 40°F (4°C). No control system can guarantee a 100% safeguard against coil freeze-up. Glycol solutions or brines are the only freeze-safe media for operation of water coils at low entering air temperature conditions.

When no factory piping or valve is included, the coil connections are 1.625" ODM copper on 800 and 802C, and 2.125" ODM copper on 047 and 077C.

With the factory piping and valve package, field piping connections are the same NPT size as the valve with female threading (see Figure 58 on page 48).

Refer to the certified drawings for the recommended piping entrance locations. Seal all piping penetrations to prevent air and water leakage.

Note: Factory-installed water valves and piping are bronze, brass, and copper. Dissimilar metals within the plumbing system can cause galvanic corrosion. To avoid corrosion, provide proper di-electric fittings as well as appropriate water treatment.

Figure 57: Hot Water Heat Section (Shown With Factory Valve and Piping)





Figure 58: Hot Water Valve Package



⚠ CAUTION

Coil freeze possible. Can damage equipment.
Follow instructions for mixing antifreeze solution used. Some products have higher freezing points in their natural state than when mixed with water. The freezing of coils is not the responsibility of McQuay International. Refer to "Winterizing Water Coils" on page 116.

Steam Coil Piping

Steam coils are provided without valves for field piping, or piped with two-way valves and actuator motors.


The steam heat coil is pitched at 1/8" (3 mm) per foot (305 mm) to provide positive condensate removal. When no factory piping or valve is included, the coil connections are 2.5" male NPT iron pipe.

With the factory piping and valve package, the field supply connection is the same NPT size as the valve with female threading (see Figure 60 on page 50).

Refer to the certified drawings for the recommended piping entrance locations. All piping penetrations must be sealed to prevent air and water leakage.

Note: The valve actuator spring returns to a stem up position upon power failure. This allows full flow through the coil.

Figure 59: Steam Heat Section (Shown With Factory Valve and Piping)



Steam Piping Recommendations

- 1 Be certain that adequate piping flexibility is provided. Stresses resulting from expansion of closely coupled piping and coil arrangement can cause serious damage.
- 2 Do not reduce pipe size at the coil return connection. Carry return connection size through the dirt pocket, making the reduction at the branch leading to the trap.
- 3 Install vacuum breakers on all applications to prevent retaining condensate in the coil. Generally, the vacuum breaker is to be connected between the coil inlet and the return main. However, if the system has a flooded return main, the vacuum breaker to the atmosphere; the trap design should allow venting of the large quantities of air.
- 4 Do not drain steam mains or takeoffs through coils. Drain mains ahead of coils through a steam trap to the return line.
- 5 Do not attempt to lift condensate.
- 6 Pitch all supply and return steam piping down a minimum of 1" (25 mm) per 10 feet (3 m) of direction of flow.

Mechanical Installation

Steam Trap Recommendations

- 1 Size traps in accordance with manufacturers' recommendations. Be certain that the required pressure differential will always be available. Do not undersize.
- 2 Float and thermostatic or bucket traps are recommended for low pressure steam. Use bucket traps on systems with on-off control only.
- 3 Locate traps at least 12" (305 mm) below the coil return connection.
- 4 Always install strainers as close as possible to the inlet side of the trap.
- 5 A single tap may generally be used for coils piped in parallel, but an individual trap for each coil is preferred.

Steam Coil Freeze Conditions


If the air entering the steam coil is below 35°F (2°C), note the following recommendations:

- 1 Supply 5 psi (34.5 kPa) steam to coils at all times.
- 2 Modulating valves are not recommended. Control should be by means of face and bypass dampers.
- 3 As additional protection against freeze-up, install the tap sufficiently far below the coil to provide an adequate

hydrostatic head to ensure removal of condensate during an interruption on the steam pressure. Estimate 3 ft. (914 mm) for each 1 psi (7 kPa) of trap differential required.

- 4 If the unit is to be operated in environments with possible freezing temperatures, an optional freeze-stat is recommended. See "Freeze Protection" on page 88 for additional information.

Figure 60: Steam Valve Package



Damper Assemblies


The optional damper assemblies described in this section normally are ordered with factory-installed actuators and linkages. The following sections describe operation and linkage adjustment of the factory installed option.

Economizer Dampers

Outside air intake is provided on both sides of the unit, and the return air path is at the center of the damper set. As the single actuator modulates the outside air dampers open, the return air dampers close. Exhaust air exits the unit through the gravity relief dampers provided at the end of the economizer section.

The damper is set so that the crankarm moves through a 90-degree angle to bring the economizer dampers from full open to full close (see Figure 61). Access to the actuator and linkage is from the filler section. Mechanical stops are placed in the crankarm mounting bracket. Do not remove stops. Driving the crankarm past the stops results in damage to the linkage or damper. The unit ships with a shipping bolt securing the linkage crankarm. Remove shipping bolt before use.

Figure 61: Damper Adjustment



Note: For good airflow control, adjust linkages so damper blades do not open beyond 70 degrees. Opening a damper blade beyond 70 degrees has little effect on its airflow. Do not “over close” low leak damper blades. The edge seal should just lightly contact the adjoining blade. The blades will lock up if they are closed so far the seal goes over center.

Mechanical Installation

Intake Hood Damper (0% to 100% outside air)

Units requiring 100% outside air are provided with a rain hood and dampers that can be controlled by a single actuator. The actuator provides two-position control for opening the dampers fully during unit operation and closing the dampers during the off cycle. No unit mounted exhaust dampers are provided.

Intake Hood Damper (0% to 30% outside air)

These dampers are intended to remain at a fixed position during unit operation, providing fresh air quantities from 0 to 30% of the total system airflow, depending on the damper setting. This setting is made at the linkage rod on units with manually adjustable linkages.

On units provided with MicroTech III controls, the damper position may be set at the controller keypad. During unit operation, the two-position actuator drives the damper to the position set on the keypad. During the off cycle, the damper is automatically closed.

No unit-mounted exhaust dampers are provided with this option.

Figure 62: Damper Linkage Bar Typical For All Sizes (Sizes 015C to 040C Shown)





Figure 63: Intake Hood Damper Adjustment



Cabinet Weather Protection

This unit ships from the factory with fully gasketed access doors and cabinet caulking to provide weather resistant operation. After the unit is set in place, inspect all door gaskets for shipping damage and replace if necessary.

Protect the unit from overhead runoff from overhangs or other such structures.

Recaulk field-assembled options such as external piping or vestibules per the installation instructions provided with the option.

CAUTION

Transportation, rigging, or maintenance can damage the unit's weather seal. Periodically inspect the unit for leakage. Standing moisture can promote microbial growth, disease, or damage to the equipment and building.

Installing Ductwork

On bottom-supply/bottom-return units, if a McQuay roof curb is not used, the installing contractor should make an airtight connection by attaching field-fabricated duct collars to the bottom surface of either the roof curb's duct flange or the unit's duct opening. Do not support the total weight of the duct work from the unit or these duct flanges. See Figure 64.

Units with optional back return, side discharge, or end discharge (on RFS units), all have duct collars provided. To expose the discharge duct collars on a side discharge unit, remove the plenum section access door and the door gasketing.

Use flexible connections between the unit and ductwork to avoid transmission of vibration from the unit to the structure.

To minimize losses and sound transmission, design duct work per ASHRAE and SMACNA recommendations.

Where return air ducts are not required, connect a sound-absorbing T or L section to the unit return to reduce noise transmission to the occupied space.

WARNING


Mold can cause personal injury. Materials such as gypsum wall board can promote mold growth when damp. Such materials must be protected from moisture that can enter units during maintenance or normal operation.

Ductwork exposed to outdoor conditions must be built in accordance with ASHRAE and SMACNA recommendations and local building codes.

NOTICE

Installer must provide access in the ductwork for plenum-mounted controls. Once duct work is installed in units with side discharge, access to plenum-mounted components is difficult.

Figure 64: Installing Duct Work



Mechanical Installation

Installing Duct Static Pressure Sensor Taps

For all VAV units, field install and connect duct static pressure taps to the pressure sensors in the unit. Sensor SPS1 is standard; additional sensor SPS2 is optional. These sensors are located in the main control panel (see “Control Panel” on page 11).

Carefully locate and install the duct static pressure sensing tap. Improperly locating or installing the sensing tap causes unsatisfactory operation of the entire variable air volume system. Below are pressure tap location and installation recommendations. The installation must comply with local code requirements

- 1 Install a tee fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
- 2 Use different colored tubing for the duct pressure (HI) and reference pressure (LO) taps, or tag the tubes. McQuay recommends 1/4" plastic tubing.
- 3 Locate the duct pressure (HI) tap near the end of a long duct to ensure that all terminal box take-offs along the run have adequate static pressure.
- 4 Locate the duct tap in a nonturbulent flow area of the duct. Keep it several duct diameters away from take-off points, bends, neckdowns, attenuators, vanes, or other irregularities.
- 5 Use a static pressure tip (Dwyer A302 or equivalent) or the bare end of the plastic tubing for the duct tap. (If the duct is lined inside, use a static pressure tip device.)
- 6 Install the duct tap so that it senses only static pressure (not velocity pressure). If a bare tube end is used, it must be smooth, square (not cut at an angle) and perpendicular to the airstream (see Figure 66).
- 7 Locate the reference pressure (LO) tap somewhere near the duct pressure tap within the building (see Figure 65). If the reference tap is not connected to the sensor, unsatisfactory operation will result.
- 8 Route the tubes between the curb and the supply duct, and feed them into the unit through the knockout in the bottom of the control panel (see Figure 65). Connect the tubes to appropriate barbed fittings in the control panel. (Fittings are sized to accept 1/4" plastic tubing.)

Figure 65: Static Pressure Tubing Entrance Location





Figure 66: Pressure Sensing Tubing Installation



Installing Building Static Pressure Sensor Taps

If a unit has direct building static pressure control capability, you must field install and connect static pressure taps to pressure sensor SPS2 in the unit. This sensor is located at the bottom of the main control panel next to terminal block TB2.

Locate and install the two static pressure sensing taps. Improper location or installation of the sensor taps causes unsatisfactory operation. Below are pressure tap location and installation recommendations for both building envelope and lab, or “space within a space” pressure control applications. The installation must comply with local code requirements.



CAUTION

Fragile sensor fittings.

If you must remove tubing from a pressure sensor fitting, use care. Do not use excessive force or wrench the tubing back and forth to remove; the fitting can break off and damage sensor.

Building Pressurization Applications

- 1 Install a tee fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
- 2 Locate the building pressure (HI) tap in the area that requires the closest control. Typically, this is a ground level floor that has doors to the outside.
- 3 Locate the building tap so it is not influenced by any source of moving air (velocity pressure). These sources may include air diffusers or outside doors.
- 4 Route the building tap tube between the curb and the supply duct and feed it into the unit through the knockout in the bottom of the control panel (see Figure 65). Connect the tube to the 1/4-inch HI fitting for sensor SPS2.
- 5 Locate the reference pressure (LO) tap on the roof. Keep it away from the condenser fans, walls, or anything else that may cause air turbulence. Mount it high enough above the roof so it is not affected by snow. Not connecting the

reference tap to the sensor results in unsatisfactory operation.

- 6 Use an outdoor static pressure tip (Dwyer A306 or equivalent) to minimize the effects of wind. Place a screen over the sensor to keep out insects. Loosely packed cotton works well.
- 7 Route the outdoor tap tube out of the main control panel through a small field-cut opening in the edge of the control wiring raceway cover (see Figure 65 on page 54). Cut this “mouse hole” in the vertical portion of the edge. Seal the penetration to prevent water from entering. Connect tube to the 1/4-inch LO fitting for sensor SPS2.

Lab Pressurization Applications

- 1 Install a “T” fitting with a leak-tight removable cap in each tube near the sensor fitting. This facilitates connecting a manometer or pressure gauge if testing is required.
- 2 Use different colored tubing for the controlled space pressure (HI) and reference pressure (LO) taps, or tag the tubes.
- 3 Regardless whether the controlled space is positive or negative with respect to its reference, locate the HI pressure tap in the controlled space (setpoint can be set between -0.2 and 0.2 ” wc).
- 4 Locate the reference pressure (LO) tap in the area surrounding the controlled space. Not locating the reference tap to the sensor results in unsatisfactory operation.
- 5 Locate both taps so they are not influenced by any source of moving air (velocity pressure). These sources may include air diffusers or doors between the high and low pressure areas.
- 6 Route the building tap tube between the curb and the supply duct and feed it into the unit through the knockout in the bottom of the control panel (see Figure 65).
- 7 Connect the tube to the 1/4-inch HI fitting for sensor SPS2.

Electrical Installation

Field Power Wiring

Wiring must comply with all applicable codes and ordinances. The warranty is voided if wiring is not in accordance with these specifications. An open fuse, tripped circuit breaker, or Manual Motor Protector (MMP) indicates a short, ground, or overload. Before replacing a fuse, circuit breaker, MMP, or restarting a compressor or fan motor, identify the trouble and correct.

According to the National Electrical Code, a disconnecting means shall be located within sight of and readily accessible from the air conditioning equipment. The unit can be ordered with an optional factory mounted disconnect switch. This switch is not fused. Power leads must be over-current protected at the point of distribution. The maximum allowable overcurrent protection (MROPD) appears on the unit nameplate.

All RPS, RFS, and RDT

All units are provided with internal power wiring for single or dual point power connection. The power block or an optional disconnect switch is located within the main control panel. Field power leads are brought into the unit through 3" knockouts in the bottom of the main control panel. Refer to the unit nameplate to determine the number of power connections. See Figure 67 and Table 19 on page 58.

WARNING

Hazardous voltage. Can cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

If the unit has a factory mounted disconnect switch, generally the switch must be turned off to open the main control panel door. However, the door can be opened without disconnecting power by following the procedure covered on page 117. If this is done, use caution since power is not removed from the unit or the controller.

Note: To wire entry points, refer to certified drawings for dimensions.

Figure 67: RPS/RDT and RFS Power Wiring Connections





Figure 68: Optional Side Power Wiring Entrance



- The preferred entrance for power cables is through the bottom knockouts provided on the unit. If side entrance is the only option, a drilling location is provided.

CAUTION


Wires are located in base rail. Move wires before drilling hole through base rail.

Follow the drilling dimensions exactly to prevent damage to the control panel. The dimensions provided are the only possible point of side entrance for the power cables.

RCS Units

Field power wiring is connected from the main control panel in the RFS unit to power block (PB4) or an optional disconnect switch (DS4) located in the condenser control panel of the RCS unit. Power leads enter the bottom left corner of the condenser control panel through the conduit hubs shipped with the unit. Refer to Figure 70 and Figure 71 on page 58.

Figure 69: Typical Power Wire Entrance, Unit View—RPS 015C - 040C Shown (Actual Opening, see Submittal Documents)



All Units

The minimum circuit ampacity (wire sizing amps) is shown on the unit nameplate. Refer to Table 19 on page 58 for the recommended number of power wires.

Copper wire is required for all conductors. Size wires in accordance with the ampacity tables in Article 310 of the National Electrical Code. If long wires are required, it may be necessary to increase the wire size to prevent excessive voltage drop. Size wires for a maximum of 3% voltage drop. Supply voltage must not vary by more than 10% of nameplate. Phase voltage imbalance must not exceed 2%. (Calculate the average

voltage of the three legs. The leg with voltage deviating the farthest from the average value must not be more than 2% away.) Contact the local power company for correction of improper voltage or phase imbalance.

CAUTION

Provide proper line voltage and phase balance. Improper line voltage or excessive phase imbalance constitutes product abuse. It can cause severe damage to the unit's electrical components.

Electrical Installation

A ground lug is provided in the control panel for each disconnect or power block. Size grounding conductor in accordance with Table 250-95 of the National Electrical Code.

In compliance with the National Electrical Code, an electrically isolated 115V circuit is provided in the unit to supply the factory mounted service receptacle outlet and optional unit lights. This circuit is powered by a field connected 15A, 115V power supply. Leads are brought into the RFS and RPS units through a 7/8" knockout in the bottom of the main control panel, near the power wire entry point.

Figure 70: RCS 015C - 030C Power Wiring Connections




Figure 71: RCS 036C and 105C Power Wiring Connections (Number of Condenser Fans Varies Per Unit Size)




Table 18: Multiple Point Power Connection Options

Number of electrical circuits	Disconnect designation	Load	Location (see Figure 3 on page 4)
2	DS2	Supply and return fan motors plus controls	Main control panel
	DS1	Balance of unit	Main control panel
2	DS3	Electric heat	Electric heat control panel
	DS1	Balance of unit	Main control panel
3	DS3	Electric heat	Electric heat control panel
	DS2	Supply and return fan motors plus controls	Main control panel
	DS1	Balance of unit	Main control panel

Table 19: Recommended 3-Phase Power Wiring to Ensure Disconnects and Power Blocks Mate With Power Wiring

Wire gauge	Qty./ pole	Insulation rating (°C)	No. of conduits	Conduit (trade size, in.)	For MCA up to (amps)
10	1	75	1	1/2	35
8	1	75	1	3/4	50
6	1	75	1	1	65
4	1	75	1	1 1/4	85
3	1	75	1	1 1/4	100
2	1	75	1	1 1/4	115
1	1	75	1	1 1/4	130
1/0	1	75	1	1 1/2	150
2/0	1	75	1	2	175
3/0	1	75	1	2	200
4/0	1	75	1	2	230
250	1	75	1	2 1/2	255
300	1	75	1	2 1/2	285
350	1	75	1	3	310
400	1	75	1	3	335
500	1	75	1	3	380
3/0	2	75	2	2	400
4/0	2	75	2	2	460
250	2	75	2	2 1/2	510
300	2	75	2	2 1/2	570
350	2	75	2	3	620
400	2	75	2	3	670
500	2	75	2	3	760
250	3	75	3	2 1/2	765
300	3	75	3	2 1/2	855
350	3	75	3	3	930

1. All wire sizes assume separate conduit for each set of parallel conductors.
2. All wire sizes based on NEC Table 310-16 for 75°C THW wire (copper). Canadian electrical code wire ampacities may vary.
3. All wire sizes assume no voltage drop for short power leads.

Field Control Wiring


Roof Pak applied rooftop units are available with several control arrangements which may require low voltage field wiring. Detailed descriptions of various field control wiring options and requirements are included in the “Field Wiring” section of Bulletin No. IM 919, “MicroTech III Applied Rooftop Unit Controller.” Refer to the unit wiring diagrams for additional installation information.

Wiring must comply with applicable codes and ordinances. The warranty is voided if wiring is not in accordance with these specifications.

RPS, RDT, and RFS Units

All field control wiring connections are made at the class II terminal block TB2, which is located in the main control panel. Field wiring connections to the 115-volt receptacle and lights are made at terminal block TB7, which is also located in the main control panel. Refer to Figure 72 and “Control Panel” on page 11. Two 7/8" knockouts are provided for wire entry.

Figure 72: RDT, RFS, RPS Field Control Wiring Connections




RFS/RCS Units

The RCS unit receives 115-volt and 240-volt control circuit power and a number of control signals from the RFS unit. Two 7/8" knockouts are provided in the right side of the RCS control box.

Interconnecting wiring enters the RFS unit through 7/8" knockouts in the bottom of the main control panel. The interconnecting wiring is connected to TB4 in the RFS unit and TB5 in the RCS unit. Refer to Figure 73. A 7/8" knockout is also available in the end of the unit base as shown in Figure 72.

Note: If a single conduit containing 24V and 115V wiring is run above the roof line between the RFS and RCS, install the 24V wiring as a NEC Class I wiring system.

Figure 73: RFS and RCS Interconnecting Control Wiring



WARNING


Electrical shock hazard. Can cause severe injury or death. Connect only low voltage NEC Class II circuits to terminal block TB5. Reinstall and secure all protective deadfront panels when the wiring installation is complete.

Preparing Unit for Operation

⚠ WARNING

Moving machinery hazard. Can cause severe injury or death. Before servicing equipment, disconnect power and lock off. More than one disconnect may be required to de-energize unit.

Figure 74: RDT Spring Mount Hold-Down Fasteners



Spring Isolated Fans

Releasing Spring Mounts

The optional spring-mounted supply and return fans are locked down for shipment. Hold-down fasteners are located at each spring mount. Remove these fasteners before operating the fans. Figure 77 shows a typical spring mount. Note that the 3/8" hold-down bolt securing the fan base to the unit cross channel must be removed.

After removing the hold-down fasteners, rock the fan assembly by hand to check for freedom of movement.

Figure 75: Spring Mounted Hold-Down Fasteners, All Units






Figure 76: Fan Spring Mount Adjustment



* Grossly out-of-adjustment thrust restraints can affect this dimension. Recheck after thrust restraints are adjusted.

Adjusting Spring Mounts

Figure 77: Spring Mount



To adjust spring mount compression, perform the following:

- 1 Loosen the .625-18 UNF hex nut.
- 2 Place additional weight on the fan sled frame and use a lever to slightly compress the spring or raise the sled. This will allow the bolt to turn freely.
- 3 Place one or two drops of oil on the threads if needed.

Note: The greatest friction that makes adjustment difficult, comes from the surfaces of the top of the upper-rebound plate, both sides of the .615" washer, and the underside of the sled. If friction is occurring at these point, relieve the weight and oil the friction surfaces.

- 4 Use a flat blade socket drive bit (1/2" drive handle recommended) and make sure that when adjusting the slotted bolt, that the upper-rebound plate also turns. This action allows the bolt to push the compression plate up or down with the least friction occurring between the .625" washer and the underside of the channel.

Note: If the spring compresses to far, lift the sled before turning. If the spring does not compress enough, place weight on the sled corner, forcing it down before turning.

- 5 Re-adjust the position of the lower-rebound plate so that the sled has at least 3/4" travel and not more than 1.25" of travel.

CAUTION

Do not use impact tools for field spring mount adjustments as damage to bits or to the bolt slot may occur.

WARNING

Moving machinery hazard. Can cause severe injury or death. Start the fans for the first time according to the "Check, Test, and Start Procedures" on page 98. If this is not done, equipment damage, severe personal injury, or death can occur.


Relief Damper Tie-Down

Economizer sections with a 30" or 40" return fan have a relief damper that is tied down for shipping. Remove the two brackets and two screws before operation to allow free movement of dampers. Access is from inside the economizer section.

Adjusting Scroll Dampers

Two sets of scroll dampers are provided in the housing of the twin 15" x 6" supply fan to allow control of air volume to each fan wheel. At the factory, these dampers are fully closed, unrestricting airflow. If fan paralleling occurs, correct it by loosening the adjustment screw on top of the fan housing (see Figure 78) and slightly lowering the rod until air distribution between the fans is even.


Figure 78: Scroll Damper Adjustment



Adjusting Supply Fan Thrust Restraints

Thrust restraints are provided when housed double-width fans are mounted on springs. After the spring mounts are adjusted for level operation when the fan is running, check the thrust restraints. With the fan off, set the adjustment nuts so the spring is slightly compressed against the angle bolted to the fan housing frame. Refer to Figure 79. When the fan is turned on, the fan moves back to a level position and the thrust restraint spring compresses.

Figure 79: Thrust Restraint Adjustment



Thrust restraint adjustment (with fan off)

1. Loosen jam nuts A.
2. Turn nut C until spring cup and washer contact thrust restraint angle.
3. Turn nut B until spring is compressed by two turns of nut B.
4. Tighten jam nuts A.

Sequences of Operation

The following sequences of operation are for a typical “C” vintage applied rooftop unit equipped with MicroTech III, an economizer, 4-compressor/4-stage cooling, 3 to 1 turn down burner, variable frequency drives (VFD), a return air fan and an external time clock. These sequences describe the ladder wiring diagram logic in detail; refer to “Wiring Diagrams” on page 67 as you read them. Note that your unit’s sequences of operation may vary from those described here. Refer to the wiring diagrams supplied with the unit for exact information.

For detailed description of operation information relating to the MicroTech III controller's software, refer to the appropriate operation manual (see Table 1 on page 3). These manuals describe the various setpoints, parameters, operating states, and control algorithms that affect rooftop unit operation.

Power-up

When primary power is connected to the unit, 115 V (ac) power is fed through control circuit transformer T1 and control circuit fuse F1C (line 166, Figure 84 on page 71) to compressor crankcase heaters HTR-1, HTR-2, HTR-3 and HTR-4 (lines 836 - 848, Figure 94 on page 81).

When system switch S1 (line 203, Figure 89 on page 76) is closed, low voltage transformers T2 (line 203, Figure 89 on page 76), T3 (line 251, Figure 90 on page 77) and T9 (line 802, not shown) energize, and 115 V (ac) power is supplied to the following:

- The supply fan VFD (line 135-137, Figure 84 on page 71)
- M40A to energize the return fan VFD (line 147-149, Figure 84 on page 71)
- Heating control panel (line 603, Figure 91 on page 78)
- Economizer actuator (lines 256-257)

Transformer T2 supplies 24 V (ac) power to terminals 24V and COM on the main control board MCB (lines 207 and 208). Transformer T2 supplies 24 V (ac) power to the following (see Figure 83 on page 70 and Figure 84 on page 71):

- Switch S7 On-Auto-Off (line 217)
- Enthalpy sensor OAE (line 247)
- External time clock contacts (line 215)
- Airflow interlock switch PC7 (line 228)
- Dirty filter switches PC5 and PC6 (lines 242 and 247, not shown)
- Gas furnace alarm relay R24 (line 225, not shown)
- Freezestat switch FS1 (line 244, hot water or steam heat only, not shown)

- Smoke detectors SD1 and SD2 (line 237)

The time clock, S7 switch, and emergency shutdown terminals (lines 217-222) control fan operation.

Note: Unit ships with factory installed jumpers between TB2 101 and 105 and between 101 and 106.

Fan Operation

When the main control board (MCB) commands the supply and return fans to start, the unit enters the Startup operating state. As a result, a 3-minute timer is set, output MCB-BO3 (line 307) energizes, and relay R26 energizes (line 306, not shown).

After the 3-minute timer expires, the unit enters the Recirc operating state. As a result, output MCB-BO1 energizes relay R67 (line 401). This gives a start signal to supply fan drive AFD10 (line 445). Four seconds after MCB-BO1 is energized, output MCB-BO2 energizes relay R68 (line 404). This gives a start signal to return fan drive AFD20 (line 445).

Within 120 seconds after the fans start, the controller expects airflow switch PC7 (line 228) to close and thus energize binary input MCB-BI6. (If MCB-BI6 does not energize, the controller assumes the fans did not start. It then shuts down the unit and generates an alarm.)

During the Recirc operating state, the outside air damper is held closed. The controller does this by energizing output MCB-BO5 (line 318). On VAV units, output MCB-BO12, the VAV box output, is also de-energized (line 309) during the Recirc state.

The supply fan adjustable frequency drive (AFD10) is modulated to maintain the duct static pressure setpoint. When energized, output MCB-BO14 (line 407) drives AFD10 toward increased capacity; MCB-BO13 (line 405) drives it toward decreased capacity. On VAV units or CAV units equipped with return fan capacity control, the adjustable frequency drive (AFD20) is modulated to maintain an acceptable building static pressure (using either VaneTrol logic or direct measurement of building pressure; see the appropriate OM for more information). When energized, output MCB-BO16 (line 409) drives AFD20 toward increased capacity; MCB-BO15 (line 411) drives them toward decreased capacity.

Note: If the inverter bypass switch S4 (lines 426 and 430) is in the bypass position, MMP30 and MMP40 (line 132 and 144) protect the fans from excessive current draw. If either the supply or return fan is drawing excessive current, one of the MMPs triggers an auxiliary contacts (line 426) and open the circuit, causing both fans to stop.

Economizer Operation

Refer to Figure 90 on page 77. When the outdoor air is suitable for free cooling, the switch in enthalpy sensor OAE is in position “3” (line 248, Figure 90 on page 77) energizing analog input AIX5. When AIX5 energizes, the economizer is enabled. (Note: If selected from the keypad, the enthalpy decision can be made based on outdoor temperature. In that condition, if the outdoor air temperature is less than or equal to the changeover set point, the economizer is enabled.) If cooling is required, the economizer dampers (ACT3) are modulated to maintain the discharge air temperature setpoint. Analog input AIX5 drives the outdoor air dampers toward the open and closed (line 256) position. If the outdoor air dampers are wide open and more cooling is required, the dampers hold their positions and mechanical cooling is activated (see below).

When the outdoor air is not suitable for free cooling, the switch in enthalpy sensor OAE is in position “1,” de-energizing analog input AIX5. (Alternatively, the outdoor air temperature is above the changeover setpoint plus the economizer changeover differential). When the economizer is disabled, the dampers are held at their minimum position.

Mechanical Cooling Operation

4-Compressor/4-Stage Unit

Refer to “Electric Heat Control” on page 80 and “RPS 60 Condensing Unit Control (With Scroll Compressors), Continued” on page 83 as you read this sequence of operation. In this configuration there are four equally sized compressors

and two cooling circuits. In the following description, compressor #1 is lead. However, if Auto Lead/Lag Staging is selected on the keypad, the lead compressor is the one in the lead circuit with the least number of run hours.

When the unit disconnect is closed, 115 V (ac) power is supplied directly from control transformer T1 to the compressor crankcase heaters, HTR-1, 2, 3, and 4 (lines 836 - 848, 853) and motor protectors MP1, 2, 3, and 4 (lines 836 - 848, 854). This same 115 V (ac) source also goes through:

- System switch, S1 (line 203, Figure 89 on page 76)
- The optional phase voltage monitors, PVM1 and 2 (lines 203, 802, not shown)
- The optional ground fault relays, GFR1 and 2 (lines 203, 802, not shown)

Compressors are staged by 115 V (ac) power supplied to the following:

- Frost protect FP1 to CCB1-BI8 (line 812, not shown)—
Optional when no hot gas bypass is ordered on the unit
- Frost protect FP2 to CCB2-BI8 (line 823, not shown)—
Optional when no hot gas bypass is ordered on the unit
- HP relay R1 to CCB1-BI7 (lines 812)
- HP relay R2 to CCB2-BI7 (lines 823)
- Compressor contactor status M1 to CCB1-BI9 (line 812)
- Compressor contactor status M2 to CCB2-BI9 (line 823)
- Compressor contactor status M3 to CCB1-BI10 (line 814)
- Compressor contactor status M4 to CCB2-BI10 (line 825)

Sequences of Operation

Cross Circuit Loading

See line 812, Figure 95 on page 82. During a call for cooling, if HP1 is satisfied, then DO1 closes. If MMP1 and MP1 are satisfied, then M1 compressor contactor is energized to bring on compressor 1 on refrigerant circuit 1 (line 708 - 710, Figure 87 on page 74). The M1 auxiliary brings on:

- required condenser fans (line 854)
- liquid line and optional hot gas solenoids (lines 855 and 856)

Compressor 2 (refrigerant circuit 2) is the 2nd stage of cooling and is brought on in the same manner (line 823, Figure 95 on page 82 and lines 708 - 710, Figure 87 on page 74).

Circuit 2 condenser fans and solenoids are controlled in the same manner on lines 861 - 865).

The 3rd stage of cooling is controlled by DO2 (line 814) and brings on compressor 3 if MMP3 and MP3 are satisfied.

The 4th stage of cooling is controlled by DO4 (lines 826) and brings on compressor 3 if MMP3 and MP3 are satisfied.

Lead Circuit Loading

The loading and unloading process is similar except that both compressors in the lead cooling circuit 1 energize before energizing any compressors in lag circuit 2.

Heating


Gas Furnace, Super Modulating Burner (20:1 Turndown)

Refer to “HTD Gas Burner Schematic” on page 78 for a sequence of operation.

Using the Keypad/Display

The keypad/display consists of a 5-line by 22 character display, three keys and a “push and roll” navigation wheel. There is an Alarm Button, Menu (Home) Button, and a Back Button. The wheel is used to navigate between lines on a screen (page) and to increase and decrease changeable values when editing. Pushing the wheel acts as an Enter Button.

Figure 80: Keypad Controls



The first line on each page includes the page title and the line number to which the cursor is currently “pointing”. The line numbers are X/Y to indicate line number X of a total of Y lines for that page. The left most position of the title line includes an “up” arrow to indicate there are pages “above” the currently displayed items, a “down” arrow to indicate there are pages “below” the currently displayed items or an “up/down” arrow to indicate there are pages “above and below” the currently displayed page.

Each line on a page can contain status only information or include changeable data fields. When a line contains status only information and the cursor is on that line all but the value field of that line is highlighted meaning the text is white with a black box around it. When the line contains a changeable value and the cursor is at that line, the entire line is highlighted. Each line on a page may also be defined as a “jump” line, meaning pushing the navigation wheel will cause a “jump” to a new page. An arrow is displayed to the far right of the line to indicate it is a “jump” line and the entire line is highlighted when the cursor is on that line.

The keypad/display Information is organized into five main menus or menu groups; Alarm Lists Menu, System Summary Menu, Standard Menus, Extended Menus and Advance Menus.

Note – Only menus and items that are applicable to the specific unit configuration are displayed.

The Alarm Lists Menu includes active alarm and alarm log information. The System Summary Menu includes status information indicating the current operating condition of the unit. Standard Menus include basic menus and items required to setup the unit for general operation. These include such things are control mode, occupancy mode and heating and cooling setpoints. Extended Menus include more advanced items for “tuning” unit operation such as PI loop parameters and time delays. Advanced Menus include the most advanced items such as “unit configuration” parameters and service related parameters. These generally do not needing changing


or accessing unless there is a fundamental change to or a problem with the unit operation.

Passwords

When the keypad/display is first accessed, the Home Key is pressed, the Back Key is pressed multiple times, or if the keypad/display has been idle for the Password Timeout timer (default 10 minutes), the display will show a “main” page where the user can enter a password or continue without entering a password. The three password levels available are Level 2, Level 4, and Level 6, with Level 2 having the highest level of access. Entering the Level 6 password allows access to the Alarm Lists Menu, System Summary Menu, and the Standard Menus group. Entering the Level 4 password allows similar access to Level 6 with the addition of the Extended Menus group. Entering the Level 2 password allows similar access to Level 4 with the addition of the Advanced Menus group. The Level 2 password is 6363, the Level 4 is 2526, and the Level 6 password is 5321. Continuing without entering one of these three levels allows access only to the Alarm Lists Menu and the System Summary Menu.

Note – Alarms can be acknowledged without entering a password.


Figure 81: Password Main Page



The password field initially has a value **** where each * represents an adjustable field. These values can be changed by entering the Edit Mode described below.

MicroTech III Controller Operation

Figure 82: Password Entry Page



Entering an invalid password has the same effect as continuing without entering a password.

Once a valid password has been entered, the controller allows further changes and access without requiring the user to enter a password until either the password timer expires or a different password is entered. The default value for this password timer is 10 minutes. It is changeable from 3 to 30 minutes via the Timer Settings menu in the Extended Menus.

Navigation Mode

In the Navigation Mode, when a line on a page contains no editable fields all but the value field of that line is highlighted meaning the text is white with a black box around it. When the line contains an editable value field the entire line is inverted when the cursor is pointing to that line.

When the navigation wheel is turned clockwise, the cursor moves to the next line (down) on the page. When the wheel is

turned counter-clockwise the cursor moves to the previous line (up) on the page. The faster the wheel is turned the faster the cursor moves.

When the Back Button is pressed the display reverts back to the previously displayed page. If the Back button is repeated pressed the display continues to revert one page back along the current navigation path until the “main menu” is reached.


When the Menu (Home) Button is pressed the display reverts to the “main page.”

When the Alarm Button is depressed, the Alarm Lists menu is displayed.

Edit Mode

The Editing Mode is entered by pressing the navigation wheel while the cursor is pointing to a line containing an editable field. Once in the edit mode pressing the wheel again causes the editable field to be highlighted. Turning the wheel clockwise while the editable field is highlighted causes the value to be increased. Turning the wheel counter-clockwise while the editable field is highlighted causes the value to be decreased. The faster the wheel is turned the faster the value is increased or decreased. Pressing the wheel again cause the new value to be saved and the keypad/display to leave the edit mode and return to the navigation mode.

Legend



ID	Description	Standard location
ACT3, 4	Actuator motor, economizer	Economizer section
ACT5	Actuator motor, discharge isolation damper	Discharge section
ACT6	Actuator motor, return air isolation damper	Return section
ACT7	Actuator motor, heat face/ bypass	Coil section, heat
ACT8	Actuator motor, cool face/ Bypass	Coil section, cool
ACT10, 11	Actuator motor, exhaust dampers	Return section
ACT12	Actuator motor, enthalpy wheel bypass damper	Energy recovery section
AFD10	Adjustable frequency drive, supply fan	AFD/supply fan section
AFD11	Adjustable frequency drive, evap cond. fans	Main/RCE control box
AFD20	Adjustable frequency drive, return/exhaust fan	AFD/ret. ex. fan section
AFD60	Adjust. freq. drive, energy recovery wheel(s)	Energy recovery section
AS	Airflow switch, burner blower	Gas heat box
BM	Burner blower motor	Heat section, gas
C1-8	Power factor capacitors, compressors	Condenser section
C10	Power factor capacitors, supply fan	Supply Fan section

ID	Description	Standard location
C11	Capacitors, Speedtrol, circuit #1	Condenser bulkhead
C20	Power factor capacitors, return fan	Return section
C21	Capacitors, Speedtrol, circuit #2	Condenser bulkhead
CB10	Circuit breaker, supply fan	Main control box
CB11	Circuit breaker, evaporative condenser fan(s)	Main/cond. control box
CB20	Circuit breaker, return/ exhaust fan	Main control box
CB60	Circuit breaker, energy recovery wheel	Main control box
CCB1, 2	Compressor control boards, refrig. circuits	Main control box
CPC	Circuit board, main, micro controller	Main control box
CPR	Circuit board, expansion, micro controller	Main control box
CS1, 2	Control switches, refrig. circuits	Main/cond. control box
DAT	Discharge air temperature sensor	Discharge section
DFLH	Design flow lefthand sensor	Return section
DFRH	Design flow righthand sensor	Return section
DHL	Duct hi-limit	Main control box
DS1	Disconnect, total unit or cond/ heat	Main control box
DS2	Disconnect, SAF/RAF/ controls	Main control box
DS3	Disconnect, electric heat	Electric heat box
DS4	Disconnect, condenser (RCS Only)	RCS control box
EAT	Exhaust air temperature sensor	Energy recovery section
EFT	Entering fan air temperature sensor	Supply fan section
EHB1	Staged electric heat board	Main control box
ERB1	Energy recovery board	Main control box
ERM1	Energy recovery wheel motor #1	Energy recovery section
ERM2	Energy recovery wheel motor #2	Energy recovery section
F1A, B	Fuse, control circuit transformer (T1), primary	Main control box
F1C	Fuse, control circuit transformer (T1), secondary	Main control box
F2	Fuse, control circuit transformer (T2), primary	Main control box
F3	Fuse, burner blower motor	Main control box
FB11, 12	Fuseblock, Speedtrol	Main/cond. control box
FB31-40	Fuseblock, electric heat (top bank)	Electric heat box
FB41-50	Fuseblock, electric heat (bot. bank)	Electric heat box
FB65	Fuseblock, evap. cond. sump heater	Main/cond. control box
FD	Flame detector	Heat section, gas
FLC	Fan limit control	Heat section, gas
FP1, 2	Frost protection, refrig. circuits	Coil section, cool
FS1, 2	Freezestat control	Coil section, heat/cool
FSG	Flame safeguard	Gas heat box

Wiring Diagrams

ID	Description	Standard location
GCB1	Generic condenser board, refig. circ.	Main control box
GFR1, 2	Ground fault relay	Main control box
GFS1, 2	Ground fault sensor	Main control box
GFR4	Ground fault relay, condenser	Condenser control box
GFS4	Ground fault sensor, condenser	Condenser control box
GRD	Ground	All control boxes
GV1	Gas valve, pilot	Heat section, gas
GV2	Gas valve, main/safety	Heat section, gas
GV3	Gas valve, redundant/safety	Heat section, gas
GV4-8	Gas valve, main, hi turn down	Heat section, gas
HL1-10	Hi-limits, pwr, elec heaters (top bank)	Heat section, electric
HL11-20	Hi-limits, pwr, elec heaters (bot. bank)	Heat section, electric
HL22	Hi-limits, gas heat (pre-filters)	Supply fan section
HL23	Hi-limits, gas heat (final filters)	Final filter section
HL31-40	Hi-limits, ctl. elec heaters (top bank)	Heat section, electric
HL41-50	Hi-limits, ctl. elec heaters (bot. bank)	Heat section, electric
HP1-4	Hi-pressure controls, refig	On compressors
HP5	Hi-pressure controls, gas	Heat section, gas
HS1	Heat switch, electric heat shutdown	Main control box
HS3	Heat switch, electric heat deadfront interlock	Electric heat box
HTR1-6	Crankcase heaters	On compressors
HTR65	Heater, sump	Evap. condenser section
HTR66	Heater, vestibule	Evap. condenser vestibule
HUM1	Humidstat sensor	Energy recovery section
IT	Ignition transformer	Gas heat box
LAT	Leaving air temperature sensor	Energy recovery section
LP1, 2	Low-pressure controls, refrigeration	On compressors
LP5	Low-pressure control, gas	Heat section, gas
LR10	Line Reactor, supply fan	Inverter bypass box
LR20	Line reactor, return/exhaust fan	Inv. bypass/main cont. box
LS1, 2	Limit switch, low fire, high fire	Gas heat box
LT10-23	Light, cabinet sections	Supply fan section
M1-8	Contactora, compressor	Main/cond. control box
M10	Contactora, supply fan	Main control box
M11-18	Contactora, condenser fans, circuit #1	Main/cond. control box
M20	Contactora, return fan	Main control box
M21-28	Contactora, Condenser fans, circuit #2	Main/cond. control box
M29	Contactora, burner motor	Gas heat box
M30	Contactora, reversing, inverter bypass, supply fan	Inverter bypass box
M31-39	Contactora, electric heat (top bank)	Electric heat box
M40	Contactora, reversing, Inverter Bypass, Return Fan	Inverter bypass box
M41-50	Contactora, electric heat (bot. bank)	Electric heat box
M60	Contactora, energy recovery wheel	Main control box
M64	Contactora, sump pump	Main/cond. control box

ID	Description	Standard location
M65	Contactora, sump heater	Main/cond. control box
MCB	Microprocessor circuit board	Main control box
MJ	Mechanical Jumper	All control boxes
MMP1-8	Manual motor protector, compressors	Main/cond. control box
MMP10	Manual motor protector, supply fan	Main control box
MMP11-18	Manual motor protector, cond. fans, ckt#1	Main/cond. control box
MMP20	Manual motor protector, return fan	Main control box
MMP21-28	Manual motor protector, cond. fans, ckt#2	Main/cond. control box
MMP30	Manual motor protector, invtr. bypass, sup. fan	Inverter bypass box
MMP40	Manual motor protector, invtr. bypass, ret. fan	Inverter bypass box
MMP51, 52, 53	Manual motor protector, exhaust fan(s)	Prop exhaust box
MMP60	Manual motor protector, energy recovery wheel	Main control box
MMP64	Manual motor protector, sump pump	Main/RCE control box
MP1-6	Motor protector, compr.#1-6	On compressors
OAE	Outside air enthalpy sensor	Economizer section
OAT	Outside air temperature sensor	Economizer section
PB1, 2	Power block, power distribution	Main control box
PB3	Power block, power distribution, electric heat	Electric heat box
PB4	Power block, power distribution, condenser	Condenser control box
PB9, 10	Power block, supply fan	Junction box, split unit
PB11, 12	Power block, power distribution	Main control box
PB19, 20	Power block, return/exhaust fan	Junction box, split unit
PC5	Pressure control, clogged filter	Pre filter section
PC6	Pressure control, clogged final filter	Final filter section
PC7	Pressure control, proof airflow	Supply fan section
PC8	Pressure control, minimum airflow	Coil section, cool
PC12, 22	Pressure control, Fantrol	Condenser section
PM1	Phone modem	Main control box
PS1, 2	Pumpdown switches, refig circuits	Main/cond. control box
PS3	Pumpdown switch, RFS only	Main control box
PVM1, 2	Phase voltage monitor	Main control box
PVM4	Phase voltage monitor, condenser	Condenser control box
R1, 2	Relay, hi pressure reset	Main/cond. control box
R3, 4	Relay, hi pressure delay	Main/cond. control box
R5-8	Relay, safety, cool fail	Main/cond. control box
R9, 10	Relay, compressor lockout	Main/cond. control box
R11, 12	Relay, Speedtrol fan cycling	Main/cond. control box
R20	Relay, Heat, gas/ steam/ hot water	Gas heat/main cont. box
R21, 22	Relay, heat, gas (hi-turn down)	Gas heat box
R23	Relay, heat, gas & electric	Gas/electric heat box
R24	Relay, heat alarm, gas	Main control box

Wiring Diagrams

ID	Description	Standard location
R25	Relay, heat, gas, start supply fan inverter	Main control box
R26	Relay, isol/exh. dampers, open/close	Main control box
R28	Relay, isolation damper, safety	Main control box
R29	Relay, remote fire alarm	Main control box
R30	Relay, cool valve with face bypass	Main control box
R45	Relay, UV lights	Main control box
R46, 47	Relay, supply fan inverter, incr/decr	Main control box
R48, 49	Relay, return fan inverter, incr/decr	Main control box
R56	Relay, heater, water pipe	Main/RCE control box
R58,59	Relay, heat wheel inverter, incr/decr	Main control box
R60	Relay, energy recovery wheel, enable	Main control box
R61	Relay, smoke detector, discharge air	Main control box
R62, 63, 65	Relay, use on specials	Main control box
R64	Relay, sump pump	Main/RCE control box
R66	Relay, smoke detector, return air	Main control box
R67	Relay, supply fan, enable	Main control box
R68	Relay, return fan, enable	Main control box
R69	Relay, Inv. bypass VAV box interlock	Main control box
R70–79	Relay, use on specials	Main control box
RAE	Return air enthalpy sensor	Return section
RAT	Return air temperature sensor	Return section
REC1	Receptacle, main box	Main control box
REC2	Receptacle, condenser box	Condenser control box
REC3	Receptacle, field power, 115V	Discharge bulkhead
REC10–23	Receptacle, cabinet sections	Cabinet sections
S1	Switch, system on/off	Main control box
S2	Switch, system on/off, condenser unit	Condenser control box
S3	Switch, furnace on/off	Gas heat box
S4	Switch, inverter bypass, on/ off	Main control box
S7	Switch, local on/auto/off to controller	Main control box
S10–23	Switches, cabinet section lights	Cabinet sections
S40–45	Switches, door interlock, UV lights	Cabinet sections
SC11	Speed control, circuit #1	Condenser bulkhead
SC21	Speed control, circuit #2	Condenser bulkhead
SD1	Smoke detector, supply	Discharge section
SD2	Smoke detector, return	Return section
SPS1, 2	Static pressure sensors, duct/building	Main control box
SR1-3	Sequencing relays, electric heat	Electric heat box
SV1, 2	Solenoid valves, liquid	Condenser section
SV61, 62	Solenoid valves, sump, fill	Main/RCE control box
SV63	Solenoid valves, sump, drain	Main/RCE control box
SWT	Sump water temperature sensor	Evap. condenser section

ID	Description	Standard location
T1	Transformer, main control (line/115 V (ac))	Main control box
T2	Transformer, control input (115/24 V (ac))	Main control box
T3	Transformer, control output (115/24 V (ac))	Main control box
T4	Transformer, exh. damper actuator (115/12 V (dc))	Main control box
T5	Transformer, electric heat	Electric heat box
T6	Transformer, dew point controller (115/24 V (ac))	Main control box
T9	Transformer, refrig. circuit 24V	Main control box
T11	Transformer, speedtrol (line/240 V (ac))	Condenser section
TB1	Terminal block, internal	Main control box
TB2	Terminal block, field	Main control box
TB3	Terminal blocks, factory	Main control box
TB4	Terminal block, RFS, field	Main control box
TB5	Terminal block, RCS, field	Condenser control box
TB6	Terminal block, RCS, factory	Condenser control box
TB7	Terminal block, 115V convenience outlet, field	Main control box
TB8	Terminal block, 115V conv. outlet, RCS, field	Condenser control box
TB11	Terminal block, heat	Heat control box
TB23	Terminal block, oil pressure box, RPE/RCE only	Evap. condenser vestibule
TB25, 26, 27, 28	Terminal block, split unit junction box	Junction box, split unit
TC12, 13, 14	Temperature controls, Fantrol	Condenser section
TC56	Temperature control, water pipe heater	Evap. condenser vestibule
TC66	Temperature control, vestibule exhaust fan	Evap. condenser vestibule
TD1, 2	Time delay, compressor lockout	Main/cond. control box
TD3, 4	Time delay, hi-pressure	Main/cond. control box
TD5–8	Time delay, part winding, compr #1 - 4	Main control box
TD10	Time delay, hi turn down burner	Gas heat box
TD11, 12	Time delay, low ambient	Main/cond. control box
TR1, 2	Transducer, pressure	Main control box
U1, 2	Unloaders, compressors	On compressors
UV	Ultra-violet light(s)	Coil/discharge section
VM1	Valve motor #1, heating	Gas heat box/ heat section
VM5	Valve motor #5, cooling	Coil section, cool
VV1	Vent valve, gas heat	Heat Section, Gas
WL63	Water level, sump, fill	Evap. condenser section
WL64	Water level, sump, low water	Evap. condenser section
ZNT1	Zone temp. sensor, setback	Field installed

Wiring Diagrams

Figure 83: VAV Fan Power (With SAF and RAF VFDs and Unit Powered Outlet/Light Circuit)





Figure 84: VAV Fan Power (With SAF and RAF VFDs and Unit Powered Outlet/Light Circuit), Continued



Wiring Diagrams

Figure 85: Constant Volume Fan Power (SAF and RAF)






Figure 86: Constant Volume Fan Power (SAF and RAF), Continued

(Schematic continues on the previous page.)

144
145
146
147
148
149
150
151
152



161
162
163
164
165
166
167
168
169
170



Wiring Diagrams

Figure 87: RPS 75 Condensing Unit Power (With SpeedTrol and Scroll Compressors)




Figure 88: VFD Control (SAF and RAF)





Figure 90: VAV Control Inputs, Continued



Wiring Diagrams

Figure 93: Electric Heat Control

NOM. NOM.
KW --VOLTS
120 --380/480/600





Figure 94: Electric Heat Control (Continued)



Wiring Diagrams

Figure 95: RPS 60 Condensing Unit Control (With Scroll Compressors)





Figure 95: RPS 60 Condensing Unit Control (With Scroll Compressors), Continued



Wiring Diagrams

Figure 96: CV Fan Control (SAF and RAF)





Figure 97: Light and Receptacle Power (Field Power)




Control Actuators

The actuators are controlled by an analog signal from the unit controller. Damper actuators utilize a 0-10VDC analog signal while modulating heating/cooling valve actuators utilize a 2-

10VDC signal. Spring-return actuators are used for the 0-30% outdoor air and economizer dampers. The mixing dampers are normally closed to the outside air.

Figure 98: Control Actuators Wiring Diagram



Enthalpy Control


Outside Air Enthalpy Control (OAE)

Units with MicroTech III control and an economizer come standard with an electromechanical enthalpy control device (OAE) that senses both the humidity and temperature of the outside air entering the unit. This device has an enthalpy scale marked **A** through **D**. Table 20 shows the control points at 50% RH for settings **A** through **D**. Figure 99 shows this scale on a psychrometric chart. When the outside air conditions exceed the setting of the device, the outside air dampers are positioned to the minimum outside air intake position by the MicroTech III controller.

Table 20: Enthalpy Control Settings

Control curve	Control point temperature at 50% RH
A	73°F (23°C)
B	70°F (21°C)
C	67°F (19°C)
D	63°F (17°C)

Figure 99: Enthalpy Control Settings



Unit Options

Differential Enthalpy Control (OAE/RAE)

An optional electric differential enthalpy control arrangement (OAE/RAE) is available on units with MicroTech III control. In this configuration a solid-state humidity and temperature sensing device is located in both the return (RAE) and outside intake (OAE) airstreams. This OAE device has the same **A** through **D** scale as the device described above. However, with the OAE/RAE arrangement the switch on, OAE must be set all the way past the **D** setting. With this done, the MicroTech III controller adjusts the return and outside air dampers to use the airstream with the lowest enthalpy.

Ground Fault Protection

The ground fault protection is designed to protect motors from destructive arcing ground faults. The system consists of a ground fault relay and a ground fault current sensor. The ground fault relay employs solid state circuits that will instantly trip and open a set of relay contacts in the 115-volt control circuit to shut the unit down whenever a ground fault condition exists. The ground fault relay is self powered. The ground fault sensor is a current transformer type of device located on the load side of the power block through which the power wires of all phases are run.

Phase Voltage Monitor

The phase voltage monitor (see page 118) protects against high voltage, phase imbalance, and phase loss (single phasing) when any one of three line voltages drops to 74% or less of setting. This device also protects against phase reversal when improper phase sequence is applied to equipment, and low voltage (brownout) when all three line voltages drop to 90% or less of setting. An indicator run light is ON when all phase voltages are within specified limits. The phase voltage monitor is located on the load side of the power block with a set of

contacts wired to the 115-volt control circuit to shut the unit down whenever the phase voltages are outside the specified limits.

Hot Gas Bypass

Hot gas bypass is a system for maintaining evaporator pressure at or above a minimum value. The purpose for regulating the hot gas into the distributor is to keep the velocity of the refrigerant as it passes through the evaporator high enough for proper oil return to the compressor when cooling load conditions are light.

The system consists of a combination of solenoid valves and a pressure regulating valve as shown in Figure 100. The solenoid valves are factory wired to open whenever the controller calls for the first stage of cooling. The pressure regulating valve starts to modulate open at 57 psig (393 kPa).


Adjustments are made by turning the adjustment screw on the pilot valve. Turning the screw clockwise will increase the valve setting. Turning the screw counterclockwise will decrease the valve setting. The average psi charge per turn of adjustment is 16 psi.

The regulating valve opening point can be determined by slowly reducing the system load or reducing the required discharge air temperature setting while observing the suction pressure. When the bypass valve starts to open, the refrigerant line on the evaporator side of the valve will begin to feel warm to the touch.

CAUTION

Do not touch gas liner during valve checkout. The hot gas line can become hot enough in a short time to cause personal injury.

Figure 100: Hot Gas Bypass System




SpeedTrol™ (N/A Unit Sizes 015C to 030C)

McQuay's SpeedTrol system of head pressure control operates in conjunction with FanTrol by modulating the motor speed of the last condenser fan of each refrigeration circuit in response to condenser pressure. By varying the speed of the last condenser fan of each refrigeration circuit, the SpeedTrol option allows mechanical cooling operation in ambient temperatures down to 0°F (-18°C) provided the unit is not exposed to windy conditions. The system designer is responsible for assuring the condensing section is not exposed to excessive wind or air circulation. SpeedTrol controllers SC11 and SC21 sense refrigerant head pressure and vary the

fan speed accordingly. When the pressure rises, SpeedTrol increases the fan speed; when the pressure falls, SpeedTrol decreases the fan speed. The SpeedTrol controller's throttling range is 140 to 200 psig (1212 to 1318 kPa) fixed.

The SpeedTrol fan motor is a single phase, 208/240-volt, thermally protected motor specially designed for variable speed application. Units with 460-volt power have a transformer mounted inside the condenser fan compartment to step the voltage down to 230 volts for the SpeedTrol motor. A portion of a typical SpeedTrol power circuit schematic is shown in Figure 101.

Figure 101: SpeedTrol Schematic



External Time Clock

You can use an external time clock as an alternative to (or in addition to) the MicroTech III controller's internal scheduling function. The external timing mechanism is set up to open and close the circuit between field terminals 101 and 102. When the circuit is open, power is not supplied to binary input MCB-BI1. This is the normal condition where the controller follows the programmable internal schedule. When the circuit is closed, power is fed to BI1. The MicroTech III controller responds by placing the unit in the occupied mode, overriding any set internal schedule.

For more information, see the "Digital Inputs" section of Bulletin No. IM 696, "MicroTech III Applied Rooftop Unit Controller."

Smoke and Fire Protection

McQuay optionally offers factory installed outdoor air, return air, and exhaust air dampers as well as smoke detectors in the supply and return air openings, complete with wiring and control. These components often are used in the building's smoke, fume, and fire protection systems. However, due to the wide variation in building design and ambient operating conditions into which our units are applied, we do not represent or warrant that our products will be fit and sufficient for smoke, fume, and fire control purposes. The owner and a fully qualified building designer are responsible for meeting all local and NFPA building code requirements with respect to smoke, fume, and fire control.



WARNING


Improper smoke, fire, or fume air handling can result in severe personal injury or death.

Unit Options

Smoke Detectors

Field installed smoke detectors in the return air ductwork or the supply air ductwork can be coordinated with the units operation through the unit controller's binary input, D14. This input is wired to TB2 and the supply air smoke detector can be wired between terminals 103 and 104 and the return air smoke detector can be wired between terminals 104 and 105. The T2 transformer supplies 24 V (ac) across each of these terminals and a dry set of contacts can be wired to these terminals respectively. This and additional wiring information can be seen on the input wiring schematics at line number 220.

Figure 102: Smoke Detector Schematic



Factory installed smoke detectors have similar wiring and the control sequence is as follows:

When smoke is detected by either sensor, the normally closed sensor contacts open. This removes power from binary input B18 on the main control board.

The Microtech III controller responds by shutting down the unit. The controller is placed in the Alarm Off state and cannot be restarted until the alarm is manually cleared. Refer to the operation manual supplied with the unit for information on clearing alarms.

The smoke detectors must be reset manually once they have been tripped. Power must be cycled to the smoke detector to reset.

Emergency Shutdown

The terminals 105 & 106 on TB2 can be used for any field supplied component that requires a unit emergency shutdown. When these terminals are used, the factory installed jumper must be removed.

Freeze Protection

An optional freezestat is available on units with MicroTech III control that have hot water, chilled water, or steam heating coils. The sensing element is located on the downstream side of the heating coil in the heating section of the unit. If the freezestat detects a freezing condition and closes, the MicroTech III controller takes different actions, depending on whether the fans are on or off. The freezestat is an auto reset

type of control; however, the controller alarm that it causes is manually reset if the fan is on and auto reset if the fan is off.

Fan On Operation

If the freezestat detects a freezing condition while the fan is on, the MicroTech III controller shuts down the fans, closes the outdoor air dampers, opens the heating valve, and sets a 10-minute timer. The MicroTech III controller's active alarm is "Freeze Fault."

When the 10-minute timer expires, the controller begins checking the freezestat again. If the freezestat is open, the heating valve closes. If the freezestat closes again, the heating valve opens, and the 10-minute timer resets.

The unit remains shut down until the "Freeze Fail" alarm is manually cleared. Refer to the operation manual supplied with the unit for information on clearing alarms (OM138 or OM137).

Fan Off Operation

If the freezestat detects a freezing condition while the fan is off, the MicroTech III controller opens the heating valve and sets a 10-minute timer. The MicroTech III controller's active alarm is "Freeze Problem."

When the 10-minute timer expires, the controller begins checking the freezestat again. If the freezestat is open, the heating valve closes. If the freezestat closes again, the heating valve opens, and the 10-minute timer resets.

When the freezestat opens again, the "Freeze Prob" alarm automatically clears. This feature protects the coil and allows the system to start normally after a cold night.


External Time Clock or Tenant Override

There are several methods of switching the rooftop unit between occupied and unoccupied operation. It can be done by the controller internal schedule, a network schedule, an external time clock, or a tenant override switch.

If the internal schedule or a network schedule is used, field wiring is not required.

An external time clock or a tenant override switch can be used by installing a set of dry contacts across terminals 101 and 102 on the field terminal block (TB2). When these contacts close, 24 V (ac) is applied to binary input MCB-DI3, overriding any internal or network schedule and placing the unit into occupied operation (provided the unit is not manually disabled). When the contacts open (24 V (ac) is removed from MCB-DI3) the unit acts according to the controller internal time schedule or a network schedule. Refer to the unit wiring diagrams for specific wiring termination details.

Figure 103: External Time Clock or Tenant Schematic



Field Output Signals

The following outputs may be available for field connections to a suitable device.

VAV Box Signal/Fan Operation Signal

Digital Output #10 (MCB-DO10) may be selected as either the Fan Operation output or the VAV output via the keypad. The VAV/Fan Op selection can be selected by accessing the Unit Setup menu in the Extended Menu section.

Fan Operation

The Fan Operation Output (MCB-DO10) supplies 24 V (ac) to terminal 116 on the field terminal block (TB2) when the output is on. To use this signal, wire the coil of a field supplied and installed 24 V (ac) pilot relay across terminals 116 and 117 on TB2. When this output is on, 24 V (ac) is supplied from the T3 control transformer through the output relay to energize the field relay. Refer to the as-built wiring diagrams.

The Fan Operation output is on when the unit is not Off and when both the unit is Off and airflow is detected. It is off when the unit is off and airflow is not detected.

VAV Box Output


The VAV Box Output (MCB-DO10) supplies 24 V (ac) to terminal 116 on the field terminal block (TB2) when the output is on. To use this signal, wire the coil of a field supplied and installed 24 V (ac) pilot relay across terminals 116 and 117 on TB2. When this output is on, 24 V (ac) is supplied from the T3 control transformer through the output relay to energize the field relay. Refer to the as-built wiring diagrams.

In the Heating state, the VAV Output is turned off to indicate that hot air instead of the normal cool air is being supplied to the VAV boxes. The VAV boxes are driven to their Heating Position when hot air is provided based on either the normally open or normally closed contacts of the VAV output. The VFD will continue to be controlled to maintain the desired duct static pressure. This output is also off when the unit is in the Startup or Recirculation states. If this output is in the Heat (off) position when the unit enters the Fan Only state or Minimum DAT Control state, the output remains off for an adjustable Post Heat Time (while the unit VFDs are driven to minimum speed) or until the VFD gets to its minimum speed if the Post Heat Time is set greater than 0. The Post Heat Timer can be adjusted via the keypad/display Timer Setting menu in the Extended Menus.

Unit Options

During unoccupied operation, the VAV Box Output is in the Cool (on) position unless airflow is detected. When airflow is detected, it switches to the Heat (off) position.

Figure 104: Field Output Schematic



Entering Fan Temperature Sensor

The entering fan temperature (EFT) sensor and an associated “Lo Airflow Problem” alarm are provided on VAV units with MicroTech III control and gas or electric heat. The EFT sensor is located in the supply fan section of the unit at the supply air funnel.

Heat is disabled whenever the airflow is detected to be too low for safe heating operation. This condition is indicated when the supply air temperature exceeds the mixed air temperature by more than 60°F (16°C).

Note: This value is not always 60°F. It depends on whether the unit is gas or electric heat and on the burner/baffling arrangement on gas heat units.

In this case, a “Lo Airflow Problem” alarm is generated and heat is not enabled until the alarm is manually cleared. Refer to the operation manual supplied with the unit for information clearing alarms (OM 920).

Duct High Pressure Limit

The duct high pressure limit control (DHL) is provided on all VAV units. The DHL protects the duct work, the terminal boxes, and the unit from over pressurization, which could be caused by, for example, tripped fire dampers or control failure.

The DHL control is factory set to open when the discharge plenum pressure rises to 3.5" wc (872 Pa). This setting should be correct for most applications; however, it is adjustable. Removing the front cover of the device reveals a scale

showing the current setting. Turning the adjustment screw (located on the bottom of the device) adjusts the setting up or down.

If the DHL switch opens, digital input MCB BI 14 on the Main Control Board de-energizes. The MicroTech III controller then shuts down the unit and enters the Off-Alarm state. The alarm must be manually cleared before the unit can start again. Refer to the operation manual supplied with your unit for more information on clearing alarms (OM 920).

Variable Frequency Drive Operation

Refer to the vendor instructions supplied with the unit.

Convenience Receptacle/Section Lights

A Ground Fault Circuit Interrupter (GFCI) convenience receptacle is provided in the main control box on all units. One of the following is required:

- 1 Connect a separate field-supplied 115 V power wiring circuit to the 115V field terminal block TB7, located in the main control box.
- 2 Select the factory powered outlet option at time of purchase.

Optional lights are available for certain sections in the unit. Each light includes a switch and convenience receptacle and is powered by the external 115V power supply connected to TB7.

DesignFlow™ Outdoor Air Damper Option

DesignFlow™ airflow measurement stations are located inside the louvered outdoor air intake doors between the intake louver and outside air dampers. Essentially, they consist of a vane that is repositioned by airflow, the amount of rotation indicating the amount of airflow. They are calibrated precisely at the factory and no further calibration is required. However, a leveling adjustment is required in the field so that the DesignFlow unit is in the same orientation as when it was factory calibrated. See “DesignFlow Station Startup” below.

The rotational position of the DesignFlow unit vane is translated into CFM by the microprocessor in the MicroTech III control system. The position of the vane is determined by two things—the force of the airflow impacting the vane and the gravitational effect on the vane. Gravity is the only factor at the lower CFM end of the range. On a correctly leveled unit, this gravitational effect will be the same as when the unit was calibrated in the factory.

Accurately leveling a station involves applying a precise mechanical force against the vane. This force should cause the vane to move to a specific position if the DesignFlow unit is correctly leveled.

DesignFlow Station Startup


- Before initial startup of the rooftop unit, carry out the following procedure on both the right-hand (control panel side) and left-hand (side opposite the control panel) DesignFlow station vanes (see Figure 105).

Note: This procedure is much easier to carry out with two people—one making the mechanical adjustments and the other viewing and recording readings on the MicroTech III control panel.

- 1 Verify that power is supplied to the unit’s MicroTech III control system. The DesignFlow startup procedure cannot be completed without use of the MicroTech III controls.
- 2 Unlock and open the louvered outdoor air intake door on the side of the unit (see Figure 105).
- 3 The swinging vane on the measurement station is locked in place for shipment. Unlock it by removing the two shipping screws. One is located one inch from the top of the vane and the other one inch from the bottom of the vane. Both are about eight inches in from the outer edge of the vane.

- 4 Examine the station for shipping damage. Manually rotate the vane and verify that it does not rub against anything.

Figure 105: DesignFlow Station



- 5 Manually hold the vane closed against the mechanical stop at the top of the assembly. Then, read the current vane leveling position on the MicroTech III keypad/display.

Do this by viewing the *LH Lvl Pos=* or *RH Lvl Pos=* parameter in the DesignFlow setup menu. The *LH Lvl Pos=* parameter indicates the current position of the vane for the left-hand DesignFlow station (side opposite the control panel). The *RH Lvl Pos=* parameter indicates the current position of the vane for the right-hand DesignFlow station (control panel side).

Important: Wait several seconds until the value on the keypad stabilizes before taking the reading.

For detailed information regarding operation and navigation through the unit keypad, refer to Operation manual OM 920.

- 6 Confirm the value of the reading. Ideally, it should read close to 20.00 (19.50 to 20.50 is acceptable). If the reading is out of range, loosen the screws fixing the mechanical stop at the top of the assembly, make a small adjustment, and recheck until the reading is in the specified range.


Note: Generally, adjustments should not be necessary.

- 7 Locate the leveling component kit, which is shipped with the unit, in the unit mail control panel.

Unit Options

- 8 Duct tape the fulcrum alignment plate to the bottom corner of the vane (see Figure 106) aligning it as follows:
 - a The bottom edge of its notches should be flush with the bottom edge of the vane.
 - b The side of one notch should be even with the bend near the outer edge of the vane.
 - c Plate should be flat against the outer surface of the vane.

Figure 106: Tape Fulcrum Alignment Plate to Vane



- 9 Locate and install the fulcrum used in the leveling procedure as follows (see Figure 106):
 - a Wipe the bottom of the louver door where the fulcrum will be located so that the duct tape will stick to it.
 - b Pre-apply duct tape to the top surface of the bottom portion of the fulcrum, extending it about one inch beyond the edges on three sides.
 - c With the alignment plate taped to the vane and the vane in the zero airflow position, locate the fulcrum parallel to and against the alignment plate.


Note: The zero airflow position is when the vane is swung away from the back wall and gently resting against its stop.

- d Once the fulcrum is in position, press the duct tape extensions down to hold the fulcrum in place.
- e Remove the alignment plate after installing the fulcrum.

- 10 Close and latch the louvered intake door.
- 11 Remove the cover from the access opening in the bottom blade of the outdoor air intake louver (see Figure 109).
- 12 Verify that the unit fans are off and that the outdoor air dampers are closed. If there is a wind, cover the outdoor air louvers with poly film, cardboard, or other suitable material to prevent adverse readings due to wind.
- 13 Rest the leveling weight assembly on the fulcrum, as shown in Figure 107, so that:
 - a Bottom two thumbscrews rest on the top edge of the fulcrum.
 - b Its top thumbscrew rests against the vertical alignment mark on the vane.

Note: The alignment mark is located 0.50 inch in from the bend on the outer edge of the vane. It intersects with a hole located one inch up from the bottom outer edge of the vane.

Figure 107: Place Leveling Weight on Fulcrum



- 14 Set up the leveling test as follows:
 - a While holding the weight so it stays on the fulcrum, manually rotate the vane to the wide-open position, manually return it to the zero CFM position, and gently release the vane.
 - b Locate the leveling weight assembly so its contact point is against the vertical mark on the vane.
 - c While the weight assembly teeters on the fulcrum, gently rap the base frame to slightly vibrate the assembly and encourage the vane to seek its equilibrium point.
- 15 Read the current *LH Lvl Pos=* (or *RH Lvl Pos=*) parameter in the DesignFlow Setup menu on the keypad/display. These parameters vary from 20% to 80% depending on the position of the DesignFlow vane
- 16 If the value indicated by the *LH Lvl Pos=* (or *RH Lvl Pos=*) parameter is not within the range of 23.64% to 24.08%, adjust the level of the DesignFlow unit using the procedure described in “Making Level Adjustments” below.
- 17 When the *LH Lvl Pos=* (or *RH Lvl Pos=*) value is in range, remove the fulcrum and leveling weight assembly and replace the access opening cover in the louvered door.


Making Level Adjustments

The DesignFlow unit is mounted so that it pivots at the top when three lock nuts are loosened, two at the top and one at the bottom of the assembly (see Figure 108). Leveling the unit involves precisely pivoting the assembly with a known force applied to the vane until the vane opens to a specific position.

If after performing Steps 13 through 15 (previous page), the vane does not come to rest within the specified range, carry out the following steps:

- 1 Unlock and open the louvered outdoor air intake door on the side of the unit.
- 2 Loosen the two .25-20 NC lock nuts at the top of the DesignFlow frame (see Figure 108).

Figure 108: DesignFlow Frame



- 3 Close and lock the intake door.
- 4 Remove the cover from the access opening in the bottom blade of the outdoor air intake louver (see Figure 109).
- 5 Loosen the .25-20 NC lock nut in the slotted hole at the bottom of the DesignFlow frame (see Figure 110).
- 6 **If the LH Lvl Pos= (or RH Lvl Pos=) value obtained in step 15 above is HIGHER than the specified range,** move the bottom of the DesignFlow frame closer to the outdoor air dampers (away from the back end of the unit). Do this by turning the long adjuster nut to increase the L dimension in Figure 110.

If the LH Lvl Pos= (or RH Lvl Pos=) value obtained in step 15 above is LOWER than the specified range, move the bottom of the DesignFlow frame away from the outdoor air dampers (toward the back end of the unit). Do this by turning the long adjuster nut to decrease the L dimension in Figure 110.

Note: If the necessary adjustment cannot be made using the long adjuster nut, reposition the two .25-20 NC jam nuts on the threaded rod to make larger adjustments (see Figure 110).

- 7 When finished making the adjustments, tighten the .25-20 NC lock nut in the slotted hole at the bottom of the DesignFlow frame (see Figure 110).
- 8 Gently rap the base frame to slightly vibrate the assembly to encourage the vane to seek its equilibrium point.
- 9 Recheck the vane position compared to the range specified in Step 16 (previous page). Readjust the level as necessary.
- 10 When the level is correct, unlock and open the louvered outdoor air intake door on the side of the unit and tighten the two .25-20 NC lock nuts at the top of the DesignFlow frame (see Figure 108).
- 11 Close and lock the intake door.
- 12 Recheck the vane position and readjust the level as necessary.
- 13 When the vane position is correct, replace the access opening cover in the louvered door.

Figure 109: Remove Covers From Access Opening





Figure 110: Leveling Adjustment




Unit Options

Propeller Exhaust Fan Option

Economizer units may include propeller exhaust or centrifugal return fan options. This section covers maintenance and operating instructions for the propeller exhaust option. Centrifugal return fan construction, maintenance and operation is similar to that for supply fans and covered in other sections of this manual.

Figure 111: Two Fans With Back Return Shown



Prestarting Checks


Check all fasteners and set screws for tightness. This is especially important for bearing set screws.

The propeller should rotate freely and not rub on the fan panel venturi. Rotation direction of the propeller should be checked by momentarily turning the unit on. Rotation should be in the same direction as the rotation decal affixed to the unit or as shown in Figure 112. For three-phase installations, fan rotation can be reversed by simply interchanging any two of the three electrical leads. For single phase installations follow the wiring diagram located on the motor.

The adjustable motor pulley is preset at the factory for the specified fan RPM. Fan speed can be increased by closing (or decreased by opening) the adjustable pulley. Two or three groove variable pitch pulleys must be adjusted an equal number of turns open. Any increase in fan speed represents a

substantial increase in horsepower required from the motor. Always check motor load amperage and compare to name plate rating when changing fan speed.

Figure 112: Fan Rotation



Once the fan is put into operation, set up a periodic maintenance program to preserve the reliability and performance of the fan. Items to include in this program are:

- Belts
- Bearings
- Fasteners
- Setscrews
- Lubrication
- Dust/dirt removal

Belts

Premature belt failures are frequently caused by improper belt tension (either too tight or too loose) or misaligned pulleys. The proper tension for operating a V-belt is the lowest tension at which the belts will not slip peak load conditions. For initial tensioning, the proper belt deflection half way between pulley centers is 1/64" for each inch of belt span. For example, if the belt span is 64 inches, the belt deflection should be one inch using moderate thumb pressure at midpoint of the drive (see Figure 113).

Check belt tension two times during the first 24 hours of operation and periodically thereafter. To adjust belt tension, simply loosen four fasteners (two on each side of the motor plate) and slide the motor plate away from the fan shaft until proper belt tension is attained. On some fans, fasteners attaching the motor to the motor plate must be loosened to adjust the belt.

It is very important that the drive pulleys remain in proper alignment after adjustments are made (see Figure 114). Misalignment of pulleys results in premature belt wear noise, vibration, and power loss.

WARNING

Rotating parts can cause severe personal injury or death. Replace all belt/fan guards that are removed temporarily for service.

Figure 113: Belt Adjustment




Figure 114: Drive Pulley Alignment





Table 21: Propeller Exhaust Fan Troubleshooting

Problem	Cause	Corrective Action
Reduced Airflow	System resistance is too high.	Check backdraft dampers for proper operation. Remove obstructions in ductwork. Clean dirty filters. Check for adequate supply for air exhaust fans or exhaust air for supply fans.
	Unit running backwards.	See "Prestarting Checks" on page 94
	Fan speed too low.	Increase fan speed
	Excessive dirt on propeller.	Clean propeller
Excessive Noise	Bearings	Tighten bearing collars and setscrews. Lubricate bearings. Replace defective bearings.
	V-Belt drive	Tighten pulleys on motor shaft and fan shaft. Adjust belt tension. Align pulleys. Replace worn belts or pulleys.
	Excessive vibration	Clean dirt build-up from propeller. Check all setscrews and fasteners for tightness. Check for worn bearing. Correct propeller imbalance. Check for loose dampers, guards or ductwork.
	Defective motor	Replace motor.

Figure 115: Propeller Exhaust Fan Replacement Parts List



Unit Options

Bearings

Bearings are the most critical moving part of the fan and should be inspected at periodic intervals. Locking collars and set screws, in addition to fasteners attaching the bearings to the bearing plate, must be checked for tightness. In a clean environment and temperatures above 32°F/below 200°F, fan shaft bearings with grease fittings should be lubricated semiannually using a high quality lithium based grease. If unusual environmental conditions exist temperatures below 32°F/above 200°F, moisture or contaminants, more frequent lubrication is required.

With the unit running, add grease very slowly with a manual grease gun until a slight bead of grease forms at the seal. Be careful not to unseat the seal by over lubricating or using excessive pressure. Bearings without grease fittings are lubricated for life.

Fasteners and Setscrews

Any fan vibration has a tendency to loosen mechanical fasteners. A periodic inspection should include checking all fasteners and set screws for tightness. Particular attention should be paid to setscrews attaching the propeller to the shaft and the shaft to the bearings. Loose bearing set screws will lead to premature failure of the fan shaft.

Lubrication

Refer to “Bearings” for bearing lubrication. Many fractional horsepower motors installed on the smaller fans are lubricated for life and require no further attention. Motors equipped with oil holes should be oiled in accordance with the manufacturer’s instructions printed on the motor. Use a high grade SAE 20 machine oil and use caution not to over lubricate.

Motors supplied with grease fittings should be greased according to directions printed on the motor.

Removal of Dust/Dirt

Thoroughly clean the exterior surface of the motor, fan panel, and entire propeller periodically. Dirt can clog cooling openings on motor housings, contaminate bearing lubricant, and collect on propeller blades causing severe imbalance if left unchecked. Use caution and do not allow water or solvents to enter the motor or bearings. Under no circumstances should motors or bearings be sprayed with steam or water.

Exhaust Fan On/Off Control

The exhaust fans are turned on and off based on building static pressure, outdoor air damper position, and discharge fan capacity. Exhaust fans do not have to always run while the supply fan is on, as does a return fan. They are turned on and off through output MCB-B02 on the Main Control Board. For detailed information on Propeller Exhaust Fan Control, refer to the operation manual supplied with the unit (OM 920).

Exhaust Fan Troubleshooting

Table 21 provides guidelines for troubleshooting problems with the propeller exhaust fan options. A list of parts is provided in Figure 115.

Ultraviolet Lights Option

When this option is employed, ultraviolet C light bathes the moist surfaces on the coil and drain pan, killing most micro-organisms that can grow there.

Typically, ultraviolet lights are installed on the leaving side of the cooling coils in the unit. Each light module is mounted on a rail and is removable for convenient bulb replacement.


UV Light Power Disconnect switches (two per door) are factory installed on every door that allows a direct line of sight to the UV lamps when opened. These switches are designed to prevent UV exposure when cabinet doors are opened and must not be disabled.

A viewing window near the UV lights allows viewing to determine if the lights are energized. The viewing windows use specially designed glass that blocks harmful UV light.

⚠ WARNING

UVC exposure is harmful to the skin and eyes. Looking at an illuminated bulb can cause permanent blindness. Skin exposure to UVC can cause cancer. Always disconnect power to unit before servicing. Do not operate if disconnect switch has been disabled.

Figure 116: Typical Ultraviolet Light Installation




Ultraviolet Light Operation

Refer to the wiring schematic below. 115 V (ac) power for the UV lights is provided by control circuit transformer T1. The lights operate whenever the unit is powered, system switch S1 is closed, and all doors with door power disconnect switches are closed. To turn the lights off, disconnect power to the entire unit, or open system switch S1.

The normally open disconnect switches are wired in series in a circuit that supplies 24 V (ac) to the coil of relay R45. When all doors are closed, relay R45 is energized, and its normally open contacts (in series with system switch S1) provide 115 V (ac) to the UV lights.

Figure 117: Typical Ultraviolet Light Wiring Schematic



Check, Test, and Start Procedures

All units are completely run tested at the factory to promote proper operation in the field. Nevertheless, the following check, test, and start procedures must be performed to properly start the unit. To obtain full warranty coverage, complete and sign the check, test, and start form supplied with the unit, or fill out the “Rooftop Equipment Warranty Regist. Form” on page 124, and return it to McQuay International.

WARNING

Electric shock and moving machinery hazard. Can cause severe equipment damage, personal injury, or death. Disconnect and tag out all electrical power before servicing this equipment.
All start-up and service work must be performed only by trained, experienced technicians familiar with the hazards of working on this type of equipment.
Read and follow this manual: “MicroTech III Applied Rooftop Unit Controller” manual (Bulletin IM 696), and operation manual (OM 920) before operating or servicing.
Bond the equipment frame to the building electrical ground through grounding terminal or other approved means.

A representative of the owner or the operator of the equipment should be present during start-up to receive instructions in the operation, care, and maintenance of the unit.

If the unit has a factory mounted disconnect switch, use the switch’s bypass mechanism to open the main control panel door without de-energizing the control panel (see page 117 for instructions).

Servicing Control Panel Components

WARNING

Hazardous voltage. Can cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

Disconnect all electric power to the unit when servicing control panel components located behind the protective deadfront panels. Always inspect units for multiple disconnects to ensure all power is removed from the control panel and its components before servicing.

Before Start-Up

- 1 Verify that the unit is completely and properly installed with ductwork connected.
- 2 Verify that all construction debris is removed, and that the filters are clean.
- 3 Verify that all electrical work is complete and properly terminated.
- 4 Verify that all electrical connections in the unit control panel and compressor terminal box are tight, and that the proper voltage is connected.
- 5 Verify all nameplate electrical data is compatible with the power supply.

- 6 Verify the phase voltage imbalance is no greater than 10%.
 - 7 Verify that gas piping is complete and leak tight.
 - 8 Verify that the shutoff cock is installed ahead of the furnace, and that all air has been bled from the gas lines.
 - 9 Manually rotate all fans and verify that they rotate freely.
 - 10 Verify that the belts are tight and the sheaves are aligned.
 - 11 Verify that all setscrews and fasteners on the fan assemblies are still tight. Do this by reading and following the instructions in “Setscrews,” which is in the “Maintenance” section of this manual.
 - 12 Verify that the evaporator drain is trapped and that the drain pan is level.
 - 13 If unit is curb mounted, verify that the curb is properly flashed to prevent water leakage.
 - 14 Before attempting to operate the unit, review the control layout description to become familiar with the control locations.
 - 15 Review the equipment and service literature, the sequences of operation, and the wiring diagrams to become familiar with the functions and purposes of the controls and devices.
 - 16 Determine which optional controls are included with the unit.
 - 17 Before closing (connecting) the power disconnect switch, open (disconnect) the following unit control circuit switches:
 - a Main Control Panel
 - Turn system switch S1 to OFF.
 - Electric heat units: turn switch HS1 to OFF.
 - b Furnace Control Compartment
 - Turn furnace switch S3 to OFF.
 - Main Control Panel Switch S7 to OFF.
 - 18 If the DAC or SCC unit does not have an optional zone temperature sensor (ZNT1) connected to it, you may need to change the keypad entry under *Setup/Service \ Unit Configuration \ Space Sensor*= from YES to NO.
- Note:** If desired, you can significantly reduce all MicroTech III internal control timers by the changing the entry under keypad menu *Setup/Service \ Unit Configuration \ Timer Settings \ Service*= from “0 min” to “X min” where X is the number of minutes you want the unit to operate with fast timers.

Power Up

- 1 Close the unit disconnect switch. With the control system switch S1 in the OFF position, power should be available only to the control circuit transformer (TI) and the compressor crankcase heaters.
- 2 Turn the Switch S1 to ON. Power should now be supplied to the control panel and the LEDs on MCB1 should follow the normal startup sequence.

Fan Start-Up

- 1 Verify all duct isolation dampers are open. Unit mounted isolation dampers may be mounted in the supply or return sections.
- 2 Place the unit into the “Fan Only” mode through the keypad menu *System Summary\System\Ctrl Mode= Fan Only*.
- 3 Turn Switch S7 to ON. The controller should enter the “Startup Initial” operating state. If the fan does not run:
 - a Check fuses F1 and F3.
 - b Check the manual motor protectors or that the circuit breakers have not tripped.
 - c Check the optional phase monitor.
- 4 If the fans are equipped with optional spring isolators, check the fan spring mount adjustment. When the fans are running they should be level. Refer to “RDT Spring Mount Hold-Down Fasteners” on page 60.
- 5 Verify the rotation is correct.
- 6 Verify the DHL safety is opening at a pressure compatible with duct working pressure limits.

Note: The supply and return fan drives usually are selected for operation in the drive's midspeed range. The return fan drives are usually shipped with fixed pitch sheaves that will provide the selected fan speed; however, the supply fan drives are usually shipped with variable pitch sheaves that are adjusted to provide the minimum fan speed. Both drives should be adjusted for proper airflow during air balancing. For more information, refer to “Air Balancing” on page 102.

Economizer Start-Up

CAUTION

Adjust dampers properly. Improper adjustment can damage the dampers.

When an economizer is ordered without an actuator, the linkage requires a 3.14" linear stroke to open it fully. Do not allow dampers to be driven beyond their normal full closed or full open position.

- 1 Check whether the outdoor air is suitable for free cooling by displaying the keypad menu *Temperature\OA Damper\OA Ambient=*. “Low” indicates low outdoor air enthalpy; “High” indicates high outdoor air enthalpy. See “Control Actuators” on page 85 to verify that the enthalpy changeover control is working properly. You may want to take temperature and humidity measurements.
- 2 At the keypad, set the cooling setpoint low enough so the controller calls for cooling. Adjust the value in *Temperature\Zone Cooling\Occ Clg Spt=* below the temperature shown in *Temperature\Zone Cooling\Control*

Temp=. In addition, on DAC units, adjust the value in *Temperature\Discharge Cooling\DAT Clg Spt=* below the temperature shown in *Temperature\Discharge Cooling\Disch Air=*.

- 3 Place the unit into cooling mode through the keypad menu *System Summary\System\Ctrl Mode= Cool Only*.
- 4 Observe the outdoor air dampers:
 - a If the outdoor enthalpy is low, the control algorithm should start to modulate the dampers open to maintain the discharge air setpoint.
 - b If the outdoor enthalpy is high, the dampers should maintain their minimum position. Look at menu *Temperature\OA Damper\MinOA Pos=*. Change this entry to another value. Verify that the dampers move to the new minimum position setpoint.
- 5 If the unit is equipped with the electromechanical enthalpy changeover control (Honeywell H205) and the outdoor air condition is borderline, attempt to change its input to the MicroTech III controller by turning the switch adjustment to “A” or “D.” Check enthalpy status in keypad menu *Temperature \ OA Damper \ OA Ambient=*. If this reading is “Low,” go to step 5a. If it is “High,” go to step 5b.

Note: It may not be possible to check the economizer operation in both low and high enthalpy states on the same day. If this is the case, repeat this procedure on another day when the opposite outdoor air enthalpy conditions exist.

Compressor Startup

With the supply and return fans operational, prepare for compressor operation.

CAUTION

Low ambient temperature hazard. Can cause compressor damage.
Do not attempt to start up and check out the refrigeration system when the outdoor air temperature is below 50°F unless the unit is specially equipped for low ambient operation.


The unit is shipped with refrigeration service valves closed. Backseat (open) the discharge and liquid line valves. Connect service gauges and crack the valves off the backseat position (one turn forward). Verify that the unit has not lost its refrigerant charge.

Verify that the crankcase heaters are operating. These should operate for at least 24 hours before starting the compressors.

Verify that the condenser fan blades are positioned properly and that the screws are tight (see Figure 118). The fan blade must be correctly positioned within its orifice for proper airflow across the condenser coils.

Check, Test, and Start Procedures

Figure 118: Condenser Fan Blade Positioning



Scroll Compressor Rotational Direction

Scroll compressors only compress in one rotational direction. Three-phase compressors rotate in either direction depending upon phasing of the power to L1, L2, and L3. Since there is a 50/50 chance of connecting power to cause rotation in the reverse direction, verify that the compressor rotates in the proper direction after the system is installed. If the compressor is rotating properly, suction pressure drops and discharge pressure rises when the compressor is energized. If the compressor is rotating in reverse, the sound level is louder and current draw is reduced substantially. After several minutes of operation, the compressor's internal protector trips.

All three-phase compressors are wired the same internally. Therefore, once the correct phasing is determined for a specific system or installation, connecting properly phased power leads to the same terminals should maintain proper rotation direction.

Perform the following procedure on all units:

- 1 At the keypad, set the cooling setpoint low enough so that the controller will call for cooling. The value in *Temperature \ Zone Cooling \ Occ Clg Spt=* will need to be adjusted below the temperature shown in *Temperature \ Zone Cooling \ Control Temp=*. In addition, on DAC units, the value in *Temperature \ Discharge Cooling \ DAT Clg Spt=* will need to be adjusted below the temperature shown in *Temperature \ Discharge Cooling \ Disch Air=*.
- 2 Place the unit into cooling mode through the keypad menu *System Summary \ System \ Ctrl Mode= Cool Only*.
- 3 Verify that the low ambient compressor lockout temperature setpoint, *Temperature \ OA Damper \ OATComp Lock=* is set below the current outside air temperature (shown in *System Summary \ Temperatures \ OA Temp=*).

Note: Do not attempt to operate the compressors if the outdoor air is too cool. See the warning statement under "Compressor Startup" on page 99.

- 4 Close the S1 switch. Now refrigeration circuit #1 is enabled, circuit #2 is disabled, and the MT III board starts its 5-minute timing cycle. Note that if the unit has an economizer and the outdoor air enthalpy is low, the economizer must fully open before the controller will energize mechanical cooling.

- 5 When the outdoor air damper has fully opened and the time delay has expired, liquid line solenoid valve SV1 should open and compressor #1 should start. If this does not happen, perform the following:
 - a Verify that there is a call for cooling by checking the keypad menu *System Summary \ System \ UnitStatus=*. This should be in "Cooling."
 - b Check the keypad menu *System Summary \ System \ Clg Status=*. The compressors will only run if this reads either "All Clg" or "Mech Clg."
 - c Trace the control circuits.

NOTICE

Venting refrigerant to atmosphere is not allowed per most local laws and/or codes.

- 6 Verify that compressor #1 starts. The compressor should start when the solenoid valve opens. If the compressor motor hums but does not run, verify that it is getting three-phase power.
- 7 The compressor should operate continuously while there is a call for cooling. If the compressor cycles on its low pressure switch, perform the following:
 - a Verify that the circuit is not short of refrigerant.
 - b Check for low airflow.
 - c Check for clogged filters.
 - d Check for restricted ductwork.
 - e Check for very low temperature return air entering the unit.
 - f Verify that the liquid line components, expansion valve, and distributor tubes are feeding the evaporator coil.
 - g Verify that all air handling section panels are closed.
 - h Verify that the liquid line service valves are completely open.
- 8 Verify that the compressors stage properly. As the circuit loads up, the second compressor (if available) will be energized. For more information on staging sequences, see IM 919, "MicroTech III Applied Rooftop Unit Controller."
- 9 Verify that the condenser fans are cycling and rotating properly (blowing air upward). When the compressor starts, at least one condenser fan should also start. The CCB1 should control the remaining condenser fans based on outdoor air conditions. Look at keypad menu *Setup/Service \ Compressor Setup \ Cond Fan1=* (also look at *Cond Fan2=, Cond Fan3=, Cond Fan4=*). The table 14 on page 45 shows recommended setpoints based on the unit size. Cond Fan1 controls BO5, Cond Fan2 controls BO6, Cond Fan3 controls BO7, Cond Fan4 controls BO8. Refer to the unit wiring diagrams and "Condenser Fan Arrangement" on page 6.
- 10 Check the oil level in the compressor sightglass. If low oil is observed, it is possible that liquid refrigerant is returning

to the compressor. Check the suction superheat, see “Expansion Valve Superheat Adjustment” on page 101. It should be between 10°F (5.5°C) and 13°F (7.2°C). See “Expansion Valve Superheat Adjustment” below.

- 11 Open switch S1. The compressor(s) should stop. Place the unit into the “Fan Only” mode through the keypad menu *System Summary \ System \ Ctrl Mode= Fan Only*.
- 12 Check refrigerant circuit #2 by repeating steps 2 through 9, substituting circuit #2 nomenclature for circuit #1 nomenclature (S2, TD2, SV2, CCB2, compressor #2 and #4).
- 13 Verify that the condenser refrigerant subcooling at full capacity is between 13°F and 20°F.

Expansion Valve Superheat Adjustment

It is very important that the expansion valve superheat setting be adjusted to be between 10°F (-12°C) and 13°F (-11°C). Insufficient superheat will cause liquid floodback to the compressor which may result in slugging. Excessive superheat will reduce system capacity and shorten compressor life.

Turn the adjustment stem clockwise to increase superheat. Not exceeding one turn, adjust the stem and then observe the superheat. Allow up to 30 minutes for the system to rebalance at the final superheat setting.

On refrigeration circuits with multiple expansion valves, the superheat adjustment should be approximately the same for all valves in the circuit.

Note: If low oil level is accompanied by heavy foaming visible in the oil sightglass, it is possible that excess liquid refrigerant is returning to the compressor

depending on the rotation of the crank shaft. Check the suction superheat and adjust the expansion valve for 10°F (-12°C) to 13°F (-11°C) of superheat. If proper superheat is obtained, sightglass foaming is not a concern.

For RCS/RFS applications in which the condensing section is remote from the air handling section, consideration should have been given to proper piping between the sections, as this can affect the compressor oil level. Refer to the “ASHRAE Handbooks” for more information on proper refrigeration piping design and installation.

R-407C Superheat

Due to refrigerant glide, when measuring and/or adjusting TEV superheat, it is important to use SATURATED VAPOR (Dew Point) TABLES. Example: The Pressure/Temperature (P/T) chart shows that the saturated vapor temperature, at the dew point, of R-407C for 79 psig is approximately 51°F. If the actual refrigerant temperature is 60°F, the superheat is 9°F.

Checking Superheat

Following are recommendations for checking superheat:

- 1 Close the unit section doors. Running the unit with its doors open will affect expansion valve and system operation considerably.
- 2 For units with one expansion valve per circuit, check the pressure and temperature at the compressor suction valve.
- 3 For units with multiple expansion valves per circuit, check the pressure at the compressor, and check the temperature at the suction header that is fed by the valve.

Check, Test, and Start Procedures

Heating System Start-up

General

- 1 At the keypad, set the heating setpoints high enough so that the controller will call for heating. The value in *Temperature \ Zone Heating \ Occ Htg Spt=* will need to be adjusted above the temperature shown in *Temperature \ Zone Heating \ Control Temp=*. In addition, on DAC units, the value in *Temperature \ Discharge Heating \ DAT Htg Spt=* will need to be adjusted above the temperature shown in *Temperature \ Discharge Heating \ Disch Air=*.
- 2 Place the unit into heating mode through the keypad menu *System Summary \ System \ Ctrl Mode= Heat Only*.
- 3 Verify that the high ambient heat lockout temperature setpoint, *Temperature \ Zone Heating \ OATHtg Lock=* is set above the current outside air temperature (shown in *System Summary \ Temperatures \ OA Temp=*).

Gas Furnace

Refer to the “Start-up and Operating Procedures” section of the Forced Draft Gas Fired Furnace Installation Manual, Bulletin No. IM 684 or 685. Perform the start-up procedures given in it.

Electric Heat

Turn the electric heat switch HS1 to ON. The electric heaters should energize. If the unit has multistage electric heat, the MicroTech III Auxiliary Control board EHB1 should energize the heaters in successive stages. The rate of staging is set in keypad menu *Setup/Service \ Heating Setup \ Stage Time=*. The default value of “5 min” can be adjusted from 2 to 60 minutes.

Steam Heat

The steam valve actuator should open the valve. The steam valve is open when the valve stem is up. If the unit loses power, the spring in the actuator should drive the valve wide open. Check this by opening system switch S1.

Hot Water Heat

The hot water valve actuator should open the valve to the coil. The three-way hot water valve is open to the coil when the valve stem is down. If the unit loses power, the spring in the actuator should drive the valve wide open to the coil. Check this by opening system switch S1.

Air Balancing

Air balancing should be performed by a qualified air balancing technician. Note that the supply fan motors are usually shipped

with variable pitch sheaves which are typically set at the low end of the drive’s fan rpm range. See “Mounting and Adjusting Motor Sheaves” on page 103. The return fan motors are usually shipped with fixed pitch sheaves.

WARNING

Moving machinery hazard. Can cause severe personal injury or death.
Do not use a mechanically driven tachometer to measure the speed of return fans on this fan arrangement. Use a strobe tachometer.

The following should be performed as part of the air balancing procedure:

- 1 Check the operating balance with the economizer dampers positioned for both full outdoor air and minimum outdoor air.
- 2 Verify that the total airflow will never be less than that required for operation of the electric heaters or gas furnace.
- 3 For VAV units that have fan tracking control, adjust the supply/return fan balance by using the MicroTech III controller’s built-in, automatic capability. For complete information on using this feature, see OM 920
- 4 When the final drive adjustments or changes are complete, check the current draw of the supply and return fan motors. The amperage must not exceed the service factor stamped on the motor nameplate.
- 5 Upon completion of the air balance, replace variable pitch motor sheaves (if any) with comparably sized fixed pitch sheaves. A fixed pitch sheave will reduce vibration and provide longer belt and bearing life.

WARNING


Rotating parts can cause severe personal injury or death. Replace all belt/fan guards that are temporarily removed for service.

Sheave Alignment

Mounting:

- 1 Verify both driving and driven sheaves are in alignment and the shafts are parallel. The center line of the driving sheave must be in line with the center line of the driven sheave. See Figure 119.
- 2 Verify that all setscrews are torqued to the values shown in Table 29 on page 113 before starting drive. Check setscrew torque and belt tension after 24 hours of service.

Figure 119: Sheave Alignment (Adjustable Shown)



Drive Belt Adjustment


General Rules of Tensioning

- 1 The ideal tension is the lowest tension at which the belt will not slip under peak load conditions.
- 2 Check tension frequently during the first 24 - 48 hours of operation.
- 3 Over tensioning shortens belt and bearing life.
- 4 Keep belts free from foreign material which may cause slippage.
- 5 Make V-drive inspection on a periodic basis. Adjust tension if the belt is slipping. Do not apply belt dressing. This may damage the belt and cause early failure.

Tension Measurement Procedure


- 1 Measure the belt span. See Figure 120.
- 2 Place belt tension checker squarely on one belt at the center of the belt span. Apply force to the checker, perpendicular to the belt span, until the belt deflection equals belt span distance divided by 64. Determine force applied while in this position.
- 3 Compare this force to the values on the drive kit label found on the fan housing.

Figure 120: Drive Belt Adjustment



Mounting and Adjusting Motor Sheaves

Figure 121: VM and VP Variable Pitch Sheaves



Check, Test, and Start Procedures

VM and VP Variable Pitch Sheaves

Mounting:

- 1 Mount all sheaves on the motor shaft with setscrew **A** toward the motor (see Figure 121).
- 2 Be sure both the driving and driven sheaves are in alignment and that the shafts are parallel.
- 3 Fit internal key **D** between sheave and shaft and lock setscrew **A** securely in place.

Adjusting:

- 1 Slack off all belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
- 2 Loosen setscrews **B** and **C** in the moving parts of the sheave and pull out external key **E** (see Figure 121). This key projects a small amount to provide a grip for removing.
- 3 Adjust the sheave pitch diameter for the desired fan speed by opening the moving parts by half or full turns from closed position. **Do not open more than five full turns for A belts or six full turns for B belts.** Adjust both halves of two-groove sheaves by the same number of turns from closed to ensure that both grooves have the same pitch diameter.
- 4 Replace external key **E** and securely tighten setscrews **B** over the key. Tighten setscrews **C** into the keyway in the fixed half of the sheave.
- 5 Put on belts and adjust the belt tension. **Do not force belts over grooves.** Loosen the belts by adjusting the motor base closer to the fan shaft.
- 6 Be sure that all keys are in place and that all setscrews are tight before starting the drive. Check the setscrews and belt tension after 24 hours of service.

LVP Variable Pitch Sheaves

Mounting:

- 1 For single-groove sheaves, slide the sheave onto the motor shaft so that the side of the sheave with setscrew **A** is next to the motor (see Figure 122 on page 106).
For two-groove sheaves, slide the sheave onto the motor shaft so that the side of the sheave with setscrew **A** is away from the motor (see Figure 122 on page 106).

- 2 To remove the flange and locking rings:
 - a Loosen setscrews **D**.
 - b Loosen **but do not remove** capscrews **E**.
 - c Remove key **F**. This key projects a small amount to provide a grip for removing.
 - d Rotate the flange counterclockwise until it disengages the threads on the shaft barrel.
- 3 Be sure that the driving and driven sheaves are in alignment and the shafts are parallel. When aligning two-groove sheaves, allow room between the sheave and motor to get to capscrews **E**.
- 4 Insert key **C** between the sheave and the shaft and tighten setscrew **A** securely.

Adjusting:

- 1 Slack off all belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
- 2 Loosen setscrews **D**.
- 3 Loosen **but do not remove** capscrews **E**.
- 4 Remove key **F**. This key projects a small amount to provide a grip for removing.
- 5 Adjust the pitch diameter by opening or closing the movable flange by half or full turns. Note that two-groove sheaves are supplied with both grooves set at the same pitch diameter. **Both movable flanges must be moved the same number of turns to ensure the same pitch diameter for satisfactory operation. Do not open sheaves more than five turns for A belts or six turns for B belts.**
- 6 Replace key **F**.
- 7 Tighten setscrews **D** and capscrews **E**.
- 8 Put on the belts and adjust the belt tension. Do not force belts over grooves. Loosen the belts by adjusting the motor base closer to the fan shaft.
- 9 Before starting the drive, make sure that all keys are in place and all setscrews and all capscrews are tight. Check and retighten all screws and re-tension the belts after approximately 24 hours of operation.

MVP Variable Pitch Sheaves

Adjusting:

- 1 Slack off belt tension by moving the motor toward the driven shaft until the belts are free from the grooves. For easiest adjustment, remove the belts.
- 2 Loosen both locking screws **A** in outer locking ring, **but do not remove** them from the sheave. There is a gap of approximately 1/2" (1 mm) between the inner and outer locking rings. This gap must be maintained for satisfactory locking of the sheave.
If locking screws **A** are removed by accident and the gap is lost, screw the outer locking ring down until it touches the inner locking ring. Then, back off the outer ring 1/2 to 3/4 turn until the inner and outer ring screw holes line up. Reinsert locking screws **A**, but do not tighten them until after adjustment is made.

- 3 Adjust the sheave to the desired pitch diameter by turning the outer locking ring with a spanner wrench. Any pitch diameter can be obtained within the sheave range. One complete turn of the outer locking ring will result in a 0.233" (6 mm) change in pitch diameter. **Do not open A-B sheaves more than four 3/4 turns for A belts or 6 turns for B belts. Do not open C sheaves more than nine 1/2 turns.**
- 4 Tighten both locking screws **A** in the outer locking ring.
- 5 Put on the belts and adjust the belt tension. **Do not force belts over grooves.** Loosen the belts by adjusting the motor base closer to the fan shaft.

CAUTION

Do not loosen any screws other than the two locking screws (A) in the outer locking ring. Before operating the drive, securely tighten these screws.

Check, Test, and Start Procedures

Figure 122: LVP Variable Pitch Sleeves




Figure 123: MVP Variable Pitch Sheaves (Type A-B)





Figure 124: MVP Variable Pitch Sheaves (Type A-B)



When all start-up procedures are completed, set the controls and program the MicroTech III controller for normal operation. Use the following list as a guide; some items may not apply to your unit. For more detail, see IM 919 and OM 920.

- 1 Turn system switch S1 to ON and S7 to AUTO.
 - 2 Turn gas furnace switch S3 to AUTO or turn electric heat switch HS1 to ON.
 - 3 Set the electromechanical (Honeywell H205) enthalpy control (OAE) as required (A, B, C, or D). Set the solid-state (Honeywell H705/C7400) enthalpy control (OAE/ RAE) past “D.”
 - 4 Set the heating and cooling parameters as required for normal unit operation:
 - a *Temperature \ Zone Cooling *
 - b *Temperature \ Zone Heating *
 - c *Temperature \ Discharge Cooling *
 - d *Temperature \ Discharge Heating *
 - 5 Set the low ambient compressor lockout setpoint as required in menu, *Temperature \ Zone Cooling \ OAT Clg Lock=*. Do not set it below 50°F (10°C) unless the unit is equipped for low ambient operation.
 - 6 Set the high ambient heat lockout temperature setpoint, *Temperature \ Zone Heating \ OAT Htg Lock=* as required.
 - 7 Set the alarm limits as required in *Setup/Service \ Alarm Limits *.
 - 8 Set the compressor lead/lag function as desired using keypad menu *Setup/Service \ Compressor Setup \ Lead Circuit=* and *Setup/Service \ Compressor Setup \ Comp Ctrl=*. Refer to “*Compressor Staging*” in Bulletins OM137 and OM138.
- Note:** If the unit has hot gas bypass on circuit #1 only, lead circuit must always be #1.
- 9 Set the duct static pressure control parameters as required in keypad menu *Airflow \ Duct Pressure *.
 - 10 Set the building static pressure control parameters as required in keypad menu *Airflow \ Bldg Pressure *.
 - 11 Set the fan tracking parameters as required in keypad menus *Setup/Service \ Fan Tracking Setup * and *Setup/Service \ Fan Balance *.
 - 12 Set the economizer control parameters as required in keypad menu *Temperature \ OA Damper *.
 - 13 Set the control timers as required in keypad menu *Setup/Service \ Timer Settings *.
 - 14 Set the date and time in keypad menu *Setup/Service \ Time/Date *.

- 15 Set the operating schedule as required using keypad menus.
Note: When used with a Building Automation System, these settings may need to be kept at the default of no schedule:
 - a *Schedules \ Daily Schedule *
 - b *Schedules \ Holiday Schedule *
- 16 Temporarily disconnect static pressure sensor tubing from sensors SPS1 and SPS2 (if installed) and place the unit into the calibrate mode by using the keypad menu *Setup/Service \ Unit Configuration \ Calibrate Mode=* and changing the value from NO to YES. The calibrate mode automatically zeroes all static pressure sensors and calibrates any actuator feedback pots connected to the MicroTech III controller. When the calibration is finished, the keypad menu *System Summary \ System \ Unit Status=* changes from “*Calib*” to “*Off Man.*”
- 17 To restart the unit, reconnect static pressure tubing and change keypad menu *System Summary \ System \ Ctrl Mode=* from OFF to AUTO.

Maintaining Control Parameter Records

McQuay recommends that the MicroTech III controller’s setpoints and parameters be recorded and saved for future reference. If the Microprocessor Control Board requires replacement, this record facilitates entering the unit’s proper data. The following tables display all the setpoints, monitoring points, and program variables offered by MicroTech III plus the keypad road map used to find each parameter.

A number of menus and menu items that appear on the unit keypad/display are conditional and may not apply to a specific unit, depending on the unit software configuration. The unit software configuration is defined by a “Software Configuration Code” shown on a label located near the keypad/display. The Software Configuration Code also can be displayed via the six menu items in the Config Code menu on the unit keypad/display. Refer to “Main Control Board (MCB) Configuration” in OM 920.

The shaded menus and menu items in Figure 126 on page 109 are conditional. A conditional menu or menu item includes a reference in Figure 126 to the position in the Software Configuration Code upon which its applicability depends. For example, the Duct Pressure menu in Figure 126 includes a notation [14=1 or 2]. This notation means that the Duct Pressure menu (and all its menu items) applies to the specific unit only if position 14 in its Software Configuration Code is a 1 or a 2. Otherwise, the menu or menu item is not applicable to the unit and does not affect its operation.

The items in Figure 126 include the factory-set value for all adjustable items. **Keep a record of any changes made to any of these items.**

Final Control Settings

Figure 125: Keypad Accessible Menu Structure





Figure 126: Keypad Accessible Menu Structure (Continued)

III Keypad Navigation



Standard Menus									
Economizer	Min OA Damper	Heating	Energy Recovery	Dehumidification	Daily Schedule	One Event Schedule	Holiday Schedule	Optimal Start	Operating Hours
Economizer Pos= XXX%	Min OA Pos= XXX%	Zone Htg Spt= 68.0°F	Energy Rcvy= Yes	Dehum Status=	Mon= 00:00-00:00	Beg= mm/dd@hh:mm	Hol 1= m/dly-m/dly	Enable= No	Supply Fan= XXXXXh
DAT Clg Spt= 55.0°F	Vent Limit= 20%	Unocc Htg Spt= 55.0°F	Wheel Speed= XXX%	Rel Humidity= XXX%	Tue= 00:00-00:00	End= mm/dd@hh:mm	Hol 2= m/dly-m/dly	Htg Rate= 0.4°F/min	Ret/Exh Fan= XXXXXh
Min OA Pos= XXX%	DCV Limit= 10%	DATMWUSpt= 70.0°F	Whl Spd Cmd= XXX%	Dewpoint= XXX°F	Wed= 00:00-00:00		Hol 3= m/dly-m/dly	Htg OAT= 35°F	Mech Cool= XXXXXh
Chgover Temp= 55.0°F	Min OA Reset= None	DAT Htg Spt= 100.0°F	ER DAT= XXX°F	Dehum Method= None	Thu= 00:00-00:00		Hol 4= m/dly-m/dly	Des Htg OAT= 0°F	Comp # 1= XXXXXh
EWT Diff= 3.0d°F	DesignFlow= Yes	Htg Reset= None	ER ExhT= XXX°F	RH Setpoint= 50%	Fri= 00:00-00:00		Hol 5= m/dly-m/dly	Clg Rate= 0.4°F/min	Comp # 2= XXXXXh
	OA @ MinV/mA= 0%	Min Htg Spt= 55.0°F	Min ExhT Diff= 2.0°F	Dewpoint Spt= 50°F	Sat= 00:00-00:00		Hol 6= m/dly-m/dly	Clg OAT= 85°F	Comp # 3= XXXXXh
	OA @ MaxV/mA= 100%	Min Htg Spt @ 0	Max ExhT Diff= 6.0°F	Reheat Spt= XXX°F	Sun= 00:00-00:00		Hol 7= m/dly-m/dly	Des Clg OAT= 95°F	Comp # 4= XXXXXh
	Min V/mA= 0.0V	Max Htg Spt= 120.0°F	Stage Time= 5min	Reheat Cap= XXX%	Hol= 00:00-00:00		Hol 8= m/dly-m/dly		Comp # 5= XXXXXh
	Max V/mA= 10.0V	Max Htg Spt @ 100	Min Off Time= 20min				Hol 9= m/dly-m/dly		Comp # 6= XXXXXh
	PPM@DCV/Lmt= 800PPM	Min DAT Ctr= Yes	Rel Humidity= XXX%				Hol 10= m/dly-m/dly		Comp # 7= XXXXXh
	PPM@Vnt/Lmt= 1000PPM	Min DAT Limit= 55.0°F							Comp # 8= XXXXXh
	PPM=	Occ Heating= Yes							Heating= XXXXXh
	Min PPM= 0 PPM								Economizer= XXXXXh
	Max PPM= 2000 PPM								Tnt Override= XXXXXh
	V/A @Min PPM= 0.0V								Dehum= XXXXXh
	V/A @Max PPM= 10.0V								ER Wheel= XXXXXh
	Min Fan Diff= 20%								
	Max Fan Diff= 50%								
	OA Flow=								
	MinOAFw Spt= 2000CFM								
	Min Clg Spd= 40%								
	LoFlo V Lmt= 30%								

Extended Menus									
Economizer Setup	Design Flow Setup	Heating Setup	Dehum Setup	Alarm Out Config	Alarm Limits	Manual Control	LON Setup	BACnet IP Setup	BACnetMSTP Setup
Econo DB= 2.0d°F	Des Flo DB= 3%	Htg DB= 2.0d°F	RH DB= 2%	Faults= Fast	Hi Disch Temp= 170°F	Manual Ctr= Normal	Rcv Hrt Bt= 30s	TBD	TBD
Econo Period= 30/40s (air/water)	DF Period= 30s	Htg Period= 60s	Dewpoint DB= 2d°F	Problems= Slow	Lo Disch Temp= 40°F	Supply Fan= Off	Snd Hrt Bt= 60s	TBD	TBD
	Des Flo Gain= 0.1	Htg Gain= 0.8	Reheat Period= 10s	Warnings= Off	Hi Return Temp= 120°F	RF/EF VFD= Off	N ID= XXXXXXXXXXXXX	TBD	TBD
Econo Gain= 10/1 (air/water)	DF Max Chg= 5%	Htg PAT= 120s	Reheat Gain= 1					TBD	TBD
	DesignFlow= Yes	Htg Max Chg= 10%	Reheat PAT= 10s					TBD	TBD
Econo PAT= 60/40s (air/water)	LH Lvl Pos= XXX.XX%	Stage Time= 5min	RH Max Chg= 16%					TBD	TBD
	RH Lvl Pos= XXX.XX%	OAT Htg Lock= 55.0°F	Dehum Method= None					TBD	TBD
Econo Max Chg= 10/15% (air/water)		OAT Diff= 2d°F	Dehum Ctr= Occupied						
		F&BP Method= OpenVlv	Sensor Loc= Return						
Flush Econo= Yes		F&BP ChgOvrT= 37°F	Mn Lvg Coil T= 48.0°F						
Econo Diff= 2d°F		Warmup Period= 240s	Mx Lvg Coil T= 55.0°F						
		Heat Up Delay= 60s	Min Rheat Spt= 55.0°F						
		Hold Period= 240s	Max Rheat Spt= 65.0°F						
			RH Sens Type= VDC						
			RH Min Signal= 0.0V						
			RH Max Signal= 10.0V						

Maintenance and Service

Installation and maintenance must be performed only by qualified personnel who are experienced with this type of equipment and familiar with local codes and regulations.

WARNING

Moving machinery and electrical power hazards. Can cause severe personal injury or death.
Disconnect and lock off all power before servicing equipment.

CAUTION

Sharp edges are inherent to sheet metal parts, screws, clips, and similar items. May cause personal injury.
Exercise caution when servicing equipment.

Servicing Control Panel Components

Disconnect all electric power to the unit when servicing control panel components. Before servicing, always inspect units for multiple disconnects to ensure all power is removed from the control panel and its components.

WARNING

Hazardous voltage. Can cause severe injury or death.
Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

Planned Maintenance

Preventive maintenance is the best way to avoid unnecessary expense and inconvenience. Have this system inspected at regular intervals by a qualified service technician. The required frequency of inspections depends upon the total operating time and the indoor and outdoor environmental conditions. Routine maintenance should cover the following items:

- Tighten all belts, wire connections, and setscrews.
- Clean the evaporator and condenser coils mechanically or with cold water, if necessary. Usually any fouling is only matted on the entering air face of the coil and can be removed by brushing.
- Lubricate the motor and fan shaft bearings.
- Align or replace the belts as needed.
- Clean or replace the filters as needed.
- Check each circuit's refrigerant sightglass when the circuit is operating under steady-state, full load conditions. The

sightglass should then be full and clear. If it is not, check for refrigerant leaks.

Note: A partially full sight glass is not uncommon at part load conditions.

- Check for proper superheat.
- Check for blockage of the condensate drain. Clean the condensate pan as needed.
- Check the power and control voltages.
- Check the running amperage of all motors.
- Check all operating temperatures and pressures.
- Check and adjust all temperature and pressure controls as needed.
- Check and adjust all damper linkages as needed.
- Check the operation of all safety controls.
- Examine the gas furnace (see Bulletin No. IM 684 or IM 685).
- Check the condenser fans and tighten their setscrews.
- Lubricate the door latch mechanisms.

Unit Storage

Location

The McQuay Rooftop Packaged System Unit is an outdoor unit. However, the schedule may dictate storage either on the ground or in its final position at the site. If the unit is stored on the ground, additional precautions should be taken as follows:

- Make sure that the unit is well supported along the length of the base rail.
- Make sure that the unit is level (no twists or uneven ground surface).
- Provide proper drainage around the unit to prevent flooding of the equipment.
- Provide adequate protection from vandalism, mechanical contact, etc. The condenser fins are particularly vulnerable to damage by even light contact with ground based objects.
- Make sure all doors are securely closed.
- If isolation dampers are provided, verify that they are properly installed and fully closed to prevent the entry of animals and debris through the supply and return air openings.
- Units without isolation dampers should be fitted with covers over the supply and return air openings.

Preparation

Supply (and Return) Fans

- 1 Move the motor base to check and lubricate slides and leadscrews.
- 2 Remove the drive belts, tag them with the fan name and unit serial number, and store them in a conditioned space out of direct sunlight.
- 3 Once every two weeks, rotate the fan and motor shafts. Mark the shaft positions first to make sure they stop in a different position.
- 4 Depending on local climatic conditions, condensate may collect on components inside the units. To prevent surface rust and discoloration, spray all bare metal parts with a rust preventive compound. Pay close attention to fan shafts, sheaves, bearings, and bearing supports,

Cabinet Sections

Once a month, open a door on each section and verify that no moisture or debris is accumulating in the unit.

Cooling Circuits

The steps below are necessary only if the unit has been started.

- 1 Provide that each circuit is properly pumped down.
- 2 Pull the fuses to each compressor (store them in the control cabinet)
- 3 Close all the refrigerant service valves on each circuit
- 4 Tag the valves as a warning for the technician who restarts the units

Gas Furnace

If the unit is equipped with a gas furnace, close the gas shutoff valve and open furnace control switch S3.

Control Compartment

- 1 McQuay International recommends that the electronic control equipment in the unit be stored in a 5% to 95% RH (non-condensing) environment.
- 2 It may be necessary to put a heat source (light bulb) in the main control panel to prevent the accumulation of atmospheric condensate within the panel.
- 3 The location and wattage of the heat source is dependent on local environmental conditions.
- 4 Check the control compartment every two weeks to provide that the heat source is functional and is adequate for current conditions.

Restart

After extended storage, perform a complete start up. Inevitable accumulations of dirt, insect nests, etc. can contribute to

problems if not cleaned out thoroughly prior to start up. In addition, thermal cycling tends to loosen mechanical and electrical connections. Following the startup procedure helps discover these and other issues that may have developed during the storage interval.

Gas Furnace

For information on maintenance of the gas furnace, refer to Bulletin No. IM 684 or IM 685.

Bearing Lubrication



Bearing overheating potential. Can damage the equipment. Do not overlubricate bearings. Use only a high grade mineral grease with a 200°F safe operating temperature. Refer to Table 23 on page 112 for specific recommended lubricants.

Motor Bearings

Supply and return fans—Supply and return fan motors should have grease added after every 2000 hours of operation. Use one of the greases shown in Table 22.

Table 22: Recommended Lubricants and Amounts for Fan Motor Bearings

Mfr. Grease	NEMA Size	Amount to Add (oz.)
Texaco,	56 to 140	0.08
Polystar	140	0.15
or	180	0.19
Polyrex EM	210	0.30
(Exxon Mobile)	250	0.47
or	280	0.61
Rykon	320	0.76
Premium #2	360	0.81
or	400	1.25
Penzoil Pen 2	440	2.12
Lube		

Using the following procedure, relubricate the bearings while the motor is warm, but not running.

- 1 Remove and clean upper and lower grease plugs.
- 2 Insert a grease fitting into the upper hole and add a small amount of clean grease (Table 22) with a low pressure gun.
- 3 Run the motor for five minutes before replacing the plugs.

Note: Specific greasing instructions are located on a tag attached to the motor. If special lubrication instructions are on the motor, they supersede all other instructions.

Condenser fan—Condenser fan motors are permanently lubricated and require no periodic lubrication.

Maintenance and Service

Fan Shaft Bearings

Any good quality lithium or lithium complex base grease, using mineral oil, conforming to NLGI grade 2 consistency, and an oil viscosity of 455-1135 SUS at 100°F (100-200 cSt at 40°C) may be used for relubrication.

Compatibility of grease is critical. Relubable Browning bearings are supplied with grease fittings or zerks for ease of lubrication with hand or automatic grease guns. Always wipe the fitting and grease nozzle clean.

CAUTION

For safety, stop rotating equipment and lockout/tagout the disconnects. Add one half of the recommended amount shown in Table 24. Start bearing, and run for a few minutes. Stop bearing and add the second half of the recommended amount. A temperature rise, sometimes 30°F (1°C), after relubrication is normal. Bearing should operate at temperature less than 200°F (94°C) and should not exceed 225°F (107°C) for intermittent operation. For a relubrication schedule, see Table 23. For any applications that are not in the ranges of the table, contact McQuay.

CAUTION

The tables below state general lubrication recommendations based on our experience and are intended as suggested or starting points only. For best results, specific applications should be monitored regularly and lubrication intervals and amounts adjusted accordingly.

Table 23: Relubrication Intervals

(Use NLGI #2 Lithium or Lithium Complex Grease)			
Speed	Temperature	Cleanliness	Relub. intervals
100 rpm	Up to 120°F (50°C)	Clean	6 to 12 months
500 rpm	Up to 150°F (65°C)	Clean	2 to 6 months
1000 rpm	Up to 210°F (100°C)	Clean	2 weeks to 2 months
1500 rpm	Over 210°F (100°C) to 250°F (120°C)	Clean	Weekly
Above 1500 rpm	Up to 150°F (65°C)	Dirty/wet	1 seek to 1 month
Max catalog rating	Over 150°F (65°C) to 250°F (120°C)	Dirty/wet	Daily to 2 weeks
	Above 250°F (120°C)		Contact Browning

Table 24: Recommended Fan Relubrication Grease Charge

Shaft Size (in)	OZ.	Shaft Size	Grams
1/2 to 3/4	0.03	20 mm	0.85
7/8 to 1-3/16	0.10	25-30 mm	2.84

Table 24: Recommended Fan Relubrication Grease Charge

1-1/4 to 1-1/2	0.15	35-40 mm	4.25
1-11/16 to 1-15/16	0.20	45-50 mm	5.67
2 to 2-7/16	0.30	55-60 mm	8.51
2-1/2 to 2-15/16	0.50	65-70 mm	15.59
3 to 3-7/16	0.85	75-80 mm	24.10
3-1/2 to 4	1.50	85-105 mm	42.53

Bearing Replacement

The following instructions must be read in entirety before attempting installation or removal. The procedures indicated should be carefully followed. Failure to do so can result in improper installation which could cause bearing performance problems as well as serious personal injury.

Bearings in Bolt-on Housings (Units)

- 1 Check area - Clean and organize bearing installation area and keep well lit. Be sure mounting surfaces are clean and flat.
- 2 Check shaft - Shaft should be within tolerance range shown in Table 25, clean, and free of nicks and burrs. Mount bearing on unused section of shafting or repair/replace shafting as required.

Table 25: Shaft Size Tolerances

Shaft Size (in)	Tolerance
1/2 to 1-7/16	+0 and -0.001
1-11/16 to 2-7/16	+0 to -0.0015
2-7/16 and up	+0 to -0.002

- 3 Install unit - Slide unit onto shaft. If it is difficult to mount bearing on shaft, use a piece of emery cloth to reduce any high spots on shaft. Do not hammer on any component of the bearing.
- 4 Fasten unit in place - Install housing mounting bolts, check and align bearing and tighten mounting bolts to recommended fastener torques. Exercising extreme caution and safety, rotate shaft slowly to center bearing.

Table 26: Recommended Lubricants for Fan Shaft Ball Bearings

Name	Temperature	Base	Thickener	NLGI grade
Texaco, Premium RB	30° to 350°F (34° to 177°C)	Parafinic mineral oil	Lithium	2
Mobile, AW2	40° to 437°F (40° to 175°C)	Mineral oil	Lithium	2
Mobile, SHC 100	68° to 356°F (50° to 180°C)	Synthetic	Lithium	2
Chevron, AltipleX Synthetic	60° to 450°F (51° to 232°C)	Synthetic	Lithium	2
Exxon, ronex MP	40° to 300°F (40° to 149°C)	Mineral oil	Lithium	2

Note: Temperature ranges over 225°F are shown for lubricants only. High temperature applications are not suitable for standard air handler components.

BOA Concentric Inserts

- 1 Be sure that BOA Concentric collar is fitted square and snug against the shoulder on the inner ring.
- 2 Torque BOA Concentric collar cap screw to torque recommended in Table 27.

Table 27: Recommended Torque Values for Concentric Locking Bearing/Shaft Size

Fan Size (in)	Bore Size (in)	Torx Screw Size	In lbs.
	1	T-25	70
	1-1/16	T-25	70
	1-3/16	T-25	70
15 (FC)/24 (FCL)	1-7/16	T-27	90
24 (FCM)/27 (FC)	1-11/16	T-27	90
20 (AF)/24 (AF)	1-15/16	T-30	180
27 (AF)/40 & 49 (SWSI)	2-3/16	T-30	180
30 & 33 (AF)/44 (SWSI)	2-7/16	T-45	400
36 (AF)	2-11/16	T-45	400
40 (AF)	2-15/16	T-45	400

Note: AF = DWDI AF, FCL = Low Pressure FC, FCM = Medium Pressure FC

Monitor Installed Bearing

After bearing has been run for several minutes, and again after several hours, check bearing for excessive noise or vibration. Shutdown machine and check housing temperature: typical applications operate at 100°F - 105°F (38°C - 66°C). Tighten all locking devices after 500 hours or 3 months, whichever comes first.

Propeller Exhaust

For information, see “Propeller Exhaust Fan Option” on page 94.

Vibration Levels

Each unit as shipped is trim balanced to operate smoothly. To provide satisfactory operation after shipping and installation, use accepted industry guidelines for field balancing fans. See Table 28.

Note: Excessive vibration from any cause contributes to premature fan and motor bearing failure. Monitor overall vibration levels every six months of operation. An increase in levels is an indication of potential trouble.

Table 28: Vibration Levels

Fan speed (RPM)	Vibration
800 or less	5 mils maximum displacement
801 or greater	0.20 in/sec maximum velocity

Vibration Causes

- 1 Wheel imbalance.
 - a Dirt or debris on wheel blades.
 - b Loose setscrews in wheel hub or bearing-to-shaft.
 - c Wheel distorted from overspeed.
- 2 Bent shaft.
- 3 Faulty drive.
 - a Variable pitch sheaves—Axial and radial runout of flanges; uneven groove spacing; out of balance. Also similar faults in driven sheave.
 - b Bad V-belts; lumpy, or mismatched; belt tension too tight or too loose.
- 4 Bad bearings, loose bearing hold-down bolts.
- 5 Motor imbalance.
- 6 Fan section not supported evenly on foundation.

Periodic Service and Maintenance

- 1 Check all moving parts for wear every six months.
- 2 Check bearing collar, sheave, wheel hub setscrews, sheave capscrews, and bearing hold-down bolts for tightness every six months.

Setscrews

Setscrews are used to lock bearings, sheaves, locking collars, and fan wheels to their shafts. They must be checked periodically to see that they have not loosened. If this is not done, severe equipment damage could occur.

Refer to Table 29 and check the tightness of all setscrews with a torque wrench. Note that if the return fan bearings setscrews must be retightened, a special procedure is required to equally load both bearings (see “Return Fan Bearing Setscrews” below).

Table 29: Setscrew Minimum Torque Specifications

Setscrew diameter (in.)	Minimum torque (ft.lb)
1/4	5.5
5/16	10.5
3/8	19.0
7/16	29.0
1/2	42.0
5/8	92.0


Maintenance and Service

Return Fan Bearing Setscrews

Because the return fan is mounted on a vertical shaft, the following procedure must be used to retighten any return fan bearing setscrews that have loosened. This procedure will provide that both bearings are equally loaded. If one bearing is carrying the entire weight of the fan, it could fail prematurely.

- 1 Loosen the fan belts.
- 2 Support the weight of the fan and the fan shaft with timbers or some other suitable means (see the fan shaft support in Figure 127). **Important:** To maintain proper drive alignment and fan-to-tunnel clearance, the fan and shaft must not drop at all when the setscrews are loosened in Step 4.
- 3 Verify that the upper shaft collar is securely fastened to the shaft. Check the setscrew torque.
- 4 Loosen the upper and lower bearing setscrews. The entire weight of the fan and shaft is now supported by the fan shaft support.
- 5 Retighten all bearing setscrews to the torque specification given in Table 29. Remove the fan shaft support and re-tension the belts.

Figure 127: Return Fan Assembly



Supply Fan Wheel-to-Funnel Alignment

If the unit is equipped with an airfoil or backward curved supply fan, the fan wheel-to-funnel alignment must be as shown in Figure 128, Figure 129, Figure 131, and Figure 132 to obtain proper air delivery and operating clearance. If necessary, adjustments are made as follows:

- 1 Verify that the fan shaft has not moved in its bearings.
- 2 Loosen the fan hub setscrews and move the wheel(s) along the shaft as necessary to obtain the correct dimension shown in Table 30, Table 31, and Table 32.

- 3 Retighten the setscrews to the torque specification given in Table 29 on page 113. Tighten the setscrews over the keyway first; tighten those at 90 degrees to the keyway last.
- 4 Verify that the radial clearance around the fan is uniform. Radial clearance can be adjusted by slightly loosening the funnel hold-down fasteners, shifting the funnel as required, and retightening the fasteners.

Figure 128: 20" DWDI Airfoil Wheel-to-Funnel (015C to 030C)




Figure 129: 24" DWDI Backward Curved Wheel-to-Funnel (036C, 040C)




Figure 130: 27 to 40" DWDI Airfoil Wheel-to-Funnel Alignment




Table 30: 27 to 40" DWDI Airfoil Wheel-to-Funnel Relationship

Wheel-to-funnel relationship (in inches)	
Wheel diameter (inches)	"A" +0.3/ - 0.0
27	9.9 (246 mm)
30	10.6 (269 mm)
33	11.7 (297 mm)
36	13.1 (333 mm)
40	14.5 (368 mm)

Figure 131: 40" SWSI Airfoil Wheel-to-Funnel Alignment (RDT 045 to 075)




Table 31: SWSI Airfoil Wheel-to-Funnel Relationship

Wheel-to-funnel relationship (in inches)	
Wheel diameter	"A"
40	0.62

Figure 132: 44" and 49" SWSI airfoil Wheel-to-Funnel Alignment




Table 32: 44" and 49" SWSI Airfoil Wheel-to-Funnel Relationship

Wheel-to-funnel relationship (in inches)	
Wheel diameter	"A"
44	16.21
49	17.81

Refrigerant Leaks

R-407C is a zeotropic blend of three HFC refrigerants (R-32, R-125, and R-134a). Zeotropic blends do not behave as one substance. Therefore, a change of phase does not occur at a fixed temperature. R-407C has a "glide" of 8°F because it boils and evaporates over an 8°F change in temperature.

If an R-407C unit leaks refrigerant, there is no way to determine how much of each of the three component refrigerants leaked. However, experience in the field has shown that **R-407C systems can be "topped off" after a leak and will operate normally.** There is no need, except in the

case of critically charged systems, to replace the entire charge after a leak.

Add charge per instructions on page 46.

Refrigerant Charge

The unit nameplate references proper charge for each RPS/RDT refrigerant circuit in case a full charge must be added to the unit. Verify these values using pages 42–45. Refer to pages 42–45 for RFS/RCS units.

WARNING

Potential severe loss of charge may occur if the high refrigerant pressure switch is replaced before reclaiming the refrigerant. Replace switch after reclaiming refrigerant.

Servicing Refrigerant Sensors or Switches

The McQuay Rooftop unit includes the following refrigerant sensors or switches.

- 1 Low refrigerant pressure sensing, operating switch, automatic reset.
 - a Disables their associated compressors on a drop in suction pressure to approximately 35 psig.
 - b Enables their associated compressors on a rise in suction pressure to approximately 60 psig.
- 2 SpeedTrol™ high refrigerant pressure sensor (not available on sizes 15 to 30), see page 87 for more information.
- 3 High refrigerant pressure, protective switch, manual reset, reset by breaking control power to the S1 control switch.
 - a R-407C high pressure switches disable their associated compressors on a rise to 425 psig discharge pressure.
 - b The switches have a differential of 100 psig.

The low pressure and SpeedTrol sensors/ switches sense refrigerant pressure through schrader fittings that contain cores. The cores are stop valves that do not allow refrigerant to flow through the schrader unless the device is in place. Therefore the low pressure and SpeedTrol sensors/switches can be replaced without reclaiming the refrigerant.

The Schrader that serves the high pressure switch does not contain a core in order to maximize the functionality of the safety. Therefore it cannot be replaced unless the refrigerant has already been reclaimed.

Maintenance and Service

Winterizing Water Coils

Coil freeze-up can be caused by such things as air stratification and failure of outdoor dampers and/or preheat coils. Routine draining of water cooling coils for winter shutdown cannot be depended upon as insurance against freeze-up. Severe coil damage may result. It is recommended that all coils be drained as thoroughly as possible and then treated in the following manner.

- Fill each coil independently with an antifreeze solution using a small circulating pump and again thoroughly drain.
- Check freezing point of antifreeze before proceeding to next coil. Due to a small amount of water always remaining in each coil, there will be a diluting effect. The small amount of antifreeze solution remaining in the coil must always be concentrated enough to prevent freeze-up.

Note: Carefully read instructions for mixing antifreeze solution used. Some products have a higher freezing point in their natural state than when mixed with water.

Control Panel Components

Manual Motor Protector (MMP)

The manual motor protector (MMP) provides coordinated branch circuit, short circuit protection, a disconnecting means, a motor controller, and coordinated motor overload protection. A short circuit indicator with manual reset is mounted along side of each MMP as a means to differentiate between a short circuit and overload trip conditions.

The MMP trip points are factory set. Do not change unless the motor ampacity changes or the MMP is replaced with a new device with incorrect setpoint adjustment. Any other non-authorized trip point or setpoint adjustment voids all or portions of the unit's warranty. Authorized setpoint adjustment is accomplished as follows

- 1 For motors with a 1.15 service factor, rotate the arrow on the dial to correspond to the motor FLA (see Figure 133).
- 2 For motors with a 1.0 service factor, multiply the motor FLA by 0.9; then rotate the arrow on the dial to correspond to that value.

To reset a tripped MMP, clear the trip by rotating the knob counterclockwise to the OFF position; then rotate knob clockwise to the ON position (see Figure 133).

WARNING

If an overload or a fault current interruption occurs, check circuits to determine the cause of the interruption. If a fault condition exits, examine the controller. If damaged, replace it to reduce the risk of fire or electrical shock.

Other MMP features:

- Three-position rotary operator: OFF-TRIP-ON (see Figure 133).
- Lockout—tagoutable rotary operator: turn the rotary operator to the OFF position (o), slide out the extension arm, and insert a lockout pin.
- Ambient compensated -20°C to $+40^{\circ}\text{C}$.
- Single-phase sensitivity: if one phase exceeds setpoint, all three phases open.
- Trip test: insert a 9/64" screw driver in the test slot to simulate a trip (see Figure 133).

Figure 133: Manual Motor Protector



Circuit Breaker

Circuit breakers are installed upstream of all VFDs to provide short circuit protection. These breakers are not adjustable.

To reset a tripped circuit breaker: Clear the trip by rotating the lever down to the OFF position (see Figure 134). Then rotate lever up to the ON position (see Figure 134).

Breakers, like MMPs, have three distinct modes of operation which are clearly indicated by the handle position. The positions are ON (usually up), OFF (usually down), and TRIPPED (midway). Some circuit breakers may have a push-to-test button.

Reset After Tripping Information

⚠ CAUTION

If a circuit breaker has tripped due to an overload or a fault current (short circuit), prior to resetting, the connected wiring circuits must be checked to determine the cause of the interruption.

If a breaker is tripped, the handle/lever will be halfway between the OFF and ON positions. To reset a tripped circuit breaker:

- 1 Press the handle or rotate the lever to the OFF position.
- 2 Press the handle or rotate the lever the opposite direction to the ON position.

⚠ WARNING

In certain applications the circuit breaker may be mounted upside down. Therefore, when the handle is in the DOWN position it may not be turned OFF. The handle position corresponds to ON and OFF text clearly printed on the face of the unit. Be sure the mounting orientation and desired handle position is verified prior to performing service on the equipment. Only qualified service personnel should work on this equipment. Improper position of the breaker handle during service may result in electric shock or death.

Figure 134: Circuit Breaker



Disconnect

⚠ DANGER

Hazardous voltage. Will cause severe injury or death. Disconnect electric power before servicing equipment. More than one disconnect may be required to de-energize the unit.

The optional disconnect is a “through-the-door” molded case switch with similar features of the circuit breaker. The “through-the-door” feature provides a safety interlock that disables power when an inexperienced person opens the control panel door. **This is not the normal recommended method to access the control panel or to disable power to an operating unit.**

⚠ CAUTION

Molded case switches do not provide over-current protection. This device may automatically open the circuit at levels above the ampere rating of the switch.

Depending on the desired operating state of the unit, four different recommended methods can be utilized to access the control panel or to disable power.

- 1 Recommended method to access the controls through the “release” method (defeats the mechanical interlock and allows the control panel door to open without disconnecting power - switch is in the power “On” position):
 - a Obtain a small standard head screwdriver.
 - b Insert the head of the screwdriver into the slotted “release” located on the right hand side of the disconnect faceplate (Figure 135). Turn the release counter-clockwise.
 - c Pull open the door after the mechanical interlock is released.
- 2 Recommended normal method to turn off an operating unit (no emergency condition present):
 - a Follow the “release” method described above.
 - b Use the pump down switch to turn off the unit.
 - c The controls will then shut the liquid line solenoids, pump the refrigerant into the condenser, and turn off the compressors.
- 3 Recommended method to “lock off” power while the disconnect is off:
 - a Rotate the handle to the “Reset Lock” position.
 - b Manually push in the lockout mechanism into the slot on the faceplate.
 - c Insert a padlock into the lockout hole located on the disconnect handle.
 - d Test rotate the handle to insure that power “lockout” is provided.

Maintenance and Service

- 4 Recommended normal method to “restore” power to a unit that is locked out:
 - a Unlock and remove the padlock when it is safe (doors are shut, no personnel are within reach of the condensing unit or are inside the air handler).
 - b Shut the control panel door and ensure the interlock mechanism is operable.
 - c Rotate the handle to the “On” position.

Figure 135: Through-the-Door Handle Disconnect




Terminals

The terminals are spring clamp type. They only require inserting (see #1 in Figure 136) and clamping the wire to be stripped, which offers several advantages over screw terminals. The clamping is done by inserting a flat-bladed screw driver (up to 9/64" wide). See #2 in Figure 136.

- Spring connection does not require torquing and resists vibration
- Easily identifiable terminal markers
- Built-in test ports on each terminal, up to 2.3 mm diameter (see #3 in Figure 136).

Figure 136: Terminal Connectors




Phase Voltage Monitor (PVM)

The phase voltage monitor (see page 86) is designed to protect three-phase loads from damaging power conditions. A microprocessor-based voltage and phase sensing circuit constantly monitors the three-phase voltages to detect harmful power line conditions. When a harmful condition is detected, its output relay is deactivated after a specified trip delay (Trip Delay). The output relay reactivates after power line conditions return to an acceptable level for a specified amount of time (Restart Delay). The trip and restart delays prevent nuisance tripping due to rapidly fluctuating power line conditions.

Other features:

- LED display to indicate status (see #1 in Figure 137)
 - Loss of phase
 - High or low voltage
 - Voltage unbalance
 - Phase reversal
 - Rapid cycling
- Standard 1 to 500 second variable restart delay (see #2 in Figure 137)
- Standard 2% to 8% variable voltage unbalance (see #3 in Figure 137)
- Standard 1 to 30 second trip delay (see #4 in Figure 137)

Figure 137: Phase Voltage Monitor



Pressure Sensors

The MicroTech III controller uses 0 to 5" W.C. static pressure transducers for measuring duct static pressure. As the duct static pressure varies from 0-5" W.C., the transducer output will vary from 4-20mA. The transducer output signal is 4-20mA however the signal entering the VFD is converted to a DC signal via a 500 Ohm resistor across the output signal at the transducer.

If building static pressure control is provided, a -0.25" W.C. to 0.25" W.C. static pressure transducer is used. As the building static pressure varies from -0.25" W.C. to 0.25" W.C., the transducer output will vary from 4-20mA. The transducer output signal is 4-20mA however the signal entering the VFD is converted to a DC signal via a 500 Ohm resistor across the output signal at the transducer.

Troubleshooting Pressure Transducers

Use the following procedure to troubleshoot a suspect sensor:

If the duct static pressure always reads 0" WC on the unit keypad/display and the VFD speed is continuously ramping to 100%, check the following:

If the unit has two duct static pressure sensors (SPS1 and SPS2), verify that they both function properly per the following procedure. Also check for faulty wiring connections at the VFD analog inputs.

The controller displays and controls to the lower of the two readings. If a sensor is defective and inputs 0 volts to the VFD, the static pressure reading on the keypad/display reads 0 and the controller attempts to increase the 0 value to set point by ramping the VFD up.

If a second sensor (SPS2) is not installed or the pressure tubing to it is not connected, make sure the 2nd DSP Sensor= parameter in the Unit Configuration menu of the keypad/

display is set to "No" so that the controller ignores the second static pressure analog input.

If a second sensor (SPS2) is installed, make sure the 2nd DSP Sensor= parameter in the Unit Configuration menu of the keypad/display is set to "Yes."

Check the 24 VDC power supply to the sensor, verify that there is 24 VDC between the suspect transducer "+" and "-" terminals.

Using an accurate manometer or gauge, measure the same pressure that the suspect transducer is sensing. To do this, tap into the transducer high and low pressure tubing or locate the measurement device taps next to the transducer taps.

If the suspect sensor is measuring duct static pressure, verify that the high and low pressure taps are properly installed. An improper pressure tap installation can cause severe fluctuations in the sensed pressure. Refer to the model-specific installation manual for pressure tap installation guidelines.

Measure the DC voltage output from the transducer across the sensor "S" and "-" terminals.

If the measured voltage and pressure do not match, there may be a wiring problem, the factory 500 ohm resistor across "S" and "-" or the transducer may be defective. Check the transducer input circuit wiring and connections for defects. If the measured voltage and pressure match, the VFD parameters and/or ModBus communication between the controller and the VFD will need to be verified.

Remove powers from the controller by opening system switch S1. If available, swap a similar good transducer with the suspect transducer or try installing a new transducer. Restore power by closing S1 and verify whether the suspect transducer is defective.

Replacement Parts List

Component designation	Description	McQuay part number
MCB	Main Control Board	060006101
CCB1	Auxiliary Cooling Control Board (DX Circuit #1 or generic condenser)	112026101 (replaces 106102701)
CCB2	Auxiliary Cooling Control Board (DX Circuit #2)	112026101 (replaces 106102701)
EHB1	Auxiliary Electric Heat Control Board	112026101 (replaces 106102701)
ERB1	Auxiliary Energy Recovery Control Board	112026101 (replaces 106102801)
–	RS-485 Communication Module (for Auxiliary Control Boards)	060006202
–	Standoffs for mounting RS-485 Communication Module (PN 060006206) onto Auxiliary Control Board (PN 112026101)	048166707
–	Keypad/Display	060006301
–	Keypad-Main Control Board Cable	111044601
ZNT1	Zone Temperature Sensor with Tenant Override	111048101
	Zone Temperature Sensor with Tenant Override & Remote Setpoint Adjustment (SCC units only)	111048102
DAT	Discharge Air Temperature Sensor (50 ft cable length-field cut to length)	060004705
EFT	Entering Fan Air Temperature Sensor (50 ft cable length-field cut to length)	060004705
OAT	Outside Air Temperature Sensor (50 ft cable length-field cut to length)	060004705
RAT	Return Air Temperature Sensor (50 ft cable length-field cut to length)	060004705
SPS1	Static Pressure Sensor: Duct, No. 1	049545007
SPS2	Static Pressure Sensor: Duct, No. 2	049545007
	Static Pressure Sensor: Building (Space) Pressure	049545006
T2	Transformer: 115/24 V (ac)	060004601
T3	Transformer: 115/24 V (ac)	060004601
T9	Transformer: 115/24 V (ac)	060630801
HUM1	Humidity Sensor: Wall Mount	067294901
	Humidity Sensor: Duct Mount	067295001
PC5	Dirty Filter Switch: First Filter Section	065493801
PC6	Dirty Filter Switch: Final Filter Section	065493801
PC7	Airflow Proving Switch	060015801
DHL	Duct High Limit Switch	065493801
OAE	Enthalpy Control: Electromechanical	030706702
	Enthalpy Control: Electronic (Used with RAE)	049262201
RAE	Return Air Enthalpy Sensor (Used with Electronic OAE)	049262202
SD1	Smoke Detector: Supply Air	049025001
SD2	Smoke Detector: Return Air	049025001
–	BACnet MS/TP Communication Module (RS485)	060006202
–	BACnet/IP Communication Module (Ethernet Cable 10BASET)	060006201
–	LonMark Space Comfort Controller (SCC) Communication Module	060006203
–	LonMark Discharge Air Controller (DAC) Communication Module	060006204
–	5 V (dc) Power Supply	111049601
–	Serial Port Ribbon	111047201
–	MCB Battery	BR2325
–	MCB Connector Repair Kit	300036605
–	Power Disconnect Switch	033696300
–	18 in. Lamp Holder	205484001
–	24 in. Lamp Holder	205484101
–	36 in. Lamp Holder	205484201
–	Hard Wire Module	205485501
–	18 in. Lamp	205484501
–	24 in. Lamp	205484601
–	36 in. Lamp	205484701

Replacement Parts

When writing to McQuay for service or replacement parts, provide the model number, serial number, and unit part number of the unit as stamped on the serial plate attached to the unit. For questions regarding wiring diagrams, it will be necessary to provide the number on the specific diagram. If replacement parts are required, include the date of unit installation, the date of failure, an explanation of the malfunction, and a description of the replacement parts required.

Compressor Arrangements

McQuay Rooftops use the following Copeland Scroll Compressors.

- 1 Single compressors, one per refrigerant circuit.
- 2 Tandem compressors, basically two compressors specifically manufactured by Copeland into a single assembly.
- 3 Trio compressors, basically three single compressors factory piped in parallel with equalization lines.

All McQuay Rooftop products include a first-year parts only warranty. The warranty period extends 12 months from startup or 18 months from date of shipment, whichever comes first. Labor to install these parts is not included with this warranty. Compressors are considered a part and are included in this standard warranty.

Scroll service replacement compressors for McQuay Rooftop Units can be obtained from the following two sources:

- McQuay Service Parts maintains a stock of replacement compressors.
- Copeland Refrigeration has stocking wholesalers throughout the U.S. who maintain a limited stock of replacement scroll

compressors. The stock of single compressors is much better than the stock of tandems “tandem/trio ready”, single compressors. Trios are almost never in wholesaler stock and are not recommended for use on McQuay Rooftops due to piping interference. Copeland does offer quick ship options though their wholesalers.

Both sources can be used, at the customer’s discretion, within the first year warranty and with the following limitations.

- 1 RPS 018C to 020C (with single compressors, no limitations).
- 2 RPS 025C to 030C (with single and tandem compressors).
 - a If any part of the tandem fails then the entire tandem must be replaced. Both sources are acceptable.
 - b Single compressor. No limitations.
- 3 RPS 036C (with tandem compressors).
 - a Circuit #1 tandem - If any part of the tandem fails then the entire tandem must be replaced. Both sources are acceptable.
 - b Circuit #2 tandem—Each of the tandem’s compressors have a rotalock and only the failed portion of the tandem may need replacement.
- 4 RPS 040C to 060C—Each of the tandem’s compressors have a rotalock and only the failed portion of the tandem may need replacement.
- 5 RPS 070C to 105C—Each of the trio compressors have a rotalock and only the failed portion of the trio may need replacement.
- 6 Only a “tandem or trio ready” compressor, with oil equalizer lines, can be used to replace a portion of the tandem or trio.

Service and Warranty Procedure

Replacing Portions of a Tandem or Trio Compressor

The decision to replace the failed portion of the tandem or trio, as opposed to replacing the entire tandem or trio, must be decided based on the following.

- 1 The entire tandem must be replaced if the individual portions do not include rotalocks and rotalocks are not available on the RPS 025 to 030 (tandems and the RPS circuit #1 tandem).
- 2 In warranty: Warranty only covers replacement of the failed portion of the tandem or trio. Either source may be used.
- 3 Out of warranty: The customer decides whether to replace the entire tandem/trio or just a portion and either source may be used.

When replacing an “in warranty” compressor through a Copeland Wholesaler, take the failed compressor to the wholesaler for an over-the-counter or an advanced replacement exchange. Credit is issued by Copeland on the returned motor compressor upon receipt and factory inspection of the inoperative motor compressor. In this transaction, be certain that the motor compressor is definitely defective. If a motor compressor is received from the field that tests satisfactorily, a service charge plus a transportation charge will be charged against its original credit value.

If there was a delay in the startup of the equipment and the first-year warranty (Copeland) has expired on the compressor, within the 18-month-from-shipment warranty, order the replacement compressor through the McQuay Parts Department (Minneapolis).

- 1 Contact the McQuay Parts Department for compressor availability.
- 2 Send a completed parts order form to the McQuay Parts Department.
- 3 The Parts Department processes the order and the compressors are shipped from our Dayton, OH warehouse via ground transportation. If next-day air is required, indicate this on the parts order form and a freight charge will be billed to your account. Air freight costs are not covered under the McQuay warranty.
- 4 After the failed compressor is replaced, return it to McQuay International with a Return Goods Tag attached, which you will receive in the mail. It must be attached to the compressor. The Return Goods Tag has instructions on where to send the compressor. If the compressor is not returned, you will be billed for the replacement compressor.

- 5 Consideration may be given at this time to a compressor teardown analysis, depending on the history of failures.

On McQuay equipment that includes the extended 2nd -5th year compressor warranty option, the replacement compressor must be ordered through the McQuay Parts Department (Minneapolis).

- 1 Contact the McQuay Parts Department for compressor availability.
- 2 Send the McQuay Parts Department a completed parts order form.
- 3 The Parts Department will process the order and the compressors will be shipped from our Dayton, OH warehouse via ground transportation. If next-day air is required, you will need to indicate this on the parts order form and a freight charge will be billed to your account. Air freight costs are not covered under the McQuay warranty.
- 4 After the failed compressor has been replaced, it must be returned to McQuay International with a Return Goods Tag attached. You will receive the tag in the mail and it must be attached to the compressor. The Return Goods Tag will have instructions on where to send the compressor. If the compressor is not returned, you will be billed for the replacement compressor.
- 5 Consideration may be given at this time to a compressor teardown analysis, depending on the history of failures.

In-Warranty Return Material Procedure

Material other than compressors may not be returned except by permission of authorized factory service personnel of McQuay International at Minneapolis, Minnesota.

A “return goods” tag will be sent to be included with the returned material. Enter the information as called for on the tag in order to expedite handling at our factories and issuance of credits. All parts shall be returned to the factory designated on the return goods tag, transportation charges prepaid.

The return of the part does not constitute an order for replacement. A purchase order for the replacement part must be entered through your nearest McQuay representative. The order should include the component's part number and description and the model and serial numbers of the unit involved.

If it is determined that the failure of the returned part is due to faulty material or workmanship within the standard warranty period, credit will be issued on the customer's purchase order.

Limited Product Warranty (North America)

McQuay International (“Company”) warrants to contractor, purchaser and any owner of the product (collectively “Owner”) that Company, at its option, will repair or replace defective parts in the event any product manufactured by Company, including products sold under the brand names McQuay Air Conditioning, AAF Air Conditioning, AAF HermanNelson and McQuay Service, and used in the United States or Canada, proves defective in material or workmanship within twelve (12) months from initial startup or eighteen (18) months from the date shipped by Company, whichever occurs first. Authorized replaced parts are warranted for the duration of the original warranty. All shipments of such parts will be made FOB factory, freight prepaid and allowed. Company reserves the right to select carrier and method of shipment.

In addition, labor to repair or replace warranty parts is provided during Company normal working hours on products with rotary screw compressors, centrifugal compressors and on absorption chillers. Warranty labor is not provided for any other products.

Company’s liability to Owner under this warranty shall not exceed the lesser of the cost of correcting defects in the products sold or the original purchase price of the products.

PRODUCT STARTUP ON ABSORPTION, CENTRIFUGAL AND SCREW COMPRESSOR PRODUCTS IS MANDATORY and must be performed by McQuay Service or a Company authorized service representative.

It is Owner’s responsibility to complete and return the Registration and Startup Forms accompanying the product to Company within ten (10) days of original startup. If this is not done, the ship date and the startup date will be deemed the same for warranty period determination, and this warranty shall expire twelve (12) months from that date.

Exceptions

- 1 If free warranty labor is available as set forth above, such free labor does not include diagnostic visits, inspections, travel time and related expenses, or unusual access time or costs required by product location.
- 2 Refrigerants, fluids, oils and expendable items such as filters are not covered by this warranty.

- 3 This warranty shall not apply to products or parts which (a) have been opened, disassembled, repaired, or altered by anyone other than Company or its authorized service representative; or (b) have been subjected to misuse, negligence, accidents, damage, or abnormal use or service; or (c) have been operated, installed, or startup has been provided in a manner contrary to Company’s printed instructions, or (d) were manufactured or furnished by others and which are not an integral part of a product manufactured by Company; or (e) have not been fully paid for by Owner.

Assistance

To obtain assistance or information regarding this warranty, please contact your local sales representative or McQuay Service office.

Sole Remedy

THIS WARRANTY CONSTITUTES THE OWNER’S SOLE REMEDY. IT IS GIVEN IN LIEU OF ALL OTHER WARRANTIES. THERE IS NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT AND UNDER NO CIRCUMSTANCE SHALL COMPANY BE LIABLE FOR INCIDENTAL, INDIRECT, SPECIAL, CONTINGENT OR CONSEQUENTIAL DAMAGES, WHETHER THE THEORY BE BREACH OF THIS OR ANY OTHER WARRANTY, NEGLIGENCE OR STRICT LIABILITY IN TORT.

No person (including any agent, sales representative, dealer or distributor) has the authority to expand the Company’s obligation beyond the terms of this express warranty or to state that the performance of the product is other than that published by Company.

For additional consideration, Company will provide an extended warranty(ies) on certain products or components thereof. The terms of the extended warranty(ies) are shown on a separate extended warranty statement.

Rooftop Equipment Warranty Regist. Form

Warranty Registration Form (continued)

VI. GAS & OIL BURNER CHECK, TEST, & START

Specifications:

For gas, see *Forced Draft Gas Burner Installation and Maintenance Bulletin*.

For oil, see *Oil Fired Furnace Installation and Maintenance Bulletin*.

- A. (Gas/Oil) Furnace model no.
- B. (Gas/Oil) Burner model no. Serial no. _____
- C. (Gas) Type firing: Single Stage two Stage modulation
- D. (Oil) Type firing start: Full fire start Low fire start
- E. (Gas) Rated firing rate: MBH input
- F. (Oil) Rated firing rate: GPH, #2 fuel oil
- G. (Gas/Oil) Altitude:ft. above sea level
- H. Is there a circulating tank? Yes No N/A

VII. GAS BURNER CHECK, TEST, & START

- A. Input:CFH
- B. Gas pressure at burner:inches wc
- C. CO₂:%
- D. CO₂:%
- E. Pilot flame only:microamps (steady at low fire)
- F. Pilot Tap-gas pressure:inches wc
- G. Motor only/burner: FLA running amps
- H. High limit control OK? Yes No N/A
- I. Flame safeguard: microamps
- J. Flame failure shutoff: seconds
- K. Airswitch OK? Yes No N/A
- L. High Gas Pressure Switch OK? Yes No N/A
- M. Low Gas Pressure Switch OK? Yes No N/A
- N. Main Gas Valve Close-off OK? Yes No N/A

VIII. OIL BURNER CHECK, TEST & START

- A. Nozzle(s): Type/manufacturer GPH Angle Pattern manufacturer
- B. Nozzle pressure: psi
- C. CO₂:%
- D. Smoke spot: number
- E. Running ampsFLA
- F. Flame safeguard: microamps
- G. High limit control OK? Yes No N/A
- H. Flame failure shutoff OK? Yes No N/A
- I. Ignition failure check OK? Yes No N/A

IX. Have all electronic or electrical controls been checked, adjusted, and tested for proper operation per the installation and maintenance bulletins? Yes No N/A

X. MAINTAINING MICROTECH CONTROL PARAMETER RECORDS

After the unit is checked, tested, and started and the final control parameters are set, record the final settings. Keep these records on file and update whenever changes to the control parameters are made. Keeping a record facilitates any required analysis and troubleshooting of the system operation and facilitates restoration after a controller replacement.

Signature:

Startup date:

RETURN COMPLETED FORM TO:

McQuay International Warranty Department, 13600 Industrial Park Boulevard, Minneapolis, MN 55441

Please list any additional comments that could affect the operation of this unit; e.g., shipping damage, failed components, adverse installation applications, etc., on a separate sheet and attach to this form.

Quality Assurance Survey Report

Quality Assurance Survey Report

To whom it may concern:

Please review the items below upon receiving and installing our product. Mark N/A on any item that does not apply to the product.

Job Name: _____ McQuay G.O. no. _____

Installation Address: _____

City: _____ State: _____

Purchasing Contractor: _____

City: _____ State: _____

Name of person doing start-up (print): _____

- | | | | | | | |
|--|-------------|-------------|--------|------|--|--|
| 1. Is there any shipping damage visible? | Yes | No N/A | | | | |
| Location on unit _____ | | | | | | |
| 2. How would you rate the overall appearance of the product; i.e., paint, fin damage, etc.? | | | | | | |
| <table border="0" style="display: inline-table; margin: 0 10px;"> <tr> <td style="padding: 0 10px;">Excellent</td> <td style="padding: 0 10px;">Good</td> <td style="padding: 0 10px;">Fair</td> <td style="padding: 0 10px;">Poor</td> </tr> </table> | Excellent | Good | Fair | Poor | | |
| Excellent | Good | Fair | Poor | | | |
| 3. Did all sections of the unit fit together properly? | Yes | No N/A | | | | |
| 4. Did the cabinet have any air leakage? | Yes | No N/A | | | | |
| Location on unit _____ | | | | | | |
| 5. Were there any refrigerant leaks? | Yes | No N/A | | | | |
| <table border="0" style="display: inline-table; margin: 0 10px;"> <tr> <td style="padding: 0 10px;">Shipping</td> <td style="padding: 0 10px;">Workmanship</td> <td style="padding: 0 10px;">Design</td> </tr> </table> | Shipping | Workmanship | Design | | | |
| Shipping | Workmanship | Design | | | | |
| 6. Does the refrigerant piping have excessive vibration? | Yes | No N/A | | | | |
| Location on unit _____ | | | | | | |
| 7. Did all of the electrical controls function at start-up? | Yes | No N/A | | | | |
| Comments _____ | | | | | | |
| 8. Did the labeling and schematics provide adequate information? | Yes | No N/A | | | | |
| 9. How would you rate the serviceability of the product? | | | | | | |
| <table border="0" style="display: inline-table; margin: 0 10px;"> <tr> <td style="padding: 0 10px;">Excellent</td> <td style="padding: 0 10px;">Good</td> <td style="padding: 0 10px;">Fair</td> <td style="padding: 0 10px;">Poor</td> </tr> </table> | Excellent | Good | Fair | Poor | | |
| Excellent | Good | Fair | Poor | | | |
| 10. How would you rate the overall quality of the product? | | | | | | |
| <table border="0" style="display: inline-table; margin: 0 10px;"> <tr> <td style="padding: 0 10px;">Excellent</td> <td style="padding: 0 10px;">Good</td> <td style="padding: 0 10px;">Fair</td> <td style="padding: 0 10px;">Poor</td> </tr> </table> | Excellent | Good | Fair | Poor | | |
| Excellent | Good | Fair | Poor | | | |
| 11. How does the quality of McQuay products rank in relation to competitive products? | | | | | | |
| <table border="0" style="display: inline-table; margin: 0 10px;"> <tr> <td style="padding: 0 10px;">Excellent</td> <td style="padding: 0 10px;">Good</td> <td style="padding: 0 10px;">Fair</td> <td style="padding: 0 10px;">Poor</td> </tr> </table> | Excellent | Good | Fair | Poor | | |
| Excellent | Good | Fair | Poor | | | |

Comments:

Please list any additional comments which could affect the operation of this unit; i.e., shipping damage, failed components, adverse installation applications, etc. If additional comment space is needed, write the comment(s) on a separate sheet, attach the sheet to this completed Quality Assurance Survey Report, and return it to the Warranty Department with the completed preceding "Equipment Warranty Registration Form".

McQuay Training and Development

Now that you have made an investment in modern, efficient McQuay equipment, its care should be a high priority. For training information on all McQuay HVAC products, please visit us at www.mcquay.com and click on training, or call 540-248-9646 and ask for the Training Department.

Warranty

All McQuay equipment is sold pursuant to its standard terms and conditions of sale, including Limited Product Warranty. Consult your local McQuay Representative for warranty details. Refer to Form 933-43285Y. To find your local McQuay Representative, go to www.mcquay.com.

This document contains the most current product information as of this printing. For the most up-to-date product information, please go to www.mcquay.com.

